Foreword

IS300 series servo driver is a servo driver which is specially desiged for Drive permanent magnet synchronous servo motor (PMSM). IS300 series servo driver has a wide capacity range (the rated current is 5A to 300A). It's able to provide not only servo pump control, but also the general functional requirements.And it is a high-power servo driver which is value-for-money in the present market.

This manual is a guide to the operations of IS300 series servo driver.

This manual provides the user with related precautions and instructions for the prototyping, installation, parameter setup, and on-site commissioning, and routine repair and maintenance of servo driver. In order to use this series of driver correctly, please read this manual carefully prior to operation and keep it properly for future using. The supporting equipment customers shall distribute this manual together with the equipment to the final users.

Unpacking and inspection:

Please confirm carefully when unpacking the box:

- If the model and driver rated values on the nameplate are the same as your order. The box contains the equipment, certificate of conformity, user manual and warranty card.
- If the product is damaged during the transportation. If there is any omission or damage, please contact our company or the supplier immediately.

First time use:

The users who use this product for the first time shall read this manual carefully. For any doubt on certain functions and performances, please contact the technical support personnel of our company for help so as to use this product properly.

With commitment to the constant improvement of the servo driver, our company may change the information provided without additional notice.

CE

IS300 series servo driver complies with the following international standards, and some products have passed the CE certification.

IEC/EN61800-5-1:2003 "Safety Regulations on Commissionable Electric Drive System" and IEC/EN 61800-3:2004 Commissionable Electric Drive System: The third Part: Electromagnetic Compatibility Standard and Specific Testing Method for the Product (Comply with IEC/EN61800-3 standard under correct installation and use as per Article 7.3.2 and 7.3.6).

Contents

FOREWOR	۲D	I
CHAPTER	1 SAFETY AND PRECAUTIONS	2 -
1.1 Safety	precautions	2 -
1.2 Precaut	ions	5 -
CHAPTER	2 PRODUCT INFORMATION	8 -
2.1 Designation	ation Rules	8 -
2.2 Namep	ate	8 -
2.3 IS300 S	Servo Driver Series	9 -
2.4 Technic	al Specifications	10 -
2.5 Physica	I Appearance and Dimensions of Mounting Hole	13 -
2.6 Option	nal Parts	19 -
2.7 Routine	Repair and Maintenance of servo driver	20 -
2.8 Instruct	ions on Warranty of Driver	22 -
2.9 Prototy	bing Guide	22 -
2.10 Guide	to Prototyping of Brake Components	23 -
CHAPTER	3 MECHANICAL AND ELECTRIC INSTALLATION	27 -
3.1 Mecha	anical installation	27 -
3.2 Electric	al Installation	31 -
CHAPTER	4 OPERATION AND DISPLAY	45 -
4.1 Introduc	ction to Operation and Display Interface	45 -
4.2 Descrip	tion of Function Code Viewing and Modification Methods .	48 -
4.3 Short	cut Menu Operation Mode	49 -
4.4 Method	of Viewing Status Parameter	51 -
4.5 Passwo	ord Setting	51 -
4.6 Automa	tic Tuning of Motor Parameters	52 -
CHAPTER	5 FUNCTION PARAMETER TABLE	55 -
CHAPTER	6 PARAMETER DESCRIPTION	89 -
Group U0	Driver parameters viewing group	89 -
Group A0	Weak magnetism and SVC control group (SAV control re	served)
89 -		
Group A1	PG Card Group	90 -
Group A2	CAN Communication Group	91 -
Group F0	Basic Function Group	97 -
Group F1	Motor Parameters	106 -
Group F2	Vector Control Parameters	109 -
Group F3	V/F Control Parameters	114 -
Group F4	Input Terminal	117 -

Group F5	Output Terminal	128 -				
Group F6	Start/Stop Control	133 -				
Group F7	Keyboard and Display	137 -				
Group F8	oup F8 Auxiliary Function 1					
Group F9	Fault and Protection	148 -				
Group FD (Communication Parameters(Reserved)	154 -				
Group FP	User Password	154 -				
CHAPTER	7 SERVO PUMP COMMISSIONING STEPS AND PRO	TOTYPING				
OF SERVC	PUMP OPTIONAL PARTS	159 -				
7.1 Servo F	Pump Commissioning Process	159 -				
7.2 Servo F	Pump Commissioning Steps	160 -				
7.3 Servo d	il pump optional parts prototyping	164 -				
CHAPTER	8 EMC (ELECTROMAGNETIC COMPATIBILITY)	169 -				
8.1 Definition	on	169 -				
8.2 EMC S	andard Description	169 -				
8.3 EMC G	uide	170 -				
CHAPTER	9 FAILURE DIAGNOSIS AND SOLUTION	175 -				
9.1 Failure	Diagnosisi and Solution	175 -				
9.2 Commo	on Fault and Resolution	190 -				
APPENDIX	1: COMMON PARAMETERS TABLE	194 -				
APPENDIX	2 SHORTCUT MENU PARAMETERS TABLE	201 -				



Safety and Precautions

Chapter 1 Safety and Precautions

Safety definition:

In this manual, safety precautions are divided into two types below:



Danger arising due to improper operations may cause severe hurt or even death.

<u>∕</u>Î∖Note

Danger arising due to improper operations may cause moderate hurt or light hurt or equipment damage.

1.1 Safety precautions

1.1.1 Before Installation:

🦸 🚵 Danger

- Do not use the damaged driver or driver with missing parts. Otherwise, there may be risk of injury.
- Use the motor with Class B or above insulation. Otherwise, there may be risk of electric shock.

1.1.2 During the Installation:

A Danger

• Mount the driver on incombustible surface like metal, and keep away from flammable substances. Otherwise it may cause fire.

Note 2. When more than two servo drivers are to be installed in one cabinet, pay attention to the installation locations (refer to Chapter 3 Mechanical and Electrical Installation) to ensure the cooling effect. 3. Do not drop the lead wire stub or screw in the servo driver. Otherwise it may damage the servo driver.

1.1.3 During wiring:

🤌 🚵 Danger

- Operation shall be performed by the professional engineering technician. Otherwise there will be danger of electric shock!
- There shall be circuit breaker between the servo driver and power supply. Otherwise, there may be fire!
- Make sure the power is disconnected prior to the connection. Otherwise there will be danger of electric shock!
- The earth terminal shall be earthed reliably. Otherwise there may be danger of electric shock.

<u>/</u>Note

- 6. Do not connect the input power cable to the output ends U, V and W. Otherwise it may damage the servo driver.
- 7. Ensure the wiring meet the EMC requirements and the local safety standard. The wire size shall be determined according to the manual. Otherwise, accident may be caused!
- 8. The brake resistor cannot be directly connected between the DC bus terminals (+) and (-). Otherwise it may cause fire.

1.1.4 Before Power-on:

🦧 🔏 Danger

- Before Power-on:
- Please confirm whether the power voltage class is consistent with the rated voltage of the servo driver and whether the I/O cable connecting positions are correct, and check whether the external circuit is short circuited and whether the connecting line is firm. Otherwise it may damage the servo driver!
- The cover must be well closed prior to the servo driver power-on. Otherwise electric shock may be caused!

∕<u>I</u>∖Note

 Whether all the external fittings are connected correctly in accordance with the circuit provided in this manual. Otherwise accident may occur!

1.1.5 Upon Power-on:

🦌 🚵 Danger

- Do not open the cover of the servo driver upon power-on. Otherwise there will be danger of electric shock!
- Do not touch the servo driver and its surrounding circuit with wet hand. Otherwise there will be danger of electric shock!
- Do not touch the servo driver terminals (including control terminal). Otherwise there will be danger of electric shock!
- At power-on, the servo driver r will perform the security check of the external heavy-current circuit automatically. Thus, at this time please do not touch the terminals U, V and W, or the terminals of motor, otherwise there will be danger of electric shock.

∕Note

- If parameter identification is required, please pay additation to the danger of injury arising from the rotating motor. Otherwise accident may occur!
- Do not change the factory settings at will. Otherwise it may damage the equipment!

1.1.6 During the operation:

🌾 🛕 Danger

- Do not approach the mechanical equipment when selecting the restart function. Otherwise it may cause injury!
- Do not touch the fan or discharge resistor to sense the temperature. Otherwise, you may get burnt!
- 3. Detection of signals during the operation shall only be conducted by qualified technician. Otherwise, personal injury or equipment damage may be caused!

/I Note

- 4. During the operation of the servo driver, keep items from falling into the equipment. Otherwise, it may damage the equipment!
- 5. Do not start and stop the servo driver by connecting and disconnecting the contactor. Otherwise, it may damage the equipment!

1.1.7 During Repair

🖌 🛕 Danger

- Do not repair and maintain the equipment with power connection. Otherwise there will be danger of electric shock!
- be sure to conduct repair and maintenance after the charge LED indictor of the servo driver is OFF. Otherwise, the residual charge on the capacitor may cause personal injury!
- The servo driver shall be repaired and maintained only by the qualified person who has received professional training. Otherwise, it may cause personal injury or equipment damage!

1.2 Precautions

1.2.1 Motor Insulation Inspection

When the motor is used for the first time, or when the motor is reused after being kept, or when periodical inspection is performed, it shall conduct motor insulation inspection so as to avoid damaging the driver because of the insulation failure of the motor windings. The motor wires must be disconnected from the driver during the insulation inspection. It is recommended to use the 500V megameter, and the insulating resistance measured shall be at least $5M\Omega$.

1.2.2 Thermal Protection of the Motor

If the rated capacity of the servo motor does not match those of the driver, especially when the rated power of the driver is higher than the rated power of the motor, the relevant motor protection parameters in the driver shall be adjusted, or thermal relay shall be mounted to protect the motor.

1.2.3 Motor Heating and Noise

Since the output voltage of servo driver is PWM wave and contains certain

harmonics, the temperature rise, noise and vibration of the motor will be higher than those when it runs at standard frequency.

1.2.4 Voltage-sensitive Device or Capacitor Improving Power Factor at the Output Side

Since the servo driver output is PWM wave, if the capacitor for improving the power factor or voltage-sensitive resistor for lightning protection is mounted at the output side, it is easy to cause instantaneous over current in the servo driver, which may damage the servo driver. It is recommended that such devices not be used.

1.2.5 Switching Devices like Contactors Used at the Input and Output terminal

If a contactor is installed between the power supply and the input terminal of the driver, it is not allowed to use the contactor to control the startup/stop of the driver. If use of such contactor is unavoidable, it shall be used with interval of at least one hour. Frequent charge and discharge will reduce the service life of the capacitor inside the driver. If switching devices like contactor are installed between the output end of the driver and the motor, it shall ensure that the on/off operation is conducted when the driver has no output. Otherwise the modules in the driver may be damaged.

1.2.8 Use under voltage rather than rated voltage

If the driver is used outside the allowable working voltage range as specified in this manual, it is easy to damage the devices in the driver.

When necessary, use the corresponding step-up or step-down instruments to change the voltage.

1.2.7 Change Three-phase Input to Two-phase Input

It is not allowed to change the IS300 series three-phase servo driver into two-phase one. Otherwise, it may cause fault or damage to the servo driver. 1.2.8 Lightning Protection

Servo driver of the series has lightning over current protection device, and has certain self-protection capacity against the lightning. In applications where lightning occurs frequently, the user shall install additional protection devices at the front-end of the driver.

1.2.9 Altitude and Derating

In areas with altitude of more than 1,000 meters, the cooling effect of the driver may turn poorer due to rare air. Therefore, it needs to derate the driver for use. Please contact our company for technical consulting in case of such condition.

1.2.10 Certain Special Use

If the user needs to use the driver with the methods other than the recommended wiring diagram in this manual, such as shared DC bus, please consult our company.

1.2.11 Precaution of Driver Disposal

The electrolytic capacitors on the main circuit and the PCB may explode when they are burnt. Emission of toxic gas may be generated when the plastic parts are burnt. Please dispose the servo driver as industrial wastes.

1.2.12 Adaptable Motor

- 1) The standard adaptable Permanent-Magnet Synchronous Motor
- Since the servo driver has built-in standard parameters of the adaptable motors, it is necessary to perform motor parameter identification or modify the default values so as to comply with the actual values as much as possible, or it may affect the running effect and protection performance;
- 3) The short circuit of the cable or motor may cause alarm or explosion of the driver. Therefore, please conduct insulation and short circuit test on the newly installed motor and cable. Such test shall also be conducted during routine maintenance. Please note that the servo driver and the test part shall be completely disconnected during the test.

2

Product Information

Chapter 2 Product Information

2.1 Designation Rules



Fig. 2-1 Designation Specification

2.2 Nameplate

MODELI	IS300T005-C				
INPUT ^I	3PH AC380V 10.5A 50/60Hz				
OUTPUT	3PH AC0 [] 380V 9.0A 0Hz [] 300Hz				
S/N:	Barcode				
Shenzhen Inovance Technology Co.,Ltd.					

Fig.2-3 Nameplate

2.3 IS300 Servo Driver Series

Servo Driver Model	Input voltage	(kVA) Power supply capacity (kVA)	(A) Input curren t (A)	(A) Output curren t (A)	(kgf) system pressure of Adaptable Injection Moulding Machine (kgf)	(L/min) Maximum Flow Rate of Adaptable Injection Moulding Machine (kgf)
IS300T005		5.9	10.5	9.0		20
IS300T010		8.9	14.6	13.0		30
IS300T015		11.0	20.5	17.0		40
IS300T020	Three-p	17.0	26.0	25.0	175	60
IS300T030		21.0	35.0	32.0		75
IS300T035		24.0	38.5	37.0		85
IS300T040	hase	30.0	46.5	45.0		105
IS300T050	380V Bango:	40.0	62.0	60.0		140
IS300T070	15%~	57.0	76.0	75.0	175	180
IS300T080	20%	69.0	92.0	91.0		210
IS300T100		85.0	113.0	112.0		260
IS300T140		114.0	157.0	150.0		360
IS300T170		134.0	180.0	176.0		420
IS300T210		160.0	214.0	210.0		500
IS300T250		192.0	256.0	253.0		600
IS300T300		231.0	307.0	304.0		720

Table 2-1 IS300 Servo Driver Series Model and Technical Data

2.4 Technical Specifications

lte	m	Specifications					
	Maximum frequency	300Hz					
	Carrier frequency	0.5k to 16kHz; t automatically adju characteristics.	the carrier frequency will be isted according to the load				
	Input frequency resolution	Digital setting: 0.01 Analog setting: max	Digital setting: 0.01Hz Analog setting: maximum frequency ×0.1%				
	Control mode	Close loop vector co V/F control	ontrol (VC)				
	Startup torque	0Hz/180% (VC)	0Hz/180% (VC)				
Individualiz ed function	Speed adjustment range	1:1000 (VC)					
	Speed stabilization precision		±0.02%(VC)				
	Torque control precision	±5%(VC)					
	Overload capacity	150% rated current	60s; 180% rated current 5s.				
	nt output voltage automatically in nains voltage.						
Individualiz ed function	Peripherals self-detectio n upon power-on	It can conduct safety detections on the peripherals upon power-on, including earth and short circuit detections.					

Table 2-2 IS300 Servo Driver Technical Specifications

lte	m	Specifications
	Shared DC Bus Function	It can realize the function that multiple drivers share the DC bus.
	QUICK key	The user can freely define short-cut menus.
	MF.K Key	Programmable key: Select the command channel switching/forward and reverse rotations/jog operation.
	Running command channel	Three types of channels: operation panel setup, control terminal setup,serial communication port setup and CAN communication port setup. These channels can be switched in various modes.
	Frequency source	There are types of frequency sources, such as analog voltage setup, analog current setup, serial portsetup and CAN setup. These frequency sources can be switched in various modes.
Run	Auxiliary Frequency source	It can implement micro tuning and synthesis of auxiliary frequency.
	Input terminal	There are five digital input terminals, It can be compatible with enabled PNP or NPN input mode. One motor PTC overheating protection input terminal. There are three analog input terminals, two of which can be used only as voltage input, while the other can be used as voltage or current input.
	Output terminal	There are three relay input terminals.One is NO/NC with optional, the other two are NO. Two analog output terminals, with optional 0//4mA to 20mA or 0/2V to 10V.
	Communicat ion terminal	CAN Communication terminal RS485 Communication terminal

lte	m	Specifications				
Display and Keyboard Operation	LED display	It can display the parameters.				
	Key locking and function selection	It can lock the keys partially or completely and define the functional range of certain keys so as to prevent error operations.				
	Protection function	It can implement power-on motor short-circuit detection, input/output phase loss protection, over current protection, over voltage protection, under voltage protection, over heat protection and overload protection.				
	Optional parts	reakers components and PG card, etc.				
	Using Place	Indoor, and be free from direct sunlight, dust, corrosive gas, combustible gas, oil smoke, vapor, drip or salt.				
	altitude	Lower than 1,000 meters				
Envir onm ent	Ambient temperature	-10 $^\circ\!\!{\rm C}$ Celsius to +40 $^\circ\!\!{\rm C}$ Celsius (derated when used in the ambient temperature of 40 $^\circ\!\!{\rm C}$ Celsius to 50 $^\circ\!\!{\rm C}$ Celsius)				
	Humidity	Less than 95%RH, without condensing				
	Vibration	Less than 5.9 m/s ² (0.6g)				
	Storage temperature	-20 $^\circ\!\mathrm{C}$ Celsius \sim +60 $^\circ\!\mathrm{C}$ Celsius				

2.5 Physical Appearance and Dimensions of Mounting Hole

2.5.1 Physical Appearance



Fig.2-4 Schematic Diagram for Physical Dimensions and Mounting Hole Dimensions



 $\oplus \oplus \oplus \oplus \oplus$

Fig.2-5 Schematic Diagram for Physical Dimensions and Mounting Hole Dimensions

2.5.2 Physical Dimensions and Mounting Hole Dimensions

Table 2-3 Physical Dimensions and Mounting Hole Dimensions (mm)

Model	Mour Ho	Iounting Hole Physical Dimensions					Diamete r of	Weight
Woder	Α	В	н	H1	w	D	Mountin g Hole	(kg)
IS300T005	1/9	236	249	,	160	192	65	2.5
IS300T010	148	230	240	/	100	105	ψυ	2.0
IS300T015								
IS300T020	190	305	322	/	208	192	φ6	6.5
IS300T030								
IS300T035	235	447	432	463	285	228	Ф8	20

Madal	Mour Ho	nting ole	Physical Dimensions				Diamete r of	Weight
Woder	Α	В	н	H1	W	D	Mountin g Hole	(kg)
IS300T040								
IS300T050								
IS300T070								
IS300T080	260	580	549	600	385	265	φ10	32
IS300T100								
IS300T140	242	670	660	700	470	207	<i>c</i> .10	47
IS300T170	343	0/0	000	700	473	307	φισ	47
IS300T210								
IS300T250	449	905	880	930	579	375	φ10	90
IS300T300								

1) Physical Dimensions of External Keyboard



Fig.2-6 Schematic Diagram for Physical Dimensions of External Keyboard





Fig.2-7 Schematic Diagram for Mounting Hole Dimensions of External Keyboard



3) Schematic Diagram for Physical Dimensions of External reactor

Fig.2-8 Schematic Diagram for Physical Dimensions of External Reactor

Servo Driver Model	A	В	с	D	E	F	G	Fixing Hole	Connec ting Diamet er of Copper Platoon
IS300T140 IS300T170 IS300T210	16 0	190	12 5	161	192	255	195	10*15	φ12
IS300T250 IS300T300	16 0	190	12 5	161	192	255	195	10*15	φ12

Table 2-4 Physical Dimensions table of External Reactor (mm)

<u>Note</u>

• For special requirements, the user can customize non-standard products.

*External DC reactor installation mode:

IS300 series Servo Driver of over IS300T140 (included), all employs standard external DC reactor, which is packed in independent wooden box and

delivered together with the Servo Driver. When mounting the Servo Driver, the user needs to remove the short circuit bus between the terminals P and (+) of the main circuit of the Servo Driver and then connect the DC reactor between P and (+). There is no polarity between the reactor terminal and the Servo Driver terminals P and (+). After the DC reactor is mounted, the short circuit bus between P and (+) will not be used.

2.6 **Optional Parts**

For detailed functions and usage instructions, see the related options description.

If you require the following options, see description when ordering.

Name	Model	Function	Remarks
Built-in brake unit	The letter "B" attached behind the product model	Built-in brake unit of IS300T035 to IS300T050 (optional)	Built-in brake unit of IS300T005 to IS300T030 is standard configuration.
External brake unit	MDBU	External brake unit of above IS300T070 (included)	If IS300T140 (included) or above is required, it can employ the parallel mode.
Energy feedback unit	MDFB	The servo driver is a energy saving product which can feed the electric energy back to AC power grid.	It can employ the parallel mode.
External LED operation panel	MDKE	External LED display and operation keyboard	IS300 series general-purpose RJ45 interface

Table 2-5 IS300 Servo Driver Optional Parts

Name	Model	Function	Remarks
Extended cable	MDCAB	Standard 8-core network cable and it can be connected with MDKE.	1m, 3m,5m and 10m are available.
Rectifier unit	MFRU	It is used when the driver shares the bus and has energy saving function.	

2.7 Routine Repair and Maintenance of Servo Driver

2.7.1 Routine Repair

The influence of the ambient temperature, humidity, dust and vibration will cause the aging of the devices in the servo driver, which may cause potential fault of the servo driver or reducing the service life of the servo driver. Therefore, it is necessary to carry out routine and periodical maintenance on the servo driver.

🦸 🚵 Danger

It is not allowed to conduct repair and maintenance on the driver right after power shutdown because there is still high voltage on the filter capacitor. The repair or maintenance can be conducted only after the charge LED indictor is OFF and the bus voltage measured with multimeter is less than 36V.

Routine inspection Items include:

- 1) Whether there is any abnormal change in the running sound of the motor;
- 2) Whether the motor has vibration during the running;
- Whether there is any change to the installation environment of the servo driver;
- 4) Whether the servo driver cooling fan works normally;
- 5) Whether the servo driver has over temperature;

Routine cleaning:

- 1) The driver shall be kept clean all the time.
- The dust on the surface of the servo driver shall be effectively removed, so as to prevent the dust entering the servo driver. Especially the metal dust is not allowed.
- 3) The oil stain on the driver cooling fan shall be effectively removed.

2.7.2 Periodic Inspection

Please perform periodic inspection on the places where the inspection is a difficult thing.

Periodic inspection Items include:

- 1) Check and clean the air duct periodically;
- 2) Check if the screws are loosened;
- 3) Check if the driver is corroded;
- 4) Check if the wire connector has arc signs;
- 5. Main circuit insulation test

<u>/</u>Note

When using the megameter (DC 500V megameter recommended) to measure the insulating resistance, the main circuit shall be disconnected with the servo driver. Do not use the insulating resistance meter to control the insulation of the circuit. It is not necessary to conduct the high voltage test (which has been completed upon delivery).

2.7.3 Replacement of Vulnerable Parts for Driver

The vulnerable parts of the driver include cooling fan and filter electrolytic capacitor, whose service life depends on the operating environment and maintenance status. General service life is shown as follows:

Part name	Service Life
fan	2 to 3 years
electrolytic capacitor	4 \sim 5 years

The user can determine the year of replacement according to the operating time.

1) Cooling fan

Possible reason for damage: Bearing is worn and blade is aging.

Judging criteria: Whether there is crack on the blade and whether there is abnormal vibration noise upon startup.

2) Filter electrolytic capacitor

Possible reason for damage: Input power supply in poor quality, high ambient temperature, frequent load jumping, and electrolyte aging.

Judging criteria: Whether there is liquid leakage and whether the safe valve has projected, and measure the static capacitance, and the insulating resistance.

2.7.4 Storage of Driver

Upon acquiring the driver, the user shall pay attention to the following points regarding the temporary and long-term storage of the driver:

- 1) Pack the driver with original package and place back into the packing box of our company.
- 2) Long-term storage will degrade the electrolytic capacitor. Thus, the product shall be powered up once every 2 years, each time lasting at least five hours. The input voltage shall be increased slowly to the rated value with the regulator.

2.8 Instructions on Warranty of Driver

Free warranty only applies to the driver itself.

- Our company will provide 18-month warranty (starting from the leave-factory date as indicated on the barcode) for the failure or damage under normal use conditions. If the equipment has been used for over 18 months, reasonable repair expenses will be charged.
- 2) Reasonable repair expenses will be charged for the following situations within 18 months:
 - a) The equipment is damaged because the user fails to comply with the requirements of the user's manual;
 - b) Damage caused by fire, flood and abnormal voltage;
 - c) Damage caused when the driver is used for abnormal function.

The service expenses will be calculated according to the standard of the manufacturer. If there is any agreement, the agreement shall prevail.

2.9 Prototyping Guide

Three control modes are available, namely, V/F and VC.

When selecting driver, it must firstly make clear the technical requirements of the system for variable frequency speed adjustment and specific details regarding the applications and load characteristics of the driver, and select the model and determine the operating mode through taking into overall consideration the adaptable motor, output voltage, rated output current and other factors.

The basic principle is that the rated load current of the motor shall not exceed the rated current of the inverter. Generally, the selection is based on the adaptable motor capacity as specified in the instruction manual. Due attention shall be paid to the comparison between the rated currents of motor and inverter. The overload capacity of the inverter only affects the startup and brake process. In case short-time overload occurs during the running process, variation of load speed may arise. If the requirement for the speed precision is relatively high, it can consider increasing the level.

Constant torque load: Most of loads have constant toque characteristics, but the requirements for rotation speed and dynamic performance are low. Extruding machine, agitator, belt conveyer, transporting trolley in the factory, and translational unit of crane are the examples. It can select MS V/F running mode when performing prototyping test.

The controlled object has higher dynamic and static index requirements: It can employ VC control mode in applications where the requirements for speed adjustment precision and dynamic performance index are relatively high and there is high precision synchronous control. Injection molding machine, elevator, paper making and plastic thin film processing product line are the examples.

2.10 Guide to Prototyping of Brake Components

(*): Table 6 Driver Bake Components Prototyping Table provides data for reference, and the user can select different resistance and power according to the actual needs (but the resistance shall not be lower than the recommended value, and the power may be higher than the recommended value). The selection of brake resistor shall be determined in accordance with the power generated by the motor in the actual application system and is associated with the system inertia, speed-down time and energy of potential load. Thus, the user needs to select based on the actual needs. The higher the system inertia, the shorter the speed-down time required, and more frequent the brake is, and then it needs to select higher power and lower resistance value for the brake resistor.

2.10.1 Selection of resistance vlaue

Renewable electric energy consumption is almost the braking resistor when braking.

Refer to the formula U*U/R=Pb,

In the formula, U refers to stable Braking system of Brake voltage. (Different system has different brake voltage. The system 380VAC is 700V).Pb refers to the Braking power.

2.10.2 Selection of braking resistor Power

Theoretically, braking Power is consistent with braking Power.But in consideration of the 70 percent derating, please refer to the formula 0.7*Pr=Pb*D, Pr refers to the resistor Power, D refers to braking frequency(Which is the regeneration process accounting for the proportion of the whole working process).For example, the braking frequency of elevator is between 20% to 30%, the winding and unwinding is between 20% to 30%.The centrifuge is between 50% to 60%, Occasional braking load is 5%. Injection molding machine braking load is 10%.

Servo Driver model	Recommended Power of Brake Resistor	Recommended Resistance Value of Brake Resistor	Braking Unit	Remarks
IS300T005	300W	≥130Ω		
IS300T010	400W	≥90Ω		
IS300T015	500W	≥65Ω		
IS300T020	800W	≥43Ω	Built-in as	No special
IS300T030	1000W	≥32Ω	standard	specification
IS300T035	1300W	≥25Ω		
IS300T040	1500W	≥22Ω		
IS300T050	2500W	≥16Ω		
IS300T070	3.7 kW	≥16Ω	Externally connected	MDBU-35-B
IS300T080	4.5 kW	≥16Ω	Externally connected	MDBU-35-B
IS300T100	5.5 kW	≥8Ω	Externally connected	MDBU-70-B
IS300T140	7.5 kW	≥8Ω	Externally connected	MDBU-70-B
IS300T170	4.5 kW×2	≥8Ω×2	Externally connected	MDBU-70-B×2
IS300T210	5.5 kW×2	≥8Ω×2	Externally connected	MDBU-70-B×2

Table 2-6Servo driver Bake Components Prototyping Table

Servo Driver model	Recommended Power of Brake Resistor	Recommended Resistance Value of Brake Resistor	Braking Unit	Remarks
IS300T250	6.5 kW×2	≥8Ω×2	Externally connected	MDBU-70-B×2
IS300T300	16kW	≥2.5Ω	Externally connected	MDBU-210-B

Note: ×2 refers to two Braking unit paralleled with their respective brake resistor; the meaning of ×3 is the same with ×2.



Mechanical and Electric

Chapter 3 Mechanical and Electric Installation

3.1 Mechanical installation

3.1.1 Installation environment:

- 1) Ambient temperature: The ambient temperature exerts great influences on the service life of the servo driver and is not allowed to exceed the allowable temperature range (-10 °C Celsius to 50 °C Celsius).
- 2) The driver shall be mounted on the surface of incombustible articles, with sufficient spaces nearby for cooling. The servo driver is easy to generate large amount of heat during the operation. The servo driver shall be mounted vertically on the base with screws.
- 3) The servo driver shall be mounted in the place without vibration or with vibration of less than 0.6G, and shall be kept away from such equipment as punching machine.
- 4) The servo driver shall be mounted in locations free from direct sunlight, high humidity and condensate.
- 5) The servo driver shall be mounted in locations free from corrosive gas, explosive gas or combustible gas.
- 6) The servo driver shall be mounted in locations free from oil dirt, dust, and metal powder.



Single Unit Installation Diagram



Upper and Lower Parts



When the servo driver power is not higher than IS300T040, the A size can be omitted. When the servo driver power is higher than IS300T040, the A size shall be higher than 50mm.

∕Note

When installing the upper and lower parts of the servo driver, the insulating splitter is required.

Power level	Physical Dimensions		
	В	Α	
≤IS300T030	≥100mm	No requirements	
IS300T035—IS300T050	≥200mm	≥50mm	
≥IS300T070	≥300mm	≥50mm	

Fig.3-1 Servo Driver Installation Diagram

3.1.2 Cooling problem shall be taken into account during the mechanical installation. Pay attention to the following items:

- Install the servo driver vertically so that the heat may be expelled from the top. However, the equipment cannot be installed upside down. If there are multiple servo drivers, parallel installation is a better choice. In applications where the upper and lower parts of the driver need to be installed, please refer to "Servo driver Installation Diagram" and install an insulating splitter.
- 2) The mounting space shall be as indicated as the above figure, so as to ensure the cooling space of the Servo driver. However, the heat dissipation of other devices in the cabinet shall also be taken into account.
- 3) The installation bracket must be flame retardant.
- 4) In the applications where there are metal dusts, it is recommended to mount the radiator outside the cabinet. In this case, the space in the sealed cabinet shall be large enough.

3.1.3 Removing and mounting the down cover plate:

The IS300T030 (included) employs plastic enclosure. Please refer to Figure 3-2 for removing the lower cover plate of the plastic enclosure. The hooker of

the lower cover plate is easy to pull out with tools by forces inside.



Fig.3-2 Removing the Down Cover Plate of Plastic Enclosure

The servo driver above IS300T035 (included) employs sheet-metal enclosure. Please refer to Figure 3-3 for removing the down cover plate of the sheet-metal enclosure. It is easy to loosen the screws of the upper cover plate with tools.





Fig.3-3 Removing the Down Cover Plateof Sheet-Metal Enclosure

3.1.4 The Installation of permanent-magnet synchronous servo motor and pressure transducer

Servo motors work process will appear to start and stop state from repeated high-speed. It easily lead to motor vibration, causing system instability. Please make sure that the electrical installation is fixed and reasonable.

Take the following one installation fixed way (the massive rubber cushion with fixed bolts) as an example for reference.



Fig.3-4 Permanent-magnet Synchronous Servo Motor Installation Diagram
The Servo pump work process would lead to vacuum state, in order to prevent air entering the pressure sensor intra-cavity that cause the pressure sensor damaged, please ensure the pressure sensor cavity always retain hydraulic oil, Please follow the oil pressure sensor installed vertically upward, as shown at the filowing.



Fig.3-5Pressure Sensor Installtion Mode

3.2 Electrical Installation

3.2.1 Guide to the external electrical parts:

Table 3-1 Guide to Prototyping of External Electrical Parts of IS300 servo

driver						
Servo Driver Modle	Circui t break er(MC CB) (A)	Reco mme nded Cont actor (A)	Recomm end-ed Input filterA	Recomm end-ed Conduct ing Wire of Main Circuit at the Input Side mm ²	Recomm ended Conducti ng Wire of Main Circuit at the Output Side mm ²	Recomm e-nded Conduct ing Wire of Control Circuit mm ²
IS300T005	25	16	25	4	4	1.5
IS300T010	32	25	35	4	4	1.5

Servo Driver Modle	Circui t break er(MC CB) (A)	Reco mme nded Cont actor (A)	Recomm end-ed Input filterA	Recomm end-ed Conduct ing Wire of Main Circuit at the Input Side mm ²	Recomm ended Conducti ng Wire of Main Circuit at the Output Side mm ²	Recomm e-nded Conduct ing Wire of Control Circuit mm ²
IS300T015	40	32	35	4	4	1.5
IS300T020	63	40	50	4	4	1.5
IS300T030	63	40	50	6	6	1.5
IS300T035	100	63	80	6	6	1.5
IS300T040	100	63	80	10	10	1.5
IS300T050	125	100	100	16	10	1.5
IS300T070	160	100	120	16	16	1.5
IS300T080	200	125	150	25	25	1.5
IS300T100	200	125	150	35	25	1.5
IS300T140	250	160	200	50	35	1.5
IS300T170	250	160	200	70	35	1.5
IS300T210	350	350	250	120	120	1.5
IS300T250	400	400	300	150	150	1.5
IS300T300	500	400	400	185	185	1.5

3.2.2 Using instruction of external electrical parts:

Table 3-2 Instruction for the Use of External Electrical Parts of IS300 Servo

Driver

Part Name	Mounting Location	Function description
Circuit	Front end of input	Disconnect the power supply when the
Dreaker	Circuit	equipment at the lower part is over current.
Contactor	Between the circuit breaker and the servo driver input side	Connection and disconnection of servo driver. Frequent power-on and power-off operations on the servo driver shall be avoided.
AC input reactor	Input side of the servo driver	 Improve the power factor of the input side; Eliminate the higher harmonics of the

Part Name	Mounting Location	Function description
		input side effectively and prevent other equipment from damaging due to distortion of voltage wave.3) Eliminate the input current unbalance due to unbalance between the power phases.
EMC Input filter	Input side of the servo driver	 Reduce the external conduction and radiation interference of the servo driver. Decrease the conduction interference flowing from the power end to the servo driver and improve the anti-interference capacity of the servo driver.
DC reactor	IS300 series servo driver adopts DC reactor above IS300T015 (included) as standard.	 Improve the power factor of the input side; Improve the whole efficiency and thermal stability of the servo driver. Eliminate the impact of higher harmonics of the input side on the servo driver and reduce the external conduction and radiation interference.
AC output reactor	Between the servo driver output side and the motor. Close to the servo driver.	 The servo driver output side generally has higher harmonics. When the motor is far from the servo driver, since there are many distributed capacitors in the circuit, certain harmonics may cause resonance in the circuit and bring about the following two impacts: 1) Degrade the motor insulation performance and damage the motor for the long run. 2) Generate large leakage current and cause frequent servo driver protection. In general, the distance between the servo driver and the motor exceeds 100 meters. Installation of output AC reactor is recommended.

3.2.3 Connections of servo pump



Schematic Diagram for Servo Pump Connections

3.2.4 Main Circuit Terminals and Connections

🌾 🚵 Danger

- Make sure that the power switch is in OFF status prior to perform wiring connection. Otherwise there may be danger of electric shock!
- •
- Only the qualified and trained personnel can perform wiring connection. Otherwise it may cause equipment and human injuries!
- It shall be earthed reliably. Otherwise there may be danger of electric shock or fire!
- Make sure that the rated value of the input power supply is consistent with that of the driver. Otherwise it may damage the driver!
- Make sure that the motor matches the driver. Otherwise it may damage the motor or generate driver protection!
- Do not connect the power supply to the terminals of U, V and W. Otherwise it may damage the driver!
- Do not directly connect the brake resistor between the DC bus terminals (+) and (-). Otherwise it may cause fire!

1) **Description** of main circuit terminals of single-phase servo driver:

Terminals	Name	Description
R、S、T R、 S and T	Input terminal of three-phase power supply	AC single-phase 220V power connection point
(+)、(-)(+) and (-)	Negative and positive terminals of DC bus	Shared DC bus input point (connection point of external braking unit of above IS300T070 (included)
(+)、PB(+) and PB	Connecting terminal of brake resistor	Connection point of Brake resistor of below IS300T050(included)
P、(+)P and (+)	Connection terminal of external reactor	Connection point of external reactor above IS300T140(included)
U、V、W U, V and W	Output terminal of servo driver	Connect the three-phase motor
	Earth terminal	Earth terminal

3) Precautions on Wiring:

a) Input power R, S and T:

The cable connection at the input side of the servo driver has no phase sequence requirement.

b) DC bus (+) and (-) terminals:

Note that the (+) and (-) terminals of DC bus have residual voltage right after power-on. It needs to wait until the CHARGE indictor is OFF and make sure that the voltage is less than 36V prior to wiring connection. Otherwise there may be danger of electric shock.

When selecting external brake unit for the driver of above IS300T07 (inculded), the poles of (+) and (-) shall not be connected reversely, or it

may damage the driver and even cause fire.

The wiring length of the brake unit shall not exceed 10 meters. Twisted wires or pair wires shall be used and connected in parallel.

Do not connect the brake resistor directly to the DC bus, or it may damage the servo driver and even cause fire.

c) Connecting terminals (+) and PB of brake resistor:

The connecting terminals of the brake resistor are effective only for the servo driver of below IS300T050 (inculded) with built-in brake unit. The prototype of brake resistor can refer to the recommended value and the wiring length shall be less than 5 meters. Otherwise it may damage the servo driver.

d) Connecting terminals P and (+) of external reactor:
 For the servo driver of above IS300T140 (included)with external reactor, when assembling, remove the connector between terminals P and (+) and connect a reactor instead.

e) Terminals U, V, W at the output side of the servo driver:

The servo driver output side cannot connect to the capacitor or surge absorber. Otherwise, it may cause frequent servo driver protection and even damage the servo driver.

In case the motor cable is too long, it may generate electrical resonance easily due to the impact of distributed capacitance, thus damaging the motor insulation or generating higher leakage current to invoke over current protection of the servo driver. When the length of motor cable is longer than 100 meters, it needs to install a AC output reactor.

f) Earth terminal \bigoplus PE:

This terminal shall be earthed reliably, with resistance of earth cable of less than 0.1Ω . Otherwise, it may cause fault or damage the servo driver.

Do not share the earth terminal and zero line of the power supply.

3.2.5 Control terminals and connection:

1) The control circuit terminals are arranged as follows:



Fig.3-7 Layout of Control Circuit Terminals

2) Function description of control terminal:

Table 3-3 Description of Control Terminal Function of Servo Driver

Туре	Terminal	Terminal name	Function description
power su	+10V-GND	10V power supply	Provide 10V±10% power supply for external- units, and the maximum output current is 10mA. It is generally used as the operating power supply for the external potentiometer. The potentiometer resistance range is $1k\Omega \sim 5k\Omega$.
oply	+13V-GND	Pressure sensor power supply	Provide 13V±10% power supply for external units. The maximum output current is 10mA. It is generally used as the operating power supply for pressure sensor.

Туре	Terminal	Terminal name	Function description
	+24V-COM +24V power supply		Provide +24V power supply for external units. It is generally used as the operating power supply for digital input/output terminals. 24V±10%, no-load vitual voltage can not exceed 30V. The maximum output current is 200mA. It is internally insulated with GND.
	OP	External power input terminal	COM and 24V is internally insulated .Connect to 24V by default upon delivery. When external signal is used to drive DI1 \sim DI5, OP needs to connect to the external power supply and disconnect from the +24V power terminal.(It is determined by the J4 jumper on the control board.)
Anal og Input	Al1-GND	Analog input terminal 1 (The default pressure setting)	Input Voltage range: ±10V The resolution is 12 bit, the correction precision is 0.5 pensent. 2、 Input resistance: 100kΩ。 Input resistance: 100kΩ.
	AI2-GND	Analog input terminal 2 (The default flow settup)	 The resolution is 12 bit, the correction precision is 0.5 pensent. Input resistance: 100kΩ.
	Al3-GND	Analog input terminal 3 (default pressure sensor signal input)	 Input range: ±10V/0 to 20mA, which is determined by J3 jumper on the control board. There is 12-bit resolution, the correction precision is 0.5 pensent. Input impedance: It is 100kΩ at the time of voltage input and 500Ω at the time of current input.

Туре	Terminal	Terminal name	Function description
	DI1-COM	Digital input 1	1 、 Insulate drain-to-source input
	DI2-COM	Digital input 2	programmable terminals,input
	DI3-COM	Digital input 3	frequency is less than 100 Hz;
Digit	DI4-COM	Digital input 4	 Input resistance: 3.3kΩ;
al Input	DI5-COM	Digital input 5	3、Voltage range for level input: $9V^{\sim}~30V_{\circ}$
	PTCP-PTCN	Motor overheating protection input	Motor overheating protection PTC sensor,support PTC130 、 PTC150 etc.
	CANH	CAN	The higest communication speed is
Com	CANL	CAN	1Mbps.Whether to connect terminal
muni catio	CGND	terminal	resistance is determined by the J4 jumper on the control board.
n	485B	195	Retain the terminal without the
Termi nal	485A	Communication terminal	funtion by default, the highest communication speed is 230Kbps with isolation.
Anal	AO1-GND	Analog output 1	The voltage or current output is determined by the J3 jumper on the control board. Output range: 0V \sim 10V and 0mA \sim 20mA. There is 12-bit resolution, the correction precision is 1 pensent, the maximum load resistance value is not less than 500 Ω .
og Outp ut	AO2-GND	Analog output 2	The voltage or current output is determined by the J24 jumper on the control board. Output range: 0V \sim 10V and 0mA \sim 20mA. There is 12-bit resolution, the correction precision is 1 pensent,the maximum load resistance value is not less than 500 Ω .
Real y	T/A1-T/B1	Normally closed terminal	Contact driving capacity:

Туре	Terminal	Terminal name	Function description
outp		Normally open	AC250V, 3A, COSφ=0.4。
ut	TAT-TICT	terminal	DC 30V, 1A。
		Normally open	
	1/AZ-1/GZ	terminal	
	T/A2 T/C2	Normally open	
	1/A3-1/C3	terminal	
Auxil			
ary		External keyboard	External keyboard and parameter
interf	CINKI	interface	copy unit interface
ace			

Function Instructions of PG Card Terminal

Table 3-4 Function Instructions c	f Servo Driver	PG Card Terminal
-----------------------------------	----------------	------------------

ltem	name	Description		
1	EXC	Excitation Signal		
2	/EXC	Excitation Signal		
3	SIN	CIN Foodbook Signal		
4	SINLO	SIN Feedback Signal		
5	COS	COS Foodbook Signal		
9	COSLO	COS Feedback Signal		
6	PTC-P	Motor overheating protection PTC		
7	PTC-N	sensor,support PTC130 、 PTC150 ,etc.		
8				

3) Description of Connection of control terminals:

A. Analog input terminal:

Since the weak analog voltage signal is easy to suffer external interferences, it needs to employ shielded cable generally and the length shall be no longer than 20 meters, as shown in Fig. 3-8. In case the analog signal is subject to severe interference, and analog signal source side shall be installed with filter capacitor or ferrite magnetic core, as shown in Fig.3-9.



Fig.3-8 Schematic Diagram for Connection of Input Terminal of Analog Signal





B: Digital input terminal:

It needs to employ shielded cable generally, with cable length of no more than 20 meters.

When enabled driving is adopted, necessary filtering measures shall be taken to prevent the interference to the power supply.

It is recommended to use the contact control mode.

C. DI Terminal Connection:

1、



Fig.3-11 Connection with dry contact sharing the negative pole

This is one of the most commonly used connection mode. If external power supply is used, it must remove the short circuit copper bars between +24V and OP respectively, (which is determined by J11 jumper on the control board.) and connect the positive pole of external power supply to OP and negative pole to CME.



Fig.3-11 Connection with dry contact sharing the positive pole

It must remove the short circuit copper bar between +24V and OP $\,$ (which is determined by J11 jumper on the control board.) and then connect OP with CME.



Operation and Display



Chapter4 Operation and Display

4.1 Introduction to Operation and Display Interface

With the operation panel, it can perform such operations on the driver as function parameter modification, driver working status monitoring and driver running control (startup and stop). Refer to Fig.4-1 for the physical appearance and functional zone of the operation panel.



Fig.4-1 Operation Panel Diagram

1) Description of Function LED Indictor:

RUN: When it is OFF, it indicates the driver is in stop status; when it is ON, it indicates the driver is in rotation status.

LOCAL/REMOT: It is the LED indictor for keyboard operation, terminal operation and remote operation (communication control). When it is OFF, it indicates the keyboard operation control status; when it is ON, it indicates the terminal operation control status; when it flashes, it indicates the remote operation control status.

FWD/REV: It is the LED indictor for forward/reverse rotation. When it is OFF, it indicates the driver is in forward rotation status; when it is ON, it indicates the driver is in reverse rotation status.

TUNE/TC: It is the LED indictor for tuning. When it is ON it indicates the torque control status; when it is OFF, it indicates the speed control status.

2) Unit LED indictor description:

Hz refers to frequency unit.

- A refers to current unit.
- V refers to voltage unit.

RPM refers to rotation speed unit.

- % refers to percentage
- 3) Digital display zone:

Five-digit LED display, able to display setup frequency, output frequency, various monitoring datas and alarm codes.

4) Keyboard button description

Button	Name	Function
PRG	Programming key	entry and exit of primary menu, deletion of shortcut parameter
ENTER	Confirmation key	enter the menu interfaces level by level, and confirm the set parameters.
\wedge	Increase key	increase of the data or function code
\vee	Decrease key	decrease of the data or function code
>>	Shift key	Select the displayed parameters in turn on the stop display interface and running display interface, and select the modification digit of parameters when modifying parameters.
RUN	Running key	It is used to start the running of the driver under keyboard control mode.
STOP/RESET	Stop/reset	Press this button to stop the running in the running status and reset the operation in the fault alarm status. These button characteristics are limited by the function code F7-02.
QUICK	Shortcut key	It can be used to enter or exit level 1 menu of the shortcut menu. Refer to the QUICK operation description for details.
MF.K	Multi-function selection key	In case F7-01=0, it has no function; In case F7-01=1, it serves as the key switching between local operation and remote operation. In case F7-01=2, it serves as forward/reverse rotation switching key; In case F7-01=3, it serves as forward rotation Jog key; Refer to F7-01 for the detailed operation.

Table 4-1 Keyboard Function

4.2 Description of Function Code Viewing and Modification Methods

The operation panel of the IS300 servo driver adopts three-level menu structure to carry out operations such as parameter setting.

The three-level menu includes function parameter set (level 1 menu) \rightarrow Function code (level 2 menu) \rightarrow Function code setup value (level 3 menu). Refer to Fig.4-2 for the operation procedure.



Fig.4-2 Operation Procedure of Three-level Menu

Note: When operating on level 3 menu, press PRG key or ENTER key to return to level 2 menu. The difference between PRG key and ENTER key is described as follows: Pressing ENTER KEY will save the setup parameter and return to the level 2 menu and then automatically shift to the next function code, while pressing PRG key will directly return to level 2 menu without saving the parameter, and it will return to the current function code.

Example: Modify the function code F3-02 from 10.00Hz to 15.00Hz. (The bold-type work indicates the flashing bit.)



Fig.4-3 Example of parameter editing operation

In level 3 menu, if the parameter has no flashing bit, it indicates that the function code cannot be modified. The possible reasons include:

1) The function code is an unchangeable parameter, such as actual detection parameter, running record parameter, etc.

2) The function code cannot be modified in running status. It can be modified only after the unit is stopped.

4.3 Shortcut Menu Operation Mode

The shortcut menu is set to facilitate the user to quickly view and modify the commonly used function parameters. In the shortcut menu, the parameter is displayed in the form of "UA3-01", which indicates the function parameter A3-01. Parameter modification in the shortcut menu has the same effect as the operation in the common programming status.

The shortcut menu can contain 16 function parameters at most. If there are 16 parameters and the user wants to add more, it will display "FULL". If "NULL" is displayed when entering the menu, it indicates that the shortcut menu is NULL. The shortcut menu operation is limited by the function code F7-03. When F7-3 is set to "0", addition or deletion operation can be performed on the shortcut menu. When F7-03 is set to "1", the parameter option is locked and addition or deletion operation is inenabled.

The shortcut menu has stored the 16 common parameters by default for the convenience of the user:

uA3-01	Maximum rotation speed	uA3-09	Minimum flow
uA3-02	System oil pressure	uA3-10	Minimum pressure
uA3-03	Maximum oil pressure	A3-20	AI zero drift auto correction
uA3-04	Oil pressure command	uF2-00	Speed loop proportional
risetime		gain 1	
uA3-05	Kp1Oil pressure control	uF2-01	Speed loop integration
Kp1		time 2	
uA3-06	Ti1 Oil pressure control Ti1	uF2-03	Speed loop proportional
uA3-07	Td1 Oil pressure control	gain 2	
Td1		uF2-04	Speed loop integration
uA3-08	Maximum reverse rotation	time 2	
speed			
uF4-32	AI3 Input filter time		

The user can edit the shortcut menu in accordance with the actual needs.

1) Add shortcut parameter item:



Fig.4-4 Example of Adding Shortcut Parameter Item Note: When pressing QUICK key during the programming of level 2 menu, the

display flashes and prompts whether to save the parameter into shortcut menu. Press ENTER key for confirmation, the display stops flashing, and the operation is completed. Press PRG key to cancel, the display stops flashing, and the operation is cancelled.

2) Modification of shortcut parameters



Fig.4-5 Example of Modification of Shortcut Parameters

Run or Stop Desplay:

Note: In Stop or running display interface, press QUICK key to enter shortcut key, and select different shortcut parameters with UP/DOWN key. Then press ENTER key to enter next level of menu. At this time the modification method of shortcut parameter is the same as that of the parameters in common level 3 menu. To return to the upper level display, press QUICK key, and the modified parameters will not be saved.

3) Delete shortcut parameter item:



Fig.4-6 Deletion of Shortcut Menu

Note: Press PRG key in shortcut menu, the display flashes and prompts whether to delete the parameter. Press ENTER key for confirmation, the display stops flashing and the deletion operation is completed. Press QUICK key, the display stops flashing, and the deletion operation is canceled. If the last shortcut parameter is deleted, "NULL" will be displayed upon deletion, indicating that the shortcut menu is NULL.

4.4 Method of Viewing Status Parameter

In stop or running status, it can display multiple status parameters. It can select whether to display the parameter through the function codes F7-04 (running parameter) and F7-05 (stop parameter) in accordance with the binary bits. For the meanings of the binary bits, refer to Chapter 6 F7-04 and F7-05 Function Codes for details.

In the **running** status, five running status parameters are always displayed, namely, setup frequency, bus voltage, output voltage, and output current, and other sixteen parameters, namely, DI input status, DO output status, analog input Al1 voltage, analog input Al2 voltage, analog input Al3 voltage and four reserved parameters ,etc.They are displayed in accordance with the selection of F7-04 (converted into decimal system). The displaying of the selected parameters may be switched by the button sequence.

In the stop status, there are totally sixteen stop status parameters for selection, namely, setup frequency, bus voltage, DI input status, DO output status, analog input AI1 voltage, analog input AI2 voltage, analog input AI3 voltage (or current) and five reserved parameters,They are displayed in accordance with the selection of F7-05 (converted into decimal system).The displaying of the selected parameters may be switched by the button sequence.

When the servo driver is restarted upon power shutdown, the displayed parameters are the parameters selected before the power shutdown.

4.5 Password Setup

The driver provides user password protection function. When FP-00 is set to non-zero value, it indicates the user password, and the password protection turns valid after exiting the function code editing status. When pressing PRG key again, "-----" will be displayed, and common menu cannot be entered until user password is input correctly.

To cancel the password protection function, enter with password and set FP-00 to "0".

The user password protection for the parameter items in the shortcut men depends on the status of F7-03, and is inenabled for the parameter values.

4.6 Automatic Tuning of Motor Parameters

To select the vector control running mode, it must input the nameplate parameter of the motor accurately prior to the running of the driver. The IS300 servo driver will select standard motor parameters matching the nameplate parameter. Since the vector control mode relies highly on the motor parameters, it must acquire the accurate parameters of the controlled motor to ensure the good control performance.

The procedures for the automatic tuning of motor parameters are described below:

First, select the command source (F0-02) as the command channel of the operation panel.

Second, input the following parameters in accordance with the actual motor parameters:

F1-01: Rated motor power	F1-04: Rated motor frequency				
F1-02: Rated motor voltage	F1-05:	Rated	rotation	speed	of
F1-03: Rated motor current	motor				

If the back EMF of motor is unknown, please make the motor completely disconnect from the load, and set F1-16="2"(dynamic tuning),and press RUN key on the keyboard panel, then the servo driver will automatically calculate the following parameters:

F1-11: D axis inductors	F1-14: Unit
F1-12: Q axis inductors	F1-15: Back EMF
F1-13: Stator resistance	A1-02: Encoder installation angle

Finally, complete the dynamic tuning of motor parameters.

If the motor back-EMF is known, please set the parameter to F1-15 according to the motor back-EMF ,the motor can not be completely disconnect from the load, and set F1-16="2" (dynamic tuning),and press RUN key on the keyboard panel, then the servo driver will automatically calculate the following parameters:

F1-10: No-load current	F1-14: Unit
F1-11: D axis inductors	F1-15: Back EMF
F1-12: Q axis inductors	A1-02: Encoder nstallation angle I
F1-13: stator resistor	

Finally, complete the static tuning of motor parameters.

You can calculate motor back-EMF according to the motor basic parameters, the motor basic parameters for calculation are rated-EMF coefficient of V1000rpm (V/1000rpm) and the rated speed v (RPM):

Motor back EMFcalculation method as show follows: Back EMF: Vemf = V1000 * v/1000



Function Parameter Table

Chapter 5 Function Parameter Table

If FP-00 is set to non-zero value, it means parameter protection password is set, and the parameter menu cannot be entered until correct password is input. To cancel the password, it needs to set FP-00 to "0".

The parameters in the shortcut menu are free from password protection.

The symbols in the function table are described as follows:

It indicates that the parameter setup value can be modified when the driver is in stop status and running status.

It indicates that the parameter setup value cannot be modified when the driver is in the running status.

It indicates that the numerical value of the parameter is the actually measured value, which cannot be modified.

"*": It indicates this parameter is "Factory default parameter" and can be set only by the manufacturer.

Function Parameter Table (Common Parameter reference to appendix table)

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
	Gr	oup U0 Driver l	Parameter Viewing Gr	oup		
U0-00	Running frenquency	Running frenquency	0.00Hz \sim maximum frequency (F0-10)			•
U0-01	Setup frenquency	Setup frenquency	$\begin{array}{ll} 0.00 \text{Hz} & \sim & \text{T} \\ \text{maximum frequency} \\ (\text{F0-10}) \end{array}$			•
U0-02	Bus voltage	Bus voltage	$0V\sim~830V$	_	_	•
U0-03	Output voltage	Output voltage	$0V \sim$ Motor rated voltage (F1-02)			•
U0-04	Output Current	Output Current	0.01A \sim 655.35A			•
U0-05	Output power	Output power	0.4kW \sim 1000.0kW	I	I	•
U0-06	Output torque	Output torque	0.0% \sim Upper limit torque (F2-10)	_	_	•
U0-07	Local DI/DO status	Local DI/DO status	$\begin{array}{c} Unused \\ \downarrow \\ $	•		
U0-08	Expansion DI / DO status	Expansion DI / DO status	$\begin{array}{c} \downarrow \downarrow$	DIB DI7 DI6 \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow \downarrow	-Input status -Mark line -Output status	•
U0-09	Voltage(after corrected)	Voltage(after corrected)	-10.00V~10.000V	_	_	•
U0-10	AI12 voltage after corrected)	AI12 voltage after corrected)	-10.00V~10.000V	_	_	•

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion			
U0-11	Al3voltage after corrected)	Al3voltage after corrected)	-10.00V~10.000V	_	-	•			
U0-12~ U0-29	Reserved	_	_	_	_	•			
U0-30	AI11voltage (before corrected)	Al11voltage (before corrected)	-10.00V~10.000V	_	-	•			
U0-31	AI12voltage before corrected)	AI12voltage before corrected)	-10.00V~10.000V		_	•			
U0-32	AI13voltage before corrected)	AI13voltage before corrected)	-10.00V ~10.000V	_	_	•			
	Group A0 Weak Magnetism and SVC Control Group								
A0-00	Weak magnetism control mode	Weak magnetism control mode	0: Direct calculation 1: Automatic adjustment	1	0	*			
A0-01	Weak magnetismcurren t coefficient	Weak magnetism current coefficient	80%~200%	1	100%	*			
A0-02	Weak magnetism current upper limit	Weak magnetismcurre nt upper limit	0~120	1	100%	*			
A0-03	Weak magnetism Integral multiples	Weak magnetism <u></u> Integral multiples	200~1000	1	400	*			
A0-04	Weak magnetism adjustment <u></u> coefficient	Weak magnetism adjustment coefficient	0~100	1	4	*			
A0-05	Output phase failure PWM detection time	Output phase failure PWM detection time	0~63000	1	0	*			
		Group	A1 PG Card						

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
A1-00~ A1-01	Reserved	-	-	-	-	*
A1-02	Encoder installation angle	Encoder installation angle	0.0°~359.9°	0.1°	0.0°	\$
A1-03	Select the reverse feedback speed	Select the reverse feedback speed	0~1	1	0	\$
A1-04	Rotary transformer number of pole-pairs	Rotary transformer number of pole-pairs	1~50	1	1	*
		Group A2 CAN C	Communication Group)		
A2-00	Baud rate selection	Baud rate selection	0: 20k 1: 50k 2: 125k 3: 250k 4: 500k 5: 1M	1	4	☆
A2-01	CAN communication address	CAN communication address	1~255	1	1	\$
A2-02	CAN communication continuous time	CAN communication continuous time	0.0s (inenabled) 0.1s \sim 5.0s	0.1s	0.0s	\$
		Group F0 Bas	sic Function Group			
F0-00	Model display	Model display	1: G model (heavy load model) 2: P model (light load model)	1	Model depende nt	•

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F0-01	Control mode	Control mode	0: Speed sensorless vector control (SVC) 1: Speed sensor vector control (VC) 2:V/F control	1	1	*
F0-02	Command source selection	Command source selection	0: 0:Operation panel running command channel (LED OFF) 1: Terminal command channel (LED ON) 2: Serial port command channel (LED flashes)	1	0	X5
F0-03	Main frequency source X selection	Frequency source X selection	0: Digital setup UP and DOWN adjustment (non-recorded) 1: Digital setup UP and DOWN adjustment (recorded) 2: Al1 3: Al2 4: Al3 5:Reserved 6: MS speed 7: Resvered 8: Resvered 9: Communication setup	1	1	*

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F0-04	Auxiliary Frequency source Y selection	Auxiliary Frequency source Y selection	0:Digital setup UP and DOWN adjustment (non-recorded) 1: Digital setup UP and DOWN adjustment (recorded) 2: Al1 3: Al2 4: Al3 5:Reserved 6: MS speed 7: Reserved 8: Reserved 9: Communication setup	1	0	*
F0-05	Auxiliary Frequency source Y range selection	Auxiliary Frequency source Y range selection	0: Relative to maximum frequency 1: Relative to frequency source X	1	0	\$
F0-06	Auxiliary Frequency source Y	Frequency source Y range	0%~100%	1%	100%	☆

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F0-07	Frequency source selection	Frequency source selection	0: Main frequency source X 1: Main frequency source X plus auxiliary frequency source Y 2: Switching between main frequency source X and auxiliary frequency source Y 3: Switching between main frequency source X and (main frequency source X plus auxiliary frequency source Y) 4: Switching between main frequency source Y and (main frequency source Y) 4: Switching between main frequency source X plus auxiliary frequency source X and (main	1	0	X4
F0-08	Preset frequency	Preset frequency	0.00Hz ~ the maximum frequency F0-10	0.01Hz	50.00Hz	\$
F0-09	Running direction	Running direction	0: Consistent direction 1:Reverse direction	1	0	\$
F0-10	Maximum frequency	Maximum frequency	50.00Hz~300.00Hz	1	200.00 Hz	*

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F0-11	Frequency source upper limit	Frequency source upper limit	0: F0-12 setup 1: Al1 2: Al2 3: Al3 4: Reserved 5: Communication setup	1	0	*
F0-12	Frequency upper limit	Frequency upper limit	Frequency lower limit F0-14 ~ maximum frequencyF0-10	0.01Hz	200.00H z	¥
F0-13	Frequency upper limit offset	Frequency upper limit offset	0.00Hz ~ The maximum frequency F0-10	0.01Hz	0.00Hz	☆
F0-14	Frequency lower limit	Frequency lower limit	0.00Hz ~ frequency upper limit F0-12	0.01Hz	0.00Hz	☆
F0-15	Carrier frequency	Carrier frequency	0.5kHz~16.0kHz	0.1kHz	Model depende nt	☆

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F0-16	Carrier frequency adjustment selection	Carrier frequency adjustment selection	0: Fixed PWM, carrier frequency temperature adjustment is inenabled 1: Random PWM, carrier frequency temperature adjustment inenabled 2: Fixed PWM, carrier wave temperature adjustment valid 3: Random PWM, carrier frequency temperature adjustment enabled	1	2	¥
F0-17	Speed-up time 1	Speed-up time 1	0.0s~6500.0s	0.1s	20.0s	☆
F0-18	Speed-down time1	Speed-down time1	0.0s~6500.0s	0.1s	20.0s	*
		Group F1	Notor Parameters		_	
F1-00	Motor type selection	Motor type selection	0: Common asynchronous motor 1: Variable frequency asynchronous motor 2: Permanent magnetic synchronous motor	1	2	*
F1-01	Rated power	Rated power	0.4kW~1000.0kW	0.1kW	Model depende nt	*

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F1-02	Rated voltage	Rated voltage	0V∼440V	1V	Model depende nt	*
F1-03	Rated current	Rated current	0.01A~655.35A	0.01A	Model depende nt	*
F1-04	Rated frequency	Rated frequency	0.00 \sim max	0.01Hz	Model depende nt	*
F1-05	Rrated rotation speed	Rated rotation speed	0rpm \sim 30000rpm	1rpm	Model depende nt	*
F1-06~ F1-10	Reserved	_	_	—	—	${\simeq}$
F1-11	D axis inductors	D axis inductors	0~65535	1	Model depende nt	*
F1-12	Q axis inductor	Q axis inductor	0~65535	1	Model depende nt	*
F1-13	Stator resistance	Stator resistance	0~65535	1	Model depende nt	*
F1-14	Unit	Unit	00~12	01	Model depende nt	*
F1-15	Back EMF	Back EMF	0∼65535V	1	Model depende nt	*

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F1-16	Tuning selection	Tuning selection	0: No operation 1: Static tuning(low speed) 2: Dynamic tuning (high speed) 3: Tuning mode	1	0	*
		Group F2 Vect	or Control Parameters	S		
F2-00	Speed loop proportional gain 1	Speed loop P1	0~100	1	60	¥
F2-01	Speed loop integration time 1	Speed loop I1	0.01s~10.00s	0.01s	0.30s	☆
F2-02	Switching frequency 1	Switching frequency 1	0.00~F2-05	0.01Hz	5.00Hz	¥
F2-03	Speed loop proportional gain 2	Speed loop P2	0~100	1	60	\$
F2-04	Speed loop integration time 2	Speed loop I2	0.01s~10.00s	0.01s	0.30s	☆
F2-05	Switching frequency 2	Switching frequency 2	F2-02 \sim the maxnimum	0.01Hz	10.00Hz	☆
F2-06	Slip compensation coefficient	Slip coefficient	50%~200%	1%	100%	\$
F2-07	Time constant of speed loop filter	Speed loop filter	0.000s~0.100s	0.001s	0.000s	☆
F2-08	Torque control	Torque control	0: Inenabled 1: Enabled	1	0	$\stackrel{\wedge}{\sim}$

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F2-09	Torque upper limit	Torque upper limit	0: F2-10 1: Al1 2: Al2 3: Al3 4: Reserved 5: Communication setup Analog input scale corresponds to F2-10.	1	0	*
F2-10	Torque upper limit	Torque upper limit	0.0%~250.0%	0.1%	200.0%	☆
F2-11	Encoder pulse number	Encoder pulse number	1~65535	1	1024	*
F2-12	Reserved	—	_	-	_	*
F2-13	D axis current loop Kp	D axis current loop Kp	0~65535	1	50	*
F2-14	D axis current loop Ki	D axis current loop Ki	0~65535	1	50	*
F2-15	Q axis current loop Kp	Q axis current loop Kp	0~65535	1	50	*
F2-16	Q axis current loop Ki	Q axis current loop Ki	0~65535	1	50	*
F2-17	SoftPwm selection	SoftPwm selection	0: Inenabled 1: Enabled	1	0	$\stackrel{\wedge}{\sim}$
Group F3 V/F Control Parameters						
F3-00	V/F curve setup	V/F curve setup	0: Straight V/F curve 1: Multiple-point V/F curve 2: Square V/F curve	1	0	*
Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
------------------	-------------------------------------	-------------------------------------	---	------------------	-----------------------------	---------------------------------------
F3-01	Torque boost	Torque boost	0.0: Automatic 0.1%∼30.0%0. 0:(automatic)0.1% to 30.0%	0.1%	1.0%	Å
F3-02	Cutoff frequency of torque boost	Cutoff frequency of torque boost	0.00 ~ maximum frequency	0.01Hz	50.00Hz	*
F3-03	V/F Frequency point 1	V/F Frequency point 1	0.00Hz ~ rated motor frequency	0.01Hz	0.00Hz	*
F3-04	V/F voltage point 1	V/F voltage point 1	0.0%~100.0%	0.1%	0.0%	*
F3-05	V/F frequency point 2	V/F frequency point 2	0.00Hz~motor rated frequency	0.01Hz	0.00Hz	*
F3-06	V/F voltage point 2	V/F voltage point 2	0.0%~100.0%	0.1%	0.0%	*
F3-07	V/F frequency point 3	V/F frequency point 3	0.00Hz~motor rated frequency	0.01Hz	0.00Hz	*
F3-08	V/F voltage point 3	V/F voltage point 3	0.0%~100.0%	0.1%	0.0%	*
F3-09	Slip compensation coefficient	Slip compensation coefficient	0.0%~200.0%	0.1%	0.0%	\$
F3-10	AVR selection	AVR selection	0: Inenabled 1: Enabled 2: Inenabled only at the time of deceleration	1	2	Υ.
F3-11	Oscillation suppression gain	Oscillation suppression gain	0~100	1	Mmodel depende nt	\$
		Group F4	Input Terminal			

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F4-00	DI1 terminal function selection	DI1 terminal selection	0: No function 1: Forward rotation (FWD) 2: Reverse rotation (REV) (oil pump enabled) 3: Three-line mode running control 4: Forward rotation Jog (FJOG) 5: Reverse rotation Jog (RJOG)	1	1	*
F4-01	DI2 terminal function selection	DI2 terminal selection	6: Terminal UP 7: Terminal DOWN 8:Free stop 9: Fault reset (RESET) 10: Pause 11: External fault normally open input 12: MS speed terminal 1	1	0	*

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F4-02	D13 terminal function selection	DI3 terminal selection	13:MSspeedterminal 214:MSspeed14:MSspeedterminal 315:MSspeedterminal 416:Speed-uptimeselection terminal 117:Speed-up/speed-downtimeselection terminal	1	9	*
F4-03	D14 terminal function selection	DI4 terminal selection	selection terminal 18:Main frequency source switching 19: UP and DOWN setup clear (terminal and keyboard) 20: Running command switching terminal 21: Speed-up/speed-do wn time inenabled 22~23:Reserved 32: DC brake command 33: External fault normally closed input 41~47: Reserved 48: Servo pump PID selection terminal 1	1	0	*

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F4-04	DI5 terminal function selection	DI5 terminal selection	49: Servo pump PID selection terminal 2 50 : CAN communication enabled	1	0	*
F4-05∼ F4-14	Reserved	Reserved		Reserve d	Reserve d	*
F4-15	DI terminal filter time	DI terminal filter time	1~10	1	4	☆
F4-16	Terminal command mode	Terminal command mode	0. Two-line mode 1 1. Two-line mode 2 2. Three-line mode 1 3. Three-line mode 2	1	0	*
F4-17	Change rate of terminals UP/DOWN	Change rate of terminals UP/DOWN	0.01 Hz/s ∼100.00Hz/s	0.01Hz/s	1.00Hz/s	☆
F4-18	AI1 minimum input	AI1 minimum input	-11.00V~11.00V	0.01V	0.02V	☆

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F4-19	AI1 minimum input corresponding setup	AI1 minimum setup	-100.0%~100.0%	0.1%	0.0%	\$
F4-20	AI1 maximum input	Al1 maximum input	-11.00V~11.00V	0.01V	10.00V	☆
F4-21	AI1 maximum input correspondi-ng setup	AI1 maximum setup	-100.0%~100.0%	0.1%	100.0%	*
F4-22	AI1 input filter time	AI1 filter time	0.00s~10.00s	0.01s	0.00s	☆
F4-23	AI2 minimum input	AI2 minimum input	-11.00V~11.00V	0.01V	0.02V	
F4-24	Al2 minimum input correspondi-ng setup	AI2 minimum setup	-100.0%~100.0%	0.1%	0.0%	☆
F4-25	AI2 maximum input	AI2 maximum input	-11.00V~11.00V	0.01V	10.00V	☆
F4-26	AI2 maximum input correspondi-ng setup	AI2 maximum input	-100.0%~100.0%	0.1%	100.0V	Å
F4-27	Al2input filter time	AI2 filter time	0.00s~10.00s	0.01s	0.00s	X
F4-28	AI3 minimum input	入AI3 minimum input	-11.00V~11.00V	0.01V	0.02V	\$
F4-29	AI3 minimum input correspondi-ng setup	AI3 minimum setup	-100.0%~100.0%	0.1%	0.0%	\$
F4-30	AI3 maximum input	AI3 maximum input	-11.00V~11.00V	0.01V	10.00V	☆

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F4-31	AI3 maximum input corresponding setup	AI3 maximum setup	-100.0%~100.0%	0.1%	100.0%	Υζ.
F4-32	AI3 input filter time	AI3 filter time	0.00s~10.00s	0.01s	0.00s	¥
F4-33~ F4-42	Reserved	Reserved	Reserved	Reserve d	Reserve d	¥
F4-43	Al1sample voltage	Al1sample voltage	-9.999V~9.999V	0.001V	2.000V	\$
F4-44	AI1 correction voltage 1	AI1 correction voltage 1	-9.999V~9.999V	0.001V	2.000V	\$
F4-45	AI1 sample voltage 2	AI1 sample voltage 2	-9.999V~9.999V	0.001V	8.000V	\$
F4-46	AI1 correction voltage 2	AI1 correction voltage 2	-9.999V~9.999V	0.001V	8.000V	Σγ
F4-47	AI1 sample voltage 1	AI1 sample voltage 1	-9.999V~9.999V	0.001V	2.000V	☆
F4-48	AI2 correction voltage 1	AI2 correction voltage 1	-9.999V~9.999V	0.001V	2.000V	Σγ
F4-49	Al2 sample voltage 2	Al2 sample voltage 2	-9.999V~9.999V	0.001V	8.000V	☆
F4-50	AI2 correction voltage2	AI2 correction voltage 2	-9.999V~9.999V	0.001V	8.000V	X4
F4-51	AI3 sample voltage1	AI3 sample voltage 1	-9.999V~9.999V	0.001V	2.000V	☆

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion		
F4-52	Al3 correction voltage1	AI3 correction voltage1	-9.999V~9.999V	0.001V	2.000V	☆		
F4-53	AI3 sample voltage2	Al3 sample voltage2	-9.999V~9.999V	0.001V	8.000V	☆		
F4-54	AI3 correction voltage2	AI3 correction voltage2	-9.999V~9.999V	0.001V	8.000V	☆		
F4-55~ F4-58	Reserved	-	-	-	-	☆		
Group F5 Output Terminal								
F5-00	Reserved	Reserved	Reserved	reserved	reserved	☆		
F5-01	Control board relay (T/A1-T/B1-T/C1)) output selection	Control board RELAY1 output selection	0: No output 1: Servo driver is running 2: Fault output 3: Frequency level detection FDT output 4: Frequency arrival 5: In zero speed	1	2	\$2		
F5-02	Control board relay (T/A2-T/C2) output selection)	Control board RELAY2 output selection	6: Motor overload pre-warning 7: Servo driver overload pre-warning 8~11: Reserved 12: Running time arrival	1	1	☆		

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F5-03	Control board relay (T/A3-T/C3) output selection	Control board RELAY3 output selection	 13: Frequency limiting 14: Torque limiting 15: Ready for running 16: Al1 is larger than Al2 17: Frequency upper limit arrival 18: Frequency lower limit arrival 19: Under voltage status output 20: Communication setup 21~22 Reserved 23: Swash Plate Switching of Double displacement plunger pump (NO) 24: Pressure control status output 25: Alarm output from pump(NC) 	1	0	\$\$
F5-04~ F5-09	Reserved	-	-	-	-	*

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F5-10	AO1 output selection	AO1output selection	0: Running 1: Setup frequency 2: Output current 3: Output torque 4: Output power 5: Output voltage 6:Reserved 7: Al1 8: Al2 9: Al3 10 : Feedback frequency 11 : Feedback voltage 12~16: Reserved	1	10	X5
F5-11	AO2 output selection	AO2 output selection			11	☆
F5-12~ F5-13	Reserved	-	-	-	-	☆
F5-14	AO1 offset coefficient	AO1 offset	-100.0%~100.0%	0.1%	0.0%	☆
F5-15	AO1 gain	AO1 gain	-10.00~10.00	0.01	1.00	\$
F5-16	AO2 offset coefficient	AO2 offset	-100.0%~100.0%	0.1%	0.0%	☆
F5-17	AO2 gain	AO2 gain	-10.00~10.00	0.01	1.00	Ŕ
F5-18~ F5-22	Reserved	-	-	-	-	☆
		Group F6	Start/Stop Control			

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F6-00	Start mode	Start mode	 Beginning from stop frequency Beginning from zero speed Beginning from maximum frequency 	1	0	\$
F6-01	Rotation speed tracking mode	Rotation speed tracking mode	 Beginning from stop frequency Beginning from zero speed Beginning from maximum frequency 	1	0	*
F6-02	Rotation speed tracking speed	Rotation speed tracking speed	1~100	1	20	☆
F6-03	Start frequency	Start frequency	0.00 Hz~10.00Hz	0.01Hz	0.00Hz	☆
F6-04	Start frequency retention time	Start retention time	0.0s∼36.0s	0.1s	0.0s	*
F6-05	DC brake current at start	DC brake current at start	0%~100%	1%	0%	*
F6-06	DC brake time at start	DC brake time at start	0.0s∼36.0s	0.1s	0.0s	*
F6-07	Speed-up/speed- down mode	Speed-up/ speed-down mode	0: Straight speed-up/speed-dow n 1:S-cruve speed-up/speed-dow n	1	0	*
F6-08	Start segment time of S curve	Start segment of S curve	0.0%~40.0%	0.1%	30.0%	*
F6-09	End segment time of S curve	Start segment of S curve	0.0%~40.0%	0.1%	30.0%	*
F6-10	Stop mode	Stop mode	0:Speed-down to stop 1: Free to stop	1	0	\$

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion		
F6-11	DC brake beginning frequency at stop	Brake frequency at stop	0.00Hz ~ maximum frequency	0.01Hz	0.00Hz	\$		
F6-12	DC brake waiting time at stop	Brake waiting at stop	0.0s∼36.0s	0.1s	0.0s	\$		
F6-13	DC brake current at stop	DC brake current at stop	0%~100%	1%	0%	\$		
F6-14	DC brake time at stop	DC brake time at stop	0.0s∼36.0s	0.1s	0.0s	*		
F6-15	Brake use ratio	Brake use ratio	0%~100%	1%	100%	☆		
Group F7 Keyboard and Display								
F7-00	LCD Language selection	Language selection	0: Chinese 1: English	1	0	☆		
F7-01	MF.K Key function selection	MF.K Key function selection	0:MF.K inenabled 1: Switching between operation panel command channel and remote command channel (terminal command channel or serial port communication command channel) 2: Switching between forward rotation and reverse rotation 3: Forward rotation Jog	1	0	*		

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F7-02	STOP/RESET key function	STOP key function	0: Enabled only in the keyboard control mode 1: STOP key enabled in the terminal control mode 2: STOP key fault reset function enabled in the terminal control mode 3: STOP key stop and fault reset function enabled in the terminal control mode	1	0	×5
F7-03	QUICK parameter lockout	Parameter lockout	0: QUICK parameter lockout inenabled 1: QUICK parameter lockout enabled	1	0	ž
F7-04	LED operation display parameter	Operation display	Reference to the last paragraph of chapter explaination	1	624	\$
F7-05	LED stop display parameter	Stop display	Reference to the last paragraph of chapter explaination	1	1139	☆
F7-06	Load speed display coefficient	Load speed coefficient	0.0001~6.5000	0.0001	1.0000	☆
F7-07	Radiator temperature 1	Radiator temperature 1	0.0℃~100℃	1 ℃	-	•
F7-08	Radiator temperature 2	Radiator temperature 2	0.0℃~100℃	1℃	-	•

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F7-09	Accumulated running time	Accumulated running time	0h \sim 65535h	1	-	•
F7-10	Software version No.1	Software version No.1	-	-	-	•
F7-11	Software version No.2	Software version No.2	-	-	-	•
		Group F8	Auxiliary Function			
F8-00	Jog running frequency	Jog running frequency	0.00Hz ~ maximum frequency	0.01Hz	2.00Hz	$\stackrel{\wedge}{\sim}$
F8-01	Jog speed-up time	Jog speed-up time	0.0s~6500.0s	0.1s	20.0s	$\stackrel{\wedge}{\simeq}$
F8-02	Jog speed-down time	Jog speed-down time	0.0s~6500.0s	0.1s	20.0s	$\stackrel{\wedge}{\simeq}$
F8-03	speed-up time 2	speed-up time 2	0.0s~6500.0s	0.1s	20.0s	☆
F8-04	Speed-down time 2	Speed-down time 2	0.0s~6500.0s	0.1s	20.0s	$\stackrel{\wedge}{\sim}$
F8-05	Speed-up time 3	Speed-up time 3	0.0s~6500.0s	0.1s	20.0s	\$
F8-06	Speed-down time 3	Speed-down time 3	0.0s∼6500.0s	0.1s	20.0s	☆
F8-07	Speed-up time 4	Speed-up time 4	0.0s∼6500.0s	0.1s	20.0s	☆
F8-08	Speed-up time 4	Speed-up time 4	0.0s~6500.0s	0.1s	20.0s	☆
F8-09	Skip frequency 1	Skip frequency 1	0.00Hz ~ maximum frequency	0.01Hz	0.00Hz	\$
F8-10	Skip frequency 2	Skip frequency 2	0.00Hz ~ maximum frequency	0.01Hz	0.00Hz	\$
F8-11	Skip frequency amplitude	Skip frequency amplitude	0.00Hz ~ maximum frequency	0.01Hz	0.01Hz	☆
F8-12	Forward/reverse rotation dead-zone time	Forward/reverse rotation dead-zone time	0.0s~3000.0s	0.1s	0.0s	*

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F8-13	Reverse control	Reverse control	0: Reverse rotation enabled 1: Reverse rotation inenabled	1	0	\$
F8-14	Set up frequency lower than frequency lower limit action	Frequency lower limit action	0: Run with frequency lower limit 1: Stop 2: Zero speed operation	1	0	*
F8-15	Droop control	Droop control	0.00Hz~10.00Hz	0.01Hz	0.00Hz	☆
F8-16	Over modulation enabled	Over modulation enabled	0: Over modulationinenabled1: Over modulationenabled	1	1	¥
F8-17	Setup running time	Setup running time	0h \sim 65535h	1h	65535h	☆
F8-18	Start protection selection	Start protection selection	0: No protection 1: Protection	1	0	☆
F8-19	Frequency detection value (FDTlevel)	FDT level	0.00 ~ maximum frequency	0.01Hz	50.00Hz	\$
F8-20	Frequency detection hysteresis (FDT- hysteresis)	FDT hysteresis	0.0% ~ 100.0%(FDT level)	0.1%	5.0%	\$
F8-21	Frequency arrival detection width	Frequency arrival width	0.0 ~ 100.0% (maximum frequency)	0.1%	0.0%	☆
F8-22	Earth short circuit protection detection upon power-on	Earth short circuit protection detection upon power-on	0: Inenabled 1: Enabled	1	1	Å

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F8-23	Running time to action selection	Running time to action selection	0: Continue running 1: Stop	1	0	*
		Group F9 Fa	ault and Protection			•
F9-00	Motor overload protection selection	Overload protection selection	0: Inenabled 1: Enabled	1	1	*
F9-01	Motor overload protection gain	Overload protection coefficient	0.20~10.00	0.01	1.00	\$
F9-02	Motor overload pre-warning coefficient	Overload pre-warning coefficient	50%~100%	1%	80%	☆
F9-03	Stall gain over voltage	Stall gain over voltage	0(No stall over voltage)	1	0	☆
F9-04	Stall protection voltage over voltage	Stall point over voltage	120%~150%	1%	130%	\$
F9-05	Stall gain over curren	Stall gain over curren	0~100	1	20	\$
F9-06	Stall protection current over current	Stall point over current	100%~200%	1%	150%	☆
F9-07	Transient stop/ non-stop function	Transient stop/ non-stop function	0: Inenabled 1: Enabled	1	0	X
F9-08	Transient stop/ non-stop frequency falling rate	Transient stop/ non-stop frequency falling rate	0.00Hz/s ~ maximum frequency/s	0.01Hz/s	10.00Hz/ s	☆
F9-09	Fault auto reset times	Fault auto reset times	0~3	1	0	☆

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F9-10	(T/A1-T/B1-T/C 1) Faulty rely action selection during the fault auto reset (T/A1-T/B1-T/C 1)		0:No action 1: Action	1	0	Υζ
F9-11	Fault auto-reset interval	Fault auto-reset interval	0.1s~100.0s	0.1s	1. Os	☆
F9-12	Input phase loss protection selection	Input phase loss selection	0: Inenabled 1: Enabled	1	1	*
F9-13	Output phase failure protection selection	Output phase failure selection	0: Inenabled 1: Enabled	1	1	74
F9-14	Velocity protection deviation	Velocity protection deviation	0.50Hz~50.00Hz	0.01Hz	10.00Hz	*
F9-15	Velocity deviation protection time	Velocity deviation protection time	0.0s Disable 0.0s Protection inenabled 0.1s \sim 20.0s	0.1	10.0s	7
F9-16	Motor temperture protection selection	Motor temperture protection selection	0: Inenabled 1: Enabled	1	0	☆
F9-17	Motor temperture protection mode	Motor temperture protection mode	0:D1 Signal input 1:A1 analog input 2-3:Reserved	1	0	7

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F9-18	The first fault type	The second fault type1	0: No fault 1: Reserved 2: Speed-up over current(Err 02) 3:Speed-down over current(Err 03) 4: Constant speed over current (Err 04) 5: Speed-up over voltage (Err 05) 6: Speed-down over voltage (Err 06) 7: Constant speed over voltage (Err 07) 8: Reserved 9: Under voltage failure (Err 09) 10: Servo driver overload (Err 10)	_		•
F9-19	The second failure type	The second failure type	10: Servo driver overload (Err 10) 11: Motor overload (Err 11) 12: Input phase failure (Err 12) 13: Output phase loss (Err 13) 14: Radiator overheating (Err 14) 15: External fault (Err 15) 16: Communication fault (Err 16) 17: Contactor fault (Err 17) 18: Current detection fault (Err 18) 19: Motor tuning fault		_	•

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F9-20	The last failure type	The third fault type	20: PG fault (Err 20) 21: Data overflow (21) 22: Reserved 23: Motor earth short circuit fault (23) 24~41: Reserved 42: CAN communication fault 43: Encoder fault (43) 44: Speed deviation protection fault (Err 44) 45: Motor temperature protection 46: Oil pressure sensor fault (Err46) 47~48:Relevant fault of multi-pump in parallel flow (Err47, Err48)	_		•
F9-21	Frequency upon fault	Frequency upon fault	_	_	_	•
F9-22	Current upon fault	Current upon fault	_	—	_	•

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
F9-23	Bus voltage upon fault	Bus voltage upon fault	_		_	•
F9-24	Input terminal upon fault	Input terminal upon fault	_	_	_	•
F9-25	Output terminal upon fault	Output terminal upon fault	_	_	—	•
		Group FD Com	nunication Parameter	s		
		Group FP	User Password		1	
FP-00	User password 1	Authorization for all functions code except FP-05	0~65535	1	0	\$
FP-01	Parameter initialization	Parameter initialization	0: No operation 1: Restore factory default setup value 2: Clear the fault record 3: Restore function code setup value saved by FP-05	1	0	*
FP-02	Motor specifications solidification	Motor specifications	0~65535	1	0	*
FP-03	Injection molding machine fixed specifications	Injection molding machine specifications	0~65535	1	0	*
FP-04	User password 2	Authorization to the FP-05 function code	0~65535	1	0	*

Function code	Name	LED display	Setup range	Minimu m unit	Factory default value	Modific- ation descrip-t ion
FP-05	Function code setting values in real time saved	Save all the present function setup value code	0:No operation 1: Save all the present function setup value code	1	0	*

6

Parameter Description and Solution

Chapter 6 Parameter Description

Group U0 Driver parameters viewing group

Group A0 Weak magnetism and SVC control group (SAV control reserved)

A0-00	Weak magnetism control mode		Factory default value	0
	Setup	0	Direct calculation	n
	range 1		Automatic adjustment	

A0-01	Weak magnetism current Coefficient	n t	Factory default value	100%
	Setup	80%~200%		
	range			

A0-02	Weak magnetisn current up limit	า per	Factory default value	100%
	Setup	0~120		
	range			

A0-03	Weak magnetism Integral multiples	า	Factory default value	400
	Setup	200~ 1000		
	range	200	~ 1000	

A0-04	Weak magnetism adjustment coefficient		Factory default value	4
	Setup range	0~1000		

When A0-00 ="0", calculate the weak magnetism directly, the actual output of weak magnetism current is to multiply the theoretical value by weak magnetic current coefficient (A0-01), the greater setup value is,the greater the weak magnetic current will be, the better the dynamic effect will be. But it may cause speed and current oscillation if it is too large.

When A0-00=1, adjust weak magnetism current automaticlly, get the required minimum weakening current. Adjustment speed is determined by weak magnetism adjustment coefficient (A0-04), the bigger setup value is, the faster the adjustment will be.But it may be caused by speed and current oscillation if it is too large.

A0-05	Output phase failure PWM detection time		Factory default value	0
	Setup range	0~63000)	

Determine the phase failure detection time, the value is equal to zero that does not do output phase failure detection, it can automaticlly set up after motor parameter tuning.

Group A1 PG Card Group

A1-00~	Reserved		Factory default value	_
A1-01	Setup			
	range			

A1-02	Encoder Installation angle		Factory default value	0°
	Setup	<u>م ۵۰</u>	~350 0°	
	range	$0.0 \sim 359.9^{\circ}$		

The unit is 0.1 °, it is automatically set after the motor parameter tuning.

A1-03	Select the reverse of feedback speed		Factory default value	0
	Setup	0	Select the for direction	ward direction of speed
	range	1	Select the rev direction	verse direction of speed

A1-04	Rotary transformer number of pole-pairs		Factory default value	1
	Setup range	1~50		

Group A2 CAN Communication Group

Baud rate selection		Factory default value	4	
		0	20k	
A2 00	Setup range	1	50k	
A2-00		2	125k	
		3	250k	
		4	500k	
		5	1M	

C C A2-01 au S ra	CAN communication address		Factory default value	1
	Setup	1~2	55	
	range	1~23	55	

	CAN		
A2-02	communication continuous	Factory default value	0.0
	time		

	0.0:
Setup	0.1s~5.0s
range	0.0: inenabled
	0.1s∼5.0s

Set up detection CAN break time, if the driver did not receive data within the setup time, then it will alarm 42.

Group A3 Servo oil pump control group

	oil pressure control mode		Factory default value	0
	Setup range	0	Non-oil pressure control mode	
A3-00		1	Driver oil pressure control mode 1	
		2	Driver oil press	ure control mode 2
		3	CAN oil pressure mode(For special use)	
		4	Reserved	

A3-00="0": Non-oil pressure control mode

A3-00="1": Driver oil pressure control mode 1.

CAN setup flow, oil pressure command and A13 analog channel provides oil pressure feedback command, driver conduct oil pressure control.

A3-00="2": Driver oil pressure control mode 2.

A13 analog channel provides oil pressure command, A12 analog channel provides flow command, and A13 analog channel provides oil pressure feedback command, driver conducts oil pressure control.

A3-00="3": CAN oil pressure contol mode (For special use), group A3 control group parameters of the servo oil pump disabled.

A3-00="4": 保留。Reserved.

	Maximum rotation speed		Factory default value	2000rpm
A3-01	A3-01 Setup range The correct	The r corre	naximum frequen sponding to rotation	cy of frequency lower limit on speed \sim 30000rpm

The corresponding system output flow sets motor running maximum speed, the recommendations of the setup value is less than 1.4% of the motor rated speed (F1-05).

System pressure	System pressure	oil	Factory value	default	175.0kg/cm ²
A3-02	Setup	0.0kg	/cm² to ma	ximum oil	pressure(A3-03)
	range				

Set the system maximum oil pressure value.

A3-03 Maximum oil Factory default pressure value Setup range System oil pressure (A3	Maximum pressure	oil	Factory value	default	250.0kg/cm ²
	ure (A3-	02) to 500.0kg/cm ²			

Set the pressure scale of the oil pressure sensor. (Corresponding voltage DC0 \sim 10V output pressure sensor)

A3-04	Oil pressure command risetime		Factory value	default	20ms
	Setup range	0ms∼	~2000ms		

Corresponding filter time of oil pressure command

A3-05	Oil pressure control Kp1		Factory value	default	210.0
	Setup	0.0~8	300.0		
	range	0.0	000.0		

The Oil pressure controls PID proportional gain of the first group. The greater setup value is, the faster responses will be.Responding too fast that can easily lead to overshoot and cause system instability and running oscillation. The smaller setting value is, the slower response will be, responding too slow can easily lead to inefficient and product instability.

40.00	Oil pres		Factory value	default	0.100s
A3-06	Setup	0.001	s \sim 10 000s		
	range	0.001s~10.000s			

The oil pressure controls PID integration time of the first group. The smaller setup value is, the faster response will be.Responding too fast that can easily lead to overshoot, cause system instability and running oscillation. The greater setup value is, the slower response will be, responding too slow can easily lead to inefficient and product instability.

A3-07	Oil pressure control Td1		Factory value	default	0.000s
	Setup	0 000	s \sim 1 000s		
	range	0.0008/~1.0008			

The oil pressure controls PID derivative time of the first group. The smaller setup value is, the faster response will be. Responding too fast that can easily lead to overshoot, cause system instability and running oscillation. The greater setup value is, the slower response will be, responding too slow that can easily lead to inefficient and product instability.

A3-05、A3-06、A3-07: PID of the first group oil pressure

The switching methods of PID groups refer to the servo pump commissioning steps of chapter seven.

PID of the first group oil pressure corresponding to terminals combination: DI2 (OFF) 、 DI3 (OFF)

42.00	Maximum reverse rotation speed		Factory value	default	20.0%
A3-08	设定范围 Setup range	安定范围 Setup 0.0%~100.0% ange			

It is the maximum reverse rotation when pressure relief, which corresponds to the percentage setup of the manimum rotation speed. It is used to set the maximum reverse rotation speed. The greater setup value is, the faster pressure relief will be.But excessive noise cause pump reversal.The smaller setting value is, the slower pressure relief will be.

Minimum flov		w	Factory value	default	0.5%
A3-09	设定范围				
	Setup	0.0%	~50.0%		
	range				

The system running miximum flow, corresponding to the percentage setup of the manimum rotation speed (A3-01) .

A3-10	Minimum	Factory	default	$0.5 kg/cm^2$
	pressure	value		0.000/011

Setup	$0.0 \text{ kg/cm}^2 \sim 50.0 \text{ kg/cm}^2$
range	

The minimum pressure of the system running.

A3-11	Oil pressure Kp2		Factory value	default	210.0
	Setup	0.0~	800.0		
	range	0.0 0	500.0		

Corresponding oil pressure control Kp1 (A3.05)

A3-12	Oil pressure Ti2		Factory value	default	0.100s
	Setup	0.001s~10.000s			
	range				

Corresponding oil pressure control Ti1 (A3.06)

A2 42	Oil pressure Td2		Factory value	default	0.000s
A3-13	Setup	0.000	s∼1.000s		

Corresponding oil pressure control Td1 (A3.07)

PID of the second group oil pressure

The switching methods of PID groups refer to the servo pump commissioning steps of

chapter seven.

PID of the second group oil pressure corresponding to terminals combination: DI2(ON), DI3 (OFF) .

A2 44	Oil pressure Kp3		Factory value	default	210.0
A3-14	Setup range	0.0~8	800.0		

Corresponding oil pressure control Kp1 (A3.05)

A2 15	Oil pressure Ti3		Factory value	default	0.100s
A3-15 Setup 0.001s~10.000s					
	range	0.001	0 10.0000	,	

Corresponding oil pressure control Ti1 (A3.06)

A3-16	Oil pressure Td3		Factory value	default	0.000s
	Setup	0.000	s∼1.000s		
	range				

Corresponding oil pressure control Td1 (A3.07)

A3-14、A3-15、A3-16: PID of the third group oil pressure

The switching methods of PID groups refer to the servo pump commissioning steps of chapter seven.

PID of the third group oil pressure corresponding to terminals combination:

A2 47	Oil pressure Kp4		Factory value	default	210.0
A3-17	Setup	0.0~	800.0		
	iango				

Corresponding oil pressure control Kp1 (A3.05).

42.40	Oil pressure Ti4		Factory value	default	0.100s
A3-18	Setup	0.001s	s~10.000s	3	
	Tange				

Corresponding oil pressure control Ti1 (A3.06)

42.40	Oil pressure Td4		Factory value	default	0.000s
A3-19	Setup range	0.000	s∼1.000s		

Corresponding oil pressure control Td1 (A3.07)

A3-17、A3-18、A3-19: PID of the fourth group oil pressure

The switching methods of PID groups refer to the servo pump commissioning steps of Chapter seven.

PID of the fourth group oil pressure corresponding to terminals combination: DI2 (ON) , DI3 (ON) $_{\circ}$

40.00	AI zero detection	drift	Factory value	default	0
A3-20	Setup range	0:Iner 1: Ena	nabled abled		

Set A3-20 to 1. The driver auto detection the zero drift of Al1 $\$ Al2 and Al3, give the detection various analog zero drift value to F4-18 $\$ F4-23 and F4-28, the function code will restore to zero after detection.

	Fault detecti pressure ser	on time of oil nsor	Factory default value	A3-21
A3-21	Setup range	0.000s: Detec 1s~60.000s	tion disable	d

Set the sensor fault detection time

Group F0 Basic Function Group

F0-00	Model displa	у	Factory default value	Model dependent	
	Set up	0	G model (heavy lo	oad model)	
	range	1	P model (light load model)		

This parameter is provided only for the user to view the factory default model and cannot be modified.

1: It is applicable to the heavy load of the designated rated parameters.

2: It is applicable to the light load of the designated rated parameters.

	Control mode	e		Factory default value	0		
F0-01	Satur	0	Spe	Speed sensorless vector control			
	Banga	1	Spee	Speed sensor vector control (VC)			
	Range	2	V/F control				

0: Speed sensorless vector control refers to open loop vector. It is applicable to the general high-performance control applications where one driver can only drive one motor. Such as servo pump, high-speed paper machine, crane, elevator, etc.

1: Speed sensor vector control refers to close loop vector. It must be added with encoder and PG card and is applicable to the applications where high-precision speed control or torque control is required. One driver can only drive one motor loads, such as paper-making machine, lifting machine and elevator.

2: V/F control

It is applicable to the applications where the load requirements are rather low or one driver drives multiple motors, such as fan and pump loads. It can be used in the applications where one driver drives multiple motors.

Prompt: Motor parameter identification must be conducted when selecting the vector control mode. Only when correct motor parameters are provided can the vector control mode be fully made use of. Better performance can be achieved by adjusting the speed regulator parameters (group F2).

	Command Source Selection			Factory default value	0			
E0.02		0	Op	Operation panel command				
FU-U2	Setup Range	1	Terminal command channel					
		0	Serial port communication					
		2	con	ommand channel				

Select the channel for driver control command.

The driver control command includes start, stop, forward rotation, reverse rotation and Jog.

0: Operation panel command channel ("LOCAL/REMOT" LED OFF);

Perform running command control with keys on the operation panel, such as RUN, STOP/RES keys.

1: terminal command channel ("LOCAL/REMOT" LED ON)

Perform running command control by the multifunctional input terminals such as FWD, REV, JOGF, JOGR, etc.

2: serial port command channel ("LOCAL/REMOT" LED flashes)

The running command is sent by the host computer via the communication mode.

F0-03	Main frequen selection	icy soi	urce X	Factory default value	0
	Setup	0	Digital se	etup UP and DOW	/N
	Range	-	(non-rec	orded)	
		1	Digital setup UP and DOWN		
		•	(non-recorded)		
		2	2 Al1		
		3	AI2		
		4	AI3		
		5	PULSE setup (DI5) MS speed PLC		
		6			
		7			

	8	PID
	9	communication setup

Select the input channel for main reference frequency of the driver. There are nine types of main reference frequency channels:

0: Digital setup (non-recorded)

The initial value is the value of F0-08 "Digital Setup Preset Frequency".

It can change the setup frequency value of the driver through the keys " \blacktriangle " and " \blacktriangledown " of the keyboard (or UP and DOWN of multifunctional input terminals).

Non-recorded means that the setup frequency value is recovered to the value of F0-08 "Digital Setup Preset Frequency" in case of driver power failure.

1: Digital setup (recorded)

The initial value is the value of F0-08 "Digital Setup Preset Frequency".

It can change the setup frequency value of the driver through the keys " \blacktriangle " and " \blacktriangledown " of the keyboard (or UP and DOWN of multifunctional input terminals).

"Recorded" means that the setup frequency upon restart of driver due to power failure remains the same.

2: Al1 3: Al2 4: Al3

It means that the frequency is determined by the analog input terminal. Standard unit provides two analog input terminals, and optional I/O expansion card can provide one analog input terminal (AI3). Al1 and AI3 refer to voltage input of 0 to 10V. Al2 can be used as either voltage input of 0V to10V or current input of 4mA to 20mA, which can be selected by the J3 jumper on the control board.

5: Pulse setup (DI5)

The frequency setup is set up by the terminal pulse.

Pulse setup signal specification: voltage range of 9V to 30V and frequency range of 0 kHz to 50 kHz.

Note: Pulse setup can only be input from the multifunctional input terminal DI5.

6. MS speed

Select MS speed running mode. It needs to set Group F4 "Input Terminal" and Group FC "MS Speed and PLC" parameters to determine the relative relationship between the setup signal and the reference frequency.

7. Simple PLC

Select simple PLC mode. When the frequency source is simple PLC, it needs to set Group FC "MS Speed and PLC" parameters to determine the setup frequency.

8. PID

Select process PID control. In this case, it needs to set Group FA "PID Function". The running frequency of the driver is that after PID functions. For the meanings of PID setup source, setup quantity and feedback source, please refer to Group A "PID Function".

9: Communication setup

It means that the main frequency source is set up by the host computer via the communication mode.

	Auxiliary Frequency			Factory default	0			
F0-04	source Y selection			value	0			
	Setup Range	0	Digital setup UP and DOWN (non-recorded)					
		1	Digi (re	Digital setup UP and DOWN (recorded)				
		2	Al1					
		3	AI2					
		4	AI3					
		5	PULSE setup (DI5)					
		6	MS speed					
		7	PLC					
		8	PID					
		9	Cor	nmunication setup				

When the auxiliary frequency source is used as independent frequency setup channel (i.e. frequency source switching from X to Y"), it is used in the same way as the main frequency source X.

When the auxiliary frequency source is used as overlap setup(i.e. frequency source selection switching from X plus Y or X to X plus Y), it has special points as follows:

1. When the auxiliary frequency source is digital setup, the preset frequency (F0-08) has no action, and it needs to adjust the main reference frequency through the keys " \blacktriangle " and " \blacktriangledown " of the keyboard (or UP and DOWN of multifunctional input terminals).

2. When the auxiliary frequency source is analog input setup(AI1, AI2 and AI3) or pulse input reference, 100% of input setup is relative to the auxiliary frequency source range (refer to F0-05 and F-06). To adjust the main reference frequency, it needs to set the corresponding setup range of analog input to "-n% to n% (refer to F4-13 and F4-26).

3. When the frequency source is pulse input setup, it is similar to the analog

value.

Prompt: There is difference between the auxiliary frequency source Y selection and the main frequency source X setup value. That is to say, the main and auxiliary frequency sources cannot use the same frequency setup channel.

F0-05	Auxiliary Fre source Y rela selection	quenc tive va	y alue	Factory default value	0	
	Setup	0	Relative to maximum frequency			
	Range	1	Relative to frequency source X			
	Auxiliary Frequency			Factory default	0	
F0-06	source Y			value	0	
	Setup Range			0% to 100%		

When the frequency source selection is frequency superimpositon setup (F0-07 is set to 1 or 3), it is used to determine the adjustment range of auxiliary frequency source. F0-05 is used to determine the relative object of that range. If it is relative to maximum frequency X, that range will vary with the main frequency X.

	Frequency se selection	ource		Factory default value	0		
F0-07	0 1 2 Setup Range 3	0	Main frequency source X				
		1	Mair auxi	Main frequency source X plus auxiliary frequency source Y			
		2	Switching between main frequency source X and auxiliary frequency source Y				
		3	Swit sour sour sour	ching between main ce X and (main frequ ce X plus auxiliary frec ce Y)	frequency lency luency		
		4	Swit sour sour sour	ching between main ce Y and (main frequ ce X plus auxiliary frec ce Y)	frequency lency luency		

This parameter is used to select the frequency setup channel. Frequency setup is realized through combination of main frequency source X and auxiliary frequency source Y.

When 1 is selected, the frequency source "main frequency source X plus auxiliary frequency source Y" can realize frequency superimpositon function.

When 2 is selected, it can switch between the main frequency source X and auxiliary frequency source Y via the multifunctional input terminal "Frequency Source Switching".

When 3 is selected, it can switch between the main frequency source X and (main frequency source X plus auxiliary frequency source Y) via the multifunctional input terminal "Frequency Source Switching".

When 4 is selected, it can switch between the auxiliary frequency source Y and (main frequency source X plus auxiliary frequency source Y) via the multifunctional input terminal

"Frequency Source Switching".

In this way, it can realize mutually switching between the frequency setup modes, such as switching between PID running and common running, switching between simple PLC and common running, switching between pulse setup and analog setup, and switching between analog setup and common running.

F0-08	Preset freque	ncy	Factory default value	50.00 Hz
	Setup Range	0.00 to maximum frequency (ena when the frequency source select		cy (enabled e selection

When the main frequency source is selected as "Digital setup" or "Terminals UP/DN", this function code is the initial value of frequency digital setup of the driver.

F0-09	Running direction			Factory default value	0
	Setup	0	con		
	Range	1	reve	erse direction	

Through modifying this function code, it can change the rotary direction of the motor without changing any other parameters. The role of this function code is to adjust any two lines of the motor (U, V and W) and further change the rotary direction of the motor.

Prompt: After parameter initialization, the motor running direction will restore to the original status. This action shall be carefully performed in the applications where the rotary direction of the motor is not allowed to change upon system commissioning.
F0 42	Frequency upper limit Setup Range frequence			Factory default value	50.00Hz	
FU-12				uency lower limit F0-11 to maximum ency F0-10		
	Frequency upper limit offset		Fa	actory default value	0.00Hz	
	Setup Range	0	F	0-12 setup		
50.40		1	Al	Al1		
F0-13		2	Al	AI2		
		3	Al	AI3		
		4	Pl	PULSE setup		
		5	С	Communication setup		

F0-10	Maximum frequency c Setup Range 50.001		Factory default value	50.00 Hz
			Hz to 300.00Hz	Z
E0 11	Frequency source		Factory	0
F0-11	upper limit		default value	e

It is used to define the source of frequency upper limit. The frequency upper limit can be sourced from either digital setup (F0-12) or analog input channel. When the analog input is used to set the frequency upper limit, 100% of analog input setup is relative to F0-12.

For example, in case of torque control, the speed control is inenabled. To avoid occurrence of broken materials, it can use the analog value to set the frequency upper limit. When the driver runs at the frequency upper limit, the torque control is inenabled, and the driver continues running with frequency upper limit.

When the frequency upper limit is analog value reference, this parameter is used as analog value offset.

Its benchmark value is F0-12. The addition of offset frequency and analog setup value of frequency upper limit is used as the final setup value of frequency upper limit.

F0-14	0-14 Frequency lower limit Setup range 0.		Factory default value	0. 00Hz
			0.00Hz to frequency upper limit F0-12	

The driver starts from the start frequency. If the setup frequency is lower than frequency lower limit during the running process, the driver will keep running under frequency lower limit until it stops or the setup frequency is higher than the frequency lower limit.

F0-15	Carrier frequency	de	Factory efault value	Model dependent
	Setup range		0.5kHz~16.	0kHz

This function is used to adjust the carrier frequency of the driver. By adjusting the carrier frequency, the motor noise can be reduced, and the resonance of the mechanical system can be avoided, so that the leakage current to the earth and the interference of the driver can be reduced.

When the carrier frequency is low, the output current higher harmonic component will increase, the motor loss will increase, and the motor temperature rise will also increase.

When the carrier frequency is high, the motor loss is reduced, and the motor temperature is decreased, but the driver loss and temperature rise will increase and so will the interference.

The adjustment of carrier frequency will have influences on the following performances:

Carrier frequency	Low to high
Motor noise	high to low
Output current waveform	poor to good
Motor temperature rise	high to low
Driver temperature rise	Low to high
Leakage current	low to high
External radiation interference	low to high

F0-16	Carrier frequency adjustment selection			Factory default value	0	
	Setup range	0 Fixed P tempera		WM and carrier frequency ature adjustment inenabled.		

	1	Random PWM and carrier frequency
		Eixed DW/M and carrier frequency
	2	temperature adjustment enabled
		temperature aujustment enabled.
		Random PWM, and carrier
	3	frequency temperature adjustment
		enabled.

Two PWM carrier frequency adjustment modes, fixed and random, are provided. The random PWM motor noise has wide frequency range, while the fixed PWM motor noise has fixed frequency.

When the carrier wave temperature adjustment is enabled, the driver can automatically adjust the carrier frequency according to its temperature. This function can reduce the possibility of over heat alarm of the driver.

F0-17	Speed-up time 1	Factory default value	20.0s
Se	Setup range	$0.0s{\sim}6500.0s$	
F0-18	Speed-down time 1		20.0s
10-10	Setup range	0.0s~6500.0s	

Speed-up time 1 refers to the time "t1" required for the driver to accelerate from 0Hz to the maximum output frequency (F0-10).

Speed-down time 1 refers to the time "t2" required for the driver to decelerate from the maximum output frequency (F0-10) to 0Hz,

as shown in the following figure:



Fig.6-1 Schematic diagram for speed-up/speed-down time Plesase pay attention to the difference between the actual

speed-up/speed-down time and the setup speed-up/speed-down time. There are totally four groups o speed-up/speed-down time for selection.

Group 1: F0-17 and F0-18;

Group 2: F8-03 and F8-04;

Group 3: F8-05 and F8-06;

Group 4: F8-07 and F8-08;

It can select speed-up/speed-down time via the multifunctional digital input terminals (F4-00 to F4-08).

Group F1 Motor Parameters

	Motor type selection		Factory default value	2	
F1-00	Satur	0	Common asynch	nronous motor	
	selup	1	Variable frequen	icy asynchronous motor	
	Tange	2	Permanent mag	netic synchronous motor	
E1_01	Rated power		Factory default value	Model dependent	
F1-01	Setup range	0.4kW	/~1000.0kW		
E1_02	Rated volta	ige	Factory default value	Model dependent	
F1-02	Setup range	0V~4	140V		
E1 02	Rated curre	ent	Factory default value	Model dependent	
F1-03	Setup range	0.00A	~655.35A		
	Rated		Factory default	Model dependent	
E1_04	Frequentcy	/	value		
11-04	Setup	0.00H	z~ maximum frequency		
	range			1	
	Rated rotat	ion	Factory default	Model dependent	
F1-05	speed		value		
	Setup	0rpm ⁻	~30000rpm		
	range				

<u>∕</u>Note

1. Please set the parameters according to the nameplate parameters of the motor.

2. It needs accurate motor parameters to ensure the excellent control performance of the vector control. Accurate parameter identification comes from the correct setting of the rated motor parameters.

3. To ensure the control performance, please carry out motor configurations in accordance with the standard adaptable motor of the driver. If there is huge difference between the motor power and the power of standard adaptable motor, the control performance of the driver will decrease obviously.

F1-06~	Resvered		Factory default value	_
F1-09	Setup	—		
	range			

F4 44	D-axis inductance		Factory default value	Model dependent
F1-11	Setup range	0~65535		
F4 40	Q-axis inductance	9	Factory default value	Model dependent
F1-12	Setup range	0~65535		
E4 42	Stator resistance		Factory default value	Model dependent
F1-13	Setup range	0~6	5535	
E1 14	unit		Factory default value	Model dependent
F 1-14	Setup range	00~12		
E1 15	Back EMF		Factory default value	Model dependent
F1-13	Setup range	0~6	5535V	

When the automatic tuning of the motor is normally completed, the setup values of F1-10-F1-15 will be automatically set up. unit (F1-14)

- a) Units digit determines inductors unit
 - 0: the unit is µH;
 - 1: the unit is10µH
 - 2: the unit is 100µH
- b) Tens digit determine resistance (F1-13) unit:
 - 0: the unit is µH
 - 1: the unit is10µH
 - 2: the unit is $10m\Omega$

Back EMF (F1-15) :

It is used to set the motor back EMF of rated frequency.

Each time when the rated power of the motor F1-01 is changed, the motor will automatically recover the parameter values of F1-10 to F1-15 of the default standard motor parameters. If it is impossible to conduct the motor tuning on the site, the user can manually input the parameters refer to the known parameters of the same type motors.

	Tuning sele	ection	Factory default value	0		
E4 46		0	no operation			
F1-10	F1-16 Setup	1	static tuning (low speed)			
	range	2	dynamic tuning (high speed)		
	3		Tuning mode 3			

Prompt: Correct motor rated parameter (F1-01 to F1-05) must be set before tuning.

0: No operation, it is tuning inenabled.

1: Static tuning.

It is applicable to the motor back-EMF known occasion, please set the parameter F1-15 according to the motor back-EMF.

Action description: Set the function code to 1 and press RUN key for confirmation, and then the driver will conduct static tuning.

2: Dynamic tuning

To ensure the dynamic control performance of the driver, please select rotary tuning. During the rotary tuning, the motor must be disconnected with the loads (i.e. no-load).

Upon selection of rotary tuning, the driver will conduct static tuning at first. Upon completion of static tuning, the motor will accelerate to 40% of the rated

motor frequency and maintain for certain period of time. Then the motor will decelerate to zero speed, and by this time the rotary tuning is completed.

Action description: Set the F1-16 to 2 and press RUN key for confirmation, and then the driver will conduct rotary tuning.

Tuning operation description:

When F1-11 is set to 1 or 2, press ENTER key and "TUNE" will be displayed and flashes. Press RUN key to conduct parameter tuning, and at this time the displayed "TUNE" stops flashing. After the tuning is completed, the display will return to the stop status interface. The tuning process can be stopped by pressing the STOP key.

When the tuning is completed, the value of F1-11 will automatically restore to 0.

Note: Tuning is enabled only in the keyboard control mode. (Set F0-02 to zero)

Group F2 Vector Control Parameters

Group F2 function code is enabled only for the vector control. That is to say, when F0-01=0 or 1, it is enabled, and when F0-01=2, it is inenabled.

F2-00	Speed loop proportional gain 1	Factory default value	30
	Setup range	0~100	
F2-01	Speed loop integration time 1	Factory default value	0.50s
12-01	Setup range	0.01s ~ 10.00.s	
E2-02	Switching frequency 1	Factory default value	5.00 Hz
12 02	Setup range	0.00~ F2-05	
F2-03	Speed loop proportional gain 2	Factory default value	15
	Setup range	0~100	
F2-04	Speed loop integration time 2	Factory default value	1.00s
12.04	Setup range	0.01s ~ 10.00s	

F2-05	Switching frequency 2	Factory default value	10.00Hz
	Setup range	F2-02 ~ maximum	frequency

F2-00 and F2-01 are PI adjustment parameters when the running frequency is lower than switching frequency 1 (F2-02) F2-00 and F3-01 are PI adjustment parameters when the running frequency is higher than switching frequency 2. PI parameter of frequency channel between the switching frequency 1 and switching frequency 2 is linear switching between two groups of PI parameters, as shown in the figure below:



Fig.6-2 Schematic diagram of PI parameter

The speed dynamic response characteristics of the vector control can be adjusted by setting the proportional coefficient and integration time of the speed regulator. Increasing the proportional gain or reducing the integration time can accelerate the dynamic response of the speed loop. However, if the proportional gain is too large or the integration time is too short, it will cause the oscillation of the system.

Recommended adjustment method:

If the factory default parameters cannot meet the requirements, the relevant parameter values can be subject to fine tuning.

Increase the proportional gain while ensuring no oscillation to the system, and then reduce the integration time to ensure that the system has quick response characteristics and small overshoot.

Note: Improper PI parameter setting may cause too large speed overshoot. Voltage fault may occur when the overshoot drops.

F2-06 Slip compensation coefficient Setup range Setup range	Factory default value	100%
	Setup range	50%~200%

For the speed sensorless vector control, this parameter is used to adjust the speed stabilizing precision of the motor. When the speed is too low due to heavy load of motor, this parameter needs to be enlarged or this parameters needs to be reduced.

For the speed sensor vector control, this parameter can adjust the output current of the driver carrying the same load.

F2-07	Time constant of speed loop filter	Factory default value	0.000s
	Setup range	0.000s~0.100	S

In the vector control mode, the output of speed loop regulator is torque current command. This parameter is used to filter the torque command. This parameter needs no adjustment generally and this filter time can be increased in case of huge speed fluctuation. In case of oscillation of motor, this parameter shall be reduced properly.

The time constant of speed loop filter is low, and the output torque of the driver may vary greatly, but the response is quick.

	Torque control			Factory default value	0
F2-08	Setup	0 Inenabled			
	range	1 Enabled			

0: Torque control is inenabled, and the driver performs command speed control. In case of speed control, the driver output frequency in accordance with the setup frequency command, and the output torque automatically matches the load torque, but the output torque is limited by the torque upper limit (refer to F2-09 and F2-10). When the load torque is higher than the setup torque upper limit, the output torque of the driver is limited, and the output frequency will be different from the setup frequency.

1: Torque control is enabled, and the driver performs torque control. In case of torque control, the driver outputs torque in accordance with the setup torque command, and the output frequency automatically matches the load speed, but the output frequency is limited by the frequency upper limit (refer to F0-12). When the load speed is higher than the setup frequency upper limit, the output frequency of the driver is limited, and the output torque will be

different from the setup torque.

In case of torque control, the torque command is the torque upper limit, and set by the torque upper limit source (F2-09).

It can perform switching between torque control and speed control via the multifunctional input terminals.

In case of torque control, the output frequency of the driver automatically tracks the change of the load speed, but the change of the output frequency is affected by the setup acceleration/deceleration time. If it needs to quicken the tracking speed, the acceleration/deceleration time shall be shortened.

When the setup torque of the driver is higher than the load torque, the output frequency of the driver will rise; when the output frequency of the driver reaches the frequency upper limit, the driver will keep running with the frequency upper limit.

When the setup torque of the driver is lower than the load torque, the output frequency of the driver will fall; when the output frequency of the driver reaches the frequency lower limit, the driver will keep running with the frequency lower limit.

	Torque upp source	er limi	it	Factory default value	0
	0	F2-10	F2-10		
E2-00	F2-09 Setup range	1	Al1		
12-05		2	AI2		
		3	Al3		
		4	PULSE setup		
		5	Comr	nunication setup	

F2-10	Torque upper limit		Factory default value	150%
	Setup range	0	%~ 200%	

In the speed control mode, F2-09 is used to select the setup source of torque upper limit. When setting via the analog value, 100% of the analog input setup corresponds to F2-10, and the setup 100% corresponds to the rated torque of the motor matching the driver.

In the torque control mode, torque upper limit source is the torque setup source. Torque upper limit is the torque setup command.

F2-11	Encoder pulse number	Factory default value	1024
-------	-------------------------	--------------------------	------

Setup range	0 ~ 65535

Note: When the driver controls the speed sensor vector control, it must set the pulse number of the encoder correctly, or the motor will run abnormally. If normal operation cannot be realized after correct pulse number of the encoder is set, exchange the connection positions of Phase A and Phase B of the encoder.

E2 12	Reserved		Factory default value	_
FZ-1Z	Setup	-		
	range			

E2 42	D axis curr loop	ent	Factory default value	50
F2-13	Setup range	0~65535		
E2 14	D-axis curr Ioop Ki	ent	Factory default value	50
F2-14	Setup range	0~65	5535	
E2-15	D -axis current loop Kp		Factory default value	50
F2-13	Setup range	0~65	5535	
E2-16	D-axis curr Ioop Ki	ent	Factory default value	50
12-10	Setup range	0~65	5535	

When the automatic tuning of the motor is normally completed, the setup values of F2-13 to F2-16 will be automatically set up.

Each time when the rated power of the motor F1-01 is changed, the driver will automatically recover the parameter values of F2-13 \sim F2-16 to the default standard motor parameters.

If it is impossible to tune the motor on the site, the user can manually input the parameters by referring to the known parameters of the motors of the same type.

E2-17	SoftPwm	Factory default	0
F 2- 17	selection	value	0

Setup	0	Inenabled
range	1	Enabled

Group F3 V/F Control Parameters

This group of function code is enabled only for the V/F control (F0-01=2) and is inenabled for the vector control.

V/F control is applicable to the general loads such as fan and pump or the applications where one driver drives multiple motors or the driver power is one level lower or higher than the motor power.

F3-00	V/F curve se	etup	Factory default value	0
	Setup range	0	Straight V/F curve	
		1	Multiple-point V/F curve	
		2	Square V/F curve	

The fan and pump loads may select square V/F control.

0: Straight V/F curve. It is suitable for common constant torque load.

1: Multiple-point V/F curve. It is suitable for the special loads such as dehydrator and centrifugal machine.

2: Square V/F curve. It is suitable for the centrifugal loads such as fan and pump.

F3-01	Torque boost	Factory default value			1.0%	
	Setup range		0.0% ~ 30%	0		
	Cutoff frequency	Fac	tory default			
E2 02	of torque boost		value		50.00HZ	
F3-02	Sotup rango	0.00Hz~ maximum output		utput		
	Setup range	frequency				

To compensate the low frequency torque characteristics of V/F control, it can boost the output voltage of the driver at the time of low frequency.

If the torque boost is set to be too large, the motor may be over heat, and the driver may be over current. In general, the torque boost shall not exceed 8.0%.

Adjusting this parameter effectively can avoid over current upon startup. For the relatively large loads, it is recommended to increase this parameter. For the small loads, this parameter value may be reduced.

When the torque boost is set to 0.0, the driver will adopt auto torque boost.

Cutoff frequency of torque boost: Under this frequency, the torque boost is enabled. If it exceeds this setup frequency, the torque boost is inenabled. Refer to Fig.6-3 for details.



Fig.6-3 Schematic Diagram for Manual Torque

F3-03	V/F frequency F1	Factory default value 0.00Hz
	Setup range	0.00Hz ~ rated motor frequency
F3-04	V/F voltage V1	Factory default 0.0%
	Setup range	0.0%~ 100.0%
	V/F frequency F2	Factory default 0.00Hz
F3-05		value
	Setup range	V1 ~ rated motor frequency
F3-06	V/F voltage V2	Factory default value 0.0%
	Setup range	F1 ~ 100.0%
F3-07	V/F frequency F3	Factory default value 0.00Hz
	Setup range	V2 ~ rated motor frequency
F0.00	V/F voltage V3	Factory default 0.0%
F3-08		
	Setup range	F2 ~ 100.0%

Six parameters of F3-03 to F3-08 define MS V/F curve.

The setup value of V/F curve is generally set in accordance with the load characteristics of the motor.

Note: V1<V2<V3 and F1<F2<F3. In case of low frequency, higher setup

voltage may cause over heat and even burning of the motor and stall over current or current protection of the driver.



Fig.6-4 Schematic Diagram for V/F Curve Setup

F3-09	Slip compensation coefficient	Factory default value	0.0%
	Setup range	0% ~ 200.0%	

It is enabled only for V/F control. Setting this parameter can compensate the slip in the V/F control mode due to load and reduce the change of rotation speed of the motor following the load change. In general, 100% corresponds to the rated slip of the motor with rated load. Slip coefficient adjustment can refer to the following principles: When the load is rated load and the slip compensation coefficient is set to 100%, the rotation speed of the motor in the driver is close to the reference speed.

	AVR(Automatic Voltage Regulation)			Factory default value	2
F2 40	Setup range	0	Inenabled		
F3-10		1	Enabl	ed	
		0	Inena	bled only at the tim	ne of
		2	deceleration		

In the V/F control mode, when it needs fast stop and there is no brake resistor, selecting "Inenabled only at the time of deceleration" can greatly reduce the

possibility of over voltage fault alarm. When there is brake resistor or it has not need for fast deceleration, select "Enabled".

	Oscillation suppress	ion	Factory	Model
F3-11	gain		default value	dependent
	Setup range	0~	·100	

Select "0" for this gain when the motor has no oscillation. Only when the motor has obvious oscillation and cannot run normally can this gain be properly increased. The bigger the gain is, the better oscillation suppression result will be. The method of selecting this gain is to select the smallest one on the premise that there is effective oscillation suppression measure, so as to ease the negative effect on the VF operation.

Group F4 Input Terminal

The standard unit of IS300 series driver has five multifunctional digital input terminals (DI5 of which can be used as high-speed pulse input terminal) and two analog input terminals. If the system needs more input/output terminals, optional multifunctional input/output expansion card can be used. The multifunctional input/output expansion card has 5 multifunctional digital input terminals (DI6 to DI10) and 1 analog input terminal (Al4).

F4-00	DI1 terminal function selection	Factory default value	1
F4-01	DI2 terminal function selection	Factory default value	0
F4-02	DI3 terminal function selection	Factory default value	0
F4-03	DI4 terminal function selection	Factory default value	9
F4-04	D15 terminal function selection	Factory default value	0

This parameter is used to set the functions of the multifunctional digital input terminals. If the setup is oil pressure control mode (A3-00 setting values is non-zero), the DI2 default is "48: PID select terminals 1", the DI3 default is "49: PID select Terminal 2", DI5 the default is "50: CAN communication enabled".

Setup value	Function	Description
0	No function	Even when there is signal input, the driver still has no action. The no operation function can be set on the unused terminals so as to prevent error action.
1	Forward rotation (FWD)	Control the forward rotation and reverse rotation of the
2	Reverse rotation (REV)	unver via the external terminals.
3	Three-line mode running control	This terminal is used to confirm that the driver running mode is three-line control modeFor detailed description, please refer to F4-11 three-line control mode function code.
4	Forward rotation Jog (FJOG)	FJOG refers to Jog forward rotation, while RJOG refers to Jog reverse rotation. For details regarding frequency and Jog acceleration/deceleration time during the Jog running,
5	Reverse rotation Jog (RJOG)	refer to F8-00, F8-01 and F8-02 function codes.
6	Terminal UP	When the frequency is given by the external terminals, it is
7	Terminal DOWN	used as increment and decrement commands of frequency modification When the frequency source is set to digital setup, it can be used to adjust the setup frequency.
8	Coast to stop	The driver locks the output, and the motor stop process is beyond the driver control. It is the general method adopted when there is huge load and no requirement for the stop time. This mode is the same as the meaning of coast to stop as described in F6-10.
9	Fault reset (RESET)	External fault reset function. It is the same as the function of RESET key on the keyboard. Using this function can realize long-distance fault reset.
10	Running	The driver decelerates to stop, but all the running

Setup value	Function	Description
	pause	parameters are all in the recorded status, such as PLC parameter, swing frequency parameter and PID parameter. After this signal disappears, the driver restores to the status before stopping.
11	External fault normally open input	After the external fault signal is sent to the driver, the driver reports fault and stops.
12	MS speed terminal 1	It can realize 16S speed through the combination of digital
13	MS terminal 2	the MS sneed function description
14	MS peed terminal 3	
15	MS terminal 4	
16	Speed-up/spe ed-down time selection terminal 1	It can select four types of Speed-up/speed-down time through the combination of digital status of these two
17	ed-down time selection terminal 2	terminais.
18	Frequency source switching	 When the frequency source selection (F0-07) is set to 2, it performs switching between main frequency source X and auxiliary frequency source Y via this terminal. When the frequency source selection (F0-07) is set to 3, it performs switching between main frequency source X and (main frequency X plus auxiliary frequency source Y) via this terminal. When the frequency source selection (F0-07) is set to 4, it performs switching between auxiliary frequency source X and (main frequency X plus auxiliary frequency source X and (main frequency source X plus auxiliary frequency source X and (main frequency X plus auxiliary frequency source X and (main frequency X plus auxiliary frequency source Y) via this terminal.
19	UP and DOWN setup clear (terminal and keyboard)	When the frequency reference is digital frequency reference, this terminal can be used to clear the frequency value modified by UP/DOWN and thus restore the reference frequency to the setup value of F0-08.
20	Running	When the command source (F0-02) is set to 1, it performs

Setup value	Function	Description
	command	switching between terminal control and keyboard control
	switching	via this terminal.
	terminal	When the command source (F0-02) is set to 2, it performs switching between communication control and keyboard
		control via this terminal.
	Speed-up/spe	Protect the driver from affecting by the external signals
21	ed-down	(except stop command), and maintain the current
	inenabled	frequency.
22	Reserved	-
23	Reserved	-
24	Reserved	-
25	Reserved	-
26	Reserved	-
27	Reserved	-
28	Reserved	-
	Torque	
29	control	The torque control of driver is inenabled.
	inenabled	
30	Reserved	-
31	Reserved	-
22	DC brake	This terminal is enabled, and the driver directly switches to
32	command	the DC brake status.
33	External fault normally closed input	After the external fault signal is sent to the driver, the driver reports fault and stops.

Attached Table 1 MS Speed Function Description

K ₄	K ₃	K ₂	K 1	Frequency Setup	Correspondi ng Parameter
OFF	OFF	OFF	OFF	MS speed 0	FC-0
OFF	OFF	OFF	ON	MS speed 1	FC-01
OFF	OFF	ON	OFF	MS speed 2	FC-02
OFF	OFF	ON	ON	MS speed 3	FC-03
OFF	ON	OFF	OFF	MS speed 4	FC-04
OFF	ON	OFF	ON	MS speed 5	FC-05
OFF	ON	ON	OFF	MS speed 6	FC-06
OFF	ON	ON	ON	MS speed 7	FC-07

ON	OFF	OFF	OFF	MS speed 8	FC-08
ON	OFF	OFF	ON	MS speed 9	FC-09
ON	OFF	ON	OFF	MS speed 10	FC-10
ON	OFF	ON	ON	MS speed 11	FC-11
ON	ON	OFF	OFF	MS speed 12	FC-12
ON	ON	OFF	ON	MS speed 13	FC-13
ON	ON	ON	OFF	MS speed 14	FC-14
ON	ON	ON	ON	MS speed 15	FC-15

NOTE: FC00 ~ FC15 the parameter corresponding unit is "Hz",

the negative number indicates reversal.

Attached Table 2 MS Speed Function Description

Terminal 2	Terminal 1	Speed-up/speed -down time selection	Corresponding Parameter
OFF	OFF	Speed-up time 1	F0-17 and F0-18
OFF	ON	Speed-up time 2	F8-03, F8-04
ON	OFF	Speed-up time 3	F8-05 and F8-06
ON	ON	Speed-up time 4	F8-07 and F8-08

F4-05~	Reserved		Factory default value	_
F4-14	Setup	—		
	range			

E4 15	DI filter time	•	Factory default value	4
F4-13	Setup	0~10)	
	range			

It is used to set the sensitivity of DI terminal. If the digital input terminal is vulnerable to interferences and may cause error action, it can increase this parameter value to enhance the anti-interference capability. However, this operation will reduce the sensitivity of DI terminal.

E4-16	Terminal		Factory default	0
F4-10	command mode		value	
	Setup	0	Two-line mode 1	
	range	1	Two-line mode 2	
		2	Three-line mode	1

3 Three-line mode 2

This parameter defines four different modes of controlling the operation of the driver via the external terminals.

0: Two-line running mode 1: This mode is the most commonly used two-line mode. The forward/reverse rotation of the motor is decided by the commands of FWD and REV terminals.



Fig.6-5 Two-line Running

1: Two-line running mode 2: When this mode is adopted, REV is enabled terminal. The direction is determined by the status of FWD.

K1	K2	Running Command
0	0	Stop
0	1	Stop
1	0	Forward Rotation
1	1	Reverse Rotation



Fig.6-6Three-line running

2: Three-line running mode 1: In this mode, Dln is enabled terminal, and the direction is controlled by FWD and REV respectively. However, the pulse is enabled through disconnecting the signal of Dln terminal when the driver stops.



Fig.6-7-1Three-line running

Where,

SB1: Stop button SB2: Forward rotation button

SB3:Reverse rotation button

DIn is multifunctional input terminals of DI1 to DI5 (DI1 to DI10 if multifunctional input and output expansion card is selected). In this way, it shall define the corresponding terminal functions as No.3 function "Three-line Mode Running Control".

3: Three-line running mode 2: In this mode, DIn is enabled terminal, and the running command is given by FWD, while the direction is determined by the status of REV.

Stop command is performed through disconnecting the DIn signal.



Fig.6-7 Three-line Running Mode

Where,

SB1: Stop button

SB2: Running button

DIn is multifunctional input terminals of DI1 to DI5 (DI1 to DI10 if multifunctional input and output expansion card is selected). In this way, it shall define the corresponding terminal functions as No.3 function "Three-line Mode running Control".

E4 17	Terminal UP/DOWN S	peed	Factory default value	1.00Hz/s
F4-17	Setup range		0.01Hz/s \sim	100.00Hz/s

Terminals UP/DOWN is used to adjust the change rate when setting the frequency.

E4 19	Al1 mini input	imum	Factory default value	0.02V
F4-10	Setup -11.00 range		0V~11.00V	
F4-19	Al1 mini input correspond setup	imum ing	Factory default value	0.0%
	Setup range	-100.0	00%~100.0%	

E4 20	Al1 maximum input		Factory default value	10.00V
F4-20	Setup	-11.0	0V~11.00V	
	range			
	Al1 maximum			
	input		Factory default	100.0%
F4-21	corresponding		value	100.0%
	setup			
	Setup -100.		00%~100.0%	
	range			
	Al1 input fil	ter	Factory default	0.010c
E4-22	time		value	0.0105
1 4-22	Setup	0.000	s~10.00 <mark>0s</mark>	
	range			

The above function codes define the relationship between the analog input voltage and analog input setup value. When the analog input voltage exceeds the setup maximum input or minimum input range, the excess part will be calculated as maximum input or minimum input.

When the analog input is current input, 1mA current equals to 0.5V voltage.

In difference applications, 100% of analog input corresponds to different nominal values. Refer to all the application parts for details.

Several setting examples are shown in the following figures:



Fig.6-9 Corresponding Relationship between Analog Reference and Setting Value

	AI2 minimum input		Factory default value	0.02V
F4-23	Setup	-11.0	0V~11.00V	L
	range			
F4-24	AI2 mini input correspond setup	ing	Factory default value	0.0%
	Setup range	-100.00%~100.0%		
-	AI2 maximu input	m	Factory default value	10.00V
Г4-20	Setup range	-11.0	0V~11.00V	

	A10 mov			
	innut		Factory default	
	correspond	ina	value	100.0%
F4-26	setup	ing	Value	
	Setup	-100.	00%~100.0%	
	range			
	Al2 input fil	ter	Factory default	0.00s
	time		value	0.000
F4-27	Setup	0.000	s \sim 10.000s	
	range			
	AI3 minimu	m	Factory default	
E4 29	input		value	0.02V
F4-28	Setup -11.00		0V~11.00V	
	range			
AI3 minimum		m		
F4-29	input		Factory default	0.0%
	corresponding		value	
	Sotup 100		000/ 100.00/	
	Setup	-100.	00%~100.0%	
		m	Eactory default	
	input		value	10.00V
F4-30	Setup -11.00		0V~11.00V	
	range			
	AI3 maximu	m		
	input		Factory default	100.0%
F4-31	correspond	ing	value	100.070
	setup			
	Setup	-100.	00%~100.0%	
	range			
	time	ler		0.00s
F4-32	Setun	0.000	<u> value</u> ls∼10.000s	
	range	0.000		

The applications AI2、AI3 of function are similar to those of AI1 function.

F4-33~	Reserved		Factory default value	—
F4-42	Setup	_		
	range			

	Al1 sample		Factory default	
	voltago 1			2.000V
F4-43		0.00		
	Setup	-9.9990~9.9990		
	range		1	
	Al1 correction		Factory default	2 000\/
F4-44	voltage 1		value	2.000 V
1 4 44	Setup	-9.99	9V~9.999V	
	range			
	Al1 sample		Factory default	0.000) (
F 4 4 F	voltage 2		value	8.000V
F4-45	Setup	-9.99	9V~9.999V	•
	range			
	Al1 correcti	on	Factory default	
	voltage 2		value	8.000V
F4-46	Setup	-9.99	9V~9.999V	
	range			
	Al2 sample		Factory default	
	voltage 1		value	2.000V
F4-47	Setup	-9.99	9V~9.999V	
	range			
	Al2 correcti	on	Eactory default	
	voltage 1	•	value	2.000V
F4-48	Setup	_9 99	9\/~9 999\/	
	range	0.000	0.0001	
			Factory default	
F4-49	voltage 2		value	8.000V
	Setup	_0 00		
	rango	-9.99	90 9.9990	
			Eastony defeuilt	
	voltage 2			8.000V
F4-50	Voltage 2	0.00		
	Setup	-9.99	yv∼9.999V	
	range			

E4 E4	Al3 sample voltage 1		Factory default value	2.000V
F4-31	Setup	-9.999V~9.999V		
	range			
AI3 correction		Factory default	2 0001/	
E4 52	voltage 1		value	2.000V
F4-32	Setup	-9.999V~9.999V		
	range			
	AI3 sample		Factory default	<u> 000)</u>
E4 52	voltage 2		value	0.000V
F4-33	Setup	-9.999V~9.999V		
	range			
	AI3 correction	on	Factory default	<u> 000)</u>
54.54	voltage 2		value	0.000V
F4-34	Setup	-9.99	9V~9.99 <mark>9</mark> V	
	range			

Aiming at the degree of linearity of AI1 \sim AI3 command voltage signal to corrected.

F4-55~	Reserved		Factory default value	—
F4-58	Setup	—		
	range			

Group F5 Output Terminal

IS300 series driver standard unit consists of three multifunction relay output terminals, 2 multiple analog output terminals.

E5 00	Reserved		Factory default value	-
F3-00	Setup	_		
	range			

	output
F5-02	1(Servo driver is
F5-02	dri rur

F5-03	Control board relay output	Factory	1(Servo
	selection (T/A3-T/C3)	default	driver is
		value	running)

This parameter is used to set the functions of the multifunctional digital input terminals. If the setup is oil pressure control mode (A3-00 setting values is non-zero), the T/A2-T/C2 default is swashplate switching, the T/A3-T/C3 default is pressure control status output.

Multifunctional output terminal function selection is as follows:

Setup value	Function	Description	
0	No output	The output terminal does not have any function.	
1	Driver is running	It indicates the driver is running, and there is output frequency (can be zero), and ON signal will output at this time.	
2	Fault output	When the driver is faulty, it outputs ON signal.	
3	Frequenc-y level detection FDT arrival	Please refer to F8-19 and F8-20 for details.	
4	Frequenc-y arrival	Please refer to F8-21 for details.	
5	In zero speed operation	When the driver output frequency is less than the start frequency, it outputs ON signal.	
6	Motor overload pre-warning	Judgment will be made according to the pre-warning parameter value before the motor electronic thermal protection is enabled. If it exceeds the pre-warning value, it will output ON signal. Motor overload parameters are set in F9-00 to F9-02.	
7	Driver overload pre-warni-ng	After it is found that the driver is overloaded, pre-warning will be invoked 10 seconds before the occurrence of protection. And ON signal will be output.	
8	Reserved	_	
9	Reserved	-	
10	Reserved	_	
11	Reserved	-	
12	Run time arrival	When the accumulated running time of the driver exceeds the setup time F8-17, it outputs ON signal.	
13	Frequenc-y limiting	When the setup frequency exceeds the frequency upper limit and frequency lower limit, and the output	

Setup value	Function	Description
		frequency of the driver reaches the frequency upper
14	Torque limiting	When the torque limiting function is enabled, the stall protection function is automatically enabled and the output frequency is automatically changed. Meanwhile, it outputs ON signal, indicating that it is outputting torque limit. This output signal can be used to reduce load or display overload status signal on the monitoring device.
15	Ready for running	When the main circuit and control circuit power supply are connected, the driver protection function is inenabled, and the driver is in running status, it output ON signal.
16	AI1>AI2	When the analog input Al1 value is higher than Al2 value, it outputs ON signal.
17	Frequenc-y upper limit arrival	When the running frequency reaches frequency upper limit, it outputs ON signal.
18	Frequenc-y lower limit arrival	When the running frequency reaches frequency lower limit, it outputs ON signal.
19	Under voltage status output	When the driver is in under voltage status, it outputs ON signal.
20	Communication setup	Refer to the communication protocol for relevant descriptions.
21~22	Reserved	_
23	Double displacement Plunger Pump swashplate swicth (NO)	Double displacement Plunger Pump displacement swicth
24	Pressure control status output (NC)	
25	Alarm output from pump(NC)	

F5-04~	Resvered	Factory default value	—
F5-09	Setup range	-	_

F5-10	A01 output selection	Factory default value	9
F5-11	A02output selection	Factory default value	10

The standard output of analog output (zero offset is 0 and gain is 1) is 0mA to 20mA (or 0v TO 10V), and the output range of FMP is between 0Hz and setup value of F5-09.

The corresponding value range that it indicates is shown in the table below

Set up value	Function	Range
0	Running	0 to maximum output frequency
0	frequency	
1	Setup	0 to maximum output frequency
I	frequency	
2	Output current	0 to 200% of the rated current of the motor
3	Output torque	0 to 200% of the rated torque of the motor
4	Output power	0 to 200% rated power
5	Output voltage	0 to 120% of the rated voltage of the driver
6	PULSE input	
	PULSE input	
7	AI1	0V to 10V
8	Al2	0V to 10V/0 to 20mA
9	AI3	0V to 10V
10	Feedback	0 to maximum frequency
10	frequency	
11	Feedback	0 to maximum oil pressure
I I	voltage	
12~16	Reserved	

F5-12~	Reserved		Factory default value	_
F5-13	Setup range			

EE 14	AO1 offset coefficient		Factory default value	0.0%	
FJ-14	Setup range	-100.0	0%~100.0%		
AO1 gain			Factory default value	1.00	
F0-10	Setup range	-10.00	0~10.00		
EE 16	AO2 offset coefficient		Factory default value	0.00%	
F3-10	Setup range	-100.0%~100.0%			
FF 47	AO2 gain	Factory defaul value		1.00	
FJ-17	Setup range	-10.00	D~10.00		

If "b" represents zero offset, k represents gain, Y represents actual output, and X represents standard output, the actual output is: Y=kX+b;

AO1 and AO2 zero offset coefficients 100% corresponds to 10V(20mA).

Standard output refers to 0 to maximum analog output corresponding to the output of 0 to 10V(20mA).

It is generally used to correct the zero drift of the analog output and the output amplitude deviation. It can also be defined as any necessary output curve.

For example, If the analog output is the running frequency, it is expected to output 8V(16mA) when the frequency is 0, and output 3V(6mA) at the maximum frequency, the gain shall be set to "-0.50", and the zero offset shall be set to "80%".

F5-18~	Resreved		Factory default value	_
F5-22	Setup	—		
	Tange			

Group F6 Start/Stop Control

	Startup mod	de	Factory default value	0
F6-00	Setup range	0	Direct start (When the DC brake non-zero value, perform DC braki	
		1	Rotation speed tracking restart	

0: Direct start

If the DC brake time is set to 0, start at the start frequency.

When the DC brake time is non-zero value, perform DC braking prior to start. It is applicable to the applications where reverse rotation is likely to occur when small loads are started.

1: Rotation speed tracking restart

The driver judges the rotation speed and director of the motor firstly and then starts at the frequency of the tracked rotation speed of the motor. The rotating motor will be started smoothly without surge.

It is applicable to the restart upon transient power failure of large loads.

To ensure the performance of rotation speed tracking restart, it needs to set the motor parameters accurately. (Group F1)

	Rotation speed tracking mode			Factory default value	0	
E6 01	Setup range	0	Begin	Beginning from stop frequency		
F0-01		1	Begin	Beginning from zero speed		
		0	Beginning from maximum			
	2		frequency			

To complete the rotation speed tracking process within the shortest time, select the mode of driver tracking motor rotation speed:

0: To track from the frequency upon power failure, it generally selects this mode.

1: This mode is used to track from zero frequency and restart upon long period of time of power failure.

2: This mode is used o track from the maximum frequency and applicable to the general power generating loads.

F6-02	Rotation speed tracking fastness and slowness	Factory default value	20
	Setup range	1~ 100	

When it is in the mode of rotation speed tracking restart, select the fastness and slowness of the rotation speed tracking. The higher this parameter value is, the faster the tracking speed is. But too high value may result in unreliable tracking.

F6-03	Startup frequency		Factory default value	0.00Hz
	Setup range		0.00Hz~ 10.00Hz	
	Startup frequency		Factory	0.0s
E6-04	retention time		default value	0.03
F0-04	Setup	0.05~ 36.05		
	range	0.03 0.05		

To ensure the torque at the start of driver, it needs to set a proper start frequency. In addition, to set up flux at the time of motor start, it needs to start speed-up after the start frequency is kept for a certain period of time. The start frequency value F6-03 is not limited by the frequency lower limit.

When the frequency setup value (frequency source) is lower than the start frequency, the driver cannot be started and is in the standby status. When the forward rotation and reverse rotation is being switched each other, the start frequency retention time is inenabled. The retention time is not included in the speed-up time but in the running time of simple PLC.

Example 1:

F0-03=0 Frequency source is digital setup

F0-08=2.00Hz Digital setup frequency is 2.00Hz.

F6-03=5.00Hz Start frequency is 5.00Hz.

F6-04=2.0s Start frequency retention time is 2.0s.

At this time, the driver is in the standby status, and the output frequency of the driver is 0Hz.

Example 2:

F0-03=0 Frequency source is digital setup.

F0-08=10.00Hz Digital setup frequency is 10.00Hz.

F6-03=5.00Hz Start frequency is 5.00Hz.

F6-04=2.0s Start frequency retention time is 2.0s.

At this time, the driver accelerates to 5Hz and further to setup freuqency of 10Hz in 2s.

F6-05	DC brake current at F start		actory default value	0%
	Setup range		0% ~ 100%	
	DC brake time at		actory default	0.0s
F6-06	start		value	
	Setup range		0.0s~ 36.0s	

DC brake at start s generally used when the motor is restarted after it stops completely.

If the start mode is direct start, the driver firstly performs DC brake in accordance with the DC brake current at start, and then start running after the setup DC brake time at start. If the DC brake time is set to 0, the driver directly starts without passing through the DC brake.

The higher the DC brake current is, the higher the brake force is.

DC brake current at start refers to the percentage of rated current of the driver.

_	Speed-up/s mode	peed-c	lown/	Factory default value	0
F6-07	Setup	0	Straight speed-up/speed-down		
	range	1	S-curve sp	beed-up/speed-dow	/n

It is used to select the frequency change mode during the driver start and stop process.

0: Straight speed-up/speed-down

The output frequency increases or decreases along the straight line. The speed-up/speed-down time varies with the setup speed-up/speed-down time. IS300 series driver provides four types of speed-up/speed-down time. It can select speed-up/speed-down time via the multifunctional digital input terminals (F4-00 to F4-08).

1: S-curve speed-up/speed-down

The output frequency increases or decreases along the S curve. S curve is generally used in the applications where start and stop processes are relatively flat, such as elevator and conveyor belt. Refer to F6-08 and F6-09 for the meanings of the parameters.

Start segment proportionF6-08of S curve		Factory default value	30.0%
	Setup range	0.0% ~ 40.0%	

F6-09 End se Setup	End segment proportion of S curve	Factory default value	30.0%
	Setup range	0.0%~ 40.0%	

t1 in the following figure is the parameter set in F6-08, within which the output frequency change slope increases gradually. t2 is the time defined in F6-03, with which the slope of the output frequency change gradually decreases to 0. Within the time between t1 and t2, the slope of the output frequency change remains fixed.



Fig.6-9 Schematic Diagram for S curve Speed-up/Speed-down

50.40	Stop mode		Factory default value	0
F0-10		0	Deceleration to stop	
	Setup range 1		Coast to stop	

0: Speed-down to stop

After the stop command is enabled, the driver reduces the output frequency in accordance with the deceleration mode and the defined acceleration/deceleration time, and will stop after the frequency reduces to zero.

1: Free stop

After the stop command is enabled, the driver will terminate the output immediately. The load will coast to stop according to the mechanical inertia.

F6-11	DC brake beginning frequency at stop	Factory default value	0.00Hz	
	Setup range	0.00Hz ~maximum frequency		
F6-12	DC brake waiting	Factory default	0.0c	
	time at stop	value	0.05	
	Setup range	0.0s~ 36.0s		

F6-13	DC brake current at	Factory default	0%
	stop	value	
	Setup range	0%~ 100%	
F6-14	DC brake time at	Factory default	0.80
	stop	value	0.65
	Setup range	0.0s~ 36.0s	

DC brake beginning frequency at stop: During the acceleration to stop, when it reaches this frequency, the DC brake process at stop begins.

DC brake waiting time at stop: Prior to the beginning of DC brake at stop, the driver stops output and starts DC brake upon this delay. It is used to prevent the over current fault caused by DC brake beginning when the speed is relatively high.

DC brake current at stop: It refers to the added DC brake quantity. The higher this value is, the better the DC brake effect is.

DC brake time at stop: It refers to the added time of the DC brake quantity. When this value is zero, it indicates there is no DC brake process, and the driver will stop according to the setup decoration to stop process.

F6-15	Brake using ratio	Factory default value	100%	
	Setup range	0% ~ 100%		

It is enabled for the driver with built-in brake unit. It can be used to adjust the brake effect of the bake unit.

Group F7 Keyboard and Display

F7-00	LCD language selection			Factory default value	0
	Coture roman	0	Chinese		
	Setup range 1		Eng	lish	

It is enabled for the LCD keyboard. It is used to select the character mode of LCD display.

	MF.K Key function selection			Factory default value	0
F7-01		0	MF.K Key function inenabled		
	Setup range	1	Switching between operation panel command channel and remote command channel (terminal command channel or serial port communication command channel)		
		2	Switching between forward rotation and reverse rotation		
		3	Forward rotation Jog command		

MF.K Key refers to multifunctional key. It can set and define the function of MF.K key on the keyboard via this parameter. It can perform switching via this key both in the stop and running process.

0: This key has no function.

1: Switching between keyboard command and remote operation. It refers to switching of command source, switching from the current command source to the keyboard control (local operation). If the current command source is keyboard control, this command is inenabled.

2: Switching between forward rotation and reverse rotation

It can switch the direction of the frequency command via the MF.K key on the keyboard. It is enabled only in the operation panel command channel.

3: Forward rotation Jog

It can realize forward rotation Jog (FJOG) via the MF.K key on the keyboard.

F7-02	STOP/RESET key function			Factory default value	0	
	Setup range	0	Enabled only in the keyboard control mode			
		1	STOP key enabled in the terminal control mode			
		2	STOP reset function enabled in the terminal control mode			
		3 STOP key stop and fault reset function enabled in the terminal control mode			I	
-------	----------	---	--	--	-----------------------	
	QUICK pa	QUICK parameter lockout		Factory default value	0	
F7-03	Ostur	QUIC parai adde	CK parameter I meter items in d, reduced or I	ockout inenabled. the shortcut menu modified at this tim	The can be ne.	
	range	1: QU parai be m parai	JICK paramete meter items in odified at this t meter contents	er lockout inenable the shortcut menu time, but the relate can be modified.	d. The cannot d	



	Meanings of lo	ower eight digits:	
Setup ange: ~ 65535	Meanings of Lo Meanings of Hig	wer Eight Digits	Setting frequency (Hz) Bis woltage (Y) DI input State DO output State All voltage (Y) All vol
	during the stop 1, and change	p, set the correspon- the binary numbers	ding positions to s into decimal
	Setup ange: ~ 65535	Meanings of Lo Meanings of Hi ange: - 65535 If the above p during the sto 1, and change numbers and	Setup ange: - 65535 If the above parameters need to b during the stop, set the correspond 1, and change the binary numbers numbers and set them in F7-05.

	Load speed coefficient	display	Factory default value	1.0000
F7-06	Setup range	0.0001~ 6.5000	The output freque driver and the lo are relative thro parameter. It is the load speed no displaye	ency of the ad speed bugh this set when eeds to be d.

	Radiator ter driver modu	nperature of Ile	Factory default value	
F7-07	Setup range	0.0℃~ 100.0℃	Display the temper driver module IGE the over temperat protection value o driver module IGE with the model.	erature of BT, and ure f the BT varies

	Radiator temperature of rectifier module		F	actory default value	
F7-08	Setup range	0.0℃~ 100.0℃		Display the terr driver module I the over tempe protection value driver module I with the model.	nperature of GBT, and rature e of the GBT varies

	Accumulated running time			Factory default value	0h
F7-09	Setup range	0h ~ 65535h		Display the accumula running time of the di now. When this time reaches the setup run time (F8-17), the multifunctional digital of the driver (DO and performs action.	ated river till nning l output l F5-04)
	Software version No.1			Factory default value	
F7-10	Setup range		M No	anagement software o. of the control board	version
E7-11	Software version No.2			Factory default val	ue
	Setup range		So m	oftware version No. otor control board	of the

Group F8 Auxiliary Function

F8-00	Jog running frequency		ctory default value	2.00Hz
	Setup range	0.00Hz ~ maximum frequency		Im frequency
F8-01	Jog speed-up time		ctory default value	20.00s
	Setup range		0.00s~ 6500.0s	3
F8-02	Jog speed-down time		actory default value	20.00s
	Setup range		0.00s~ 6500.0	Ds

It is used to define the reference frequency and acceleration/deceleration time of the driver when jogging. The Jog process is started and stopped according to the start mode 0 (F6-00, direct start) and the stop mode 0 (F6-10, deceleration time to stop).

The Jog acceleration time means the time required for the driver to accelerate from 0Hz to the maximum output frequency (F0-10).

The Jog deceleration time means the time required for the driver to decelerate from the maximum output frequency (F0-10)to 0Hz.

		Factory		
F0 0 0	Speed-up time 2	T actory	20.00s	
F8-03		default value		
	Setup range	0. 0s~ 6500.0s		
		Factory	00.00	
F8-04	Speed-down time 2	default value	20.00s	
	Setup range	0.0s~ 6500.0s		
		Factory	00.00	
F8-05	Speed-up time 3	default value	20.00s	
	Setup range	0.0s~ 6500.0s		
	Speed-down time 3	Factory	00.00	
F8-06		default value	20.00S	
	Setup range	0.0s~ 6500.0s		
	On a set one time s 4	Factory	00.00-	
F8-07	Speed-up time 4	default value	20.008	
	Setup range	0.0s~ 6500.0s		
E9 09	One ad down time 4	Factory	20,005	
F8-08	Speed-down time 4	default value	20.00S	

Setup range	0.0s ~ 6500.0s
eetap range	0.00 0000.00

Speed-up/speed-down time can select F0-17 and F0-18 and above three types of Speed-up/speed-down time. Their meanings are the same, and refer to F0-17 and F0-18 for the relevant descriptions.

It can select Speed-up/speed-down time 1 to 4 during the driver running process via the different combination of multifunctional digital input terminal DI. Please refer to F4-01 to F4-05.

F8-09	Skip frequency 1	Factory default value	0.00Hz
	Setup range	0.00Hz~ max	imum frequency
F8-10	Skip frequency 2	Factory default value	0.00Hz
	Setup range	0.00Hz~ maximum frequency	
	Skip frequency F		0.00Hz
F8-11	amplitude 1	default value	
	Setup range	0.00~ maxir	num frequency

When the setup frequency is within the skip frequency range, the actual running frequency will be in the skip frequency boundary close to the setup frequency.

It can make the driver run away from the mechanical resonance point of the load through setting the skip frequency. This driver can set two skip frequency points. If the two skip frequencies are set to zero, this function will be inenabled.



Fig.6-10 Schematic Diagram of Skip Frequency

F8-12	Forward/reverse rotation dead-zone time	Factory default value	0.00s
	Setup range	0.00s~ 3000.0)s

During the setting of forward/reverse rotation of the driver, the transition time at the output zero frequency position is shown in the following figure:



Fig.6-11 Schematic diagram for Forward/ Reverse Rotation Dead-zone Time

F8-13	Reverse control		Factory default value	0
	Sotup range	0	Reverse rotation enabled	
	Octop runge	1	Reverse rotation inenabled	

When this parameter is set to 0, it can perform reverse rotation control on the driver with the keyboard, terminal or communication.

When this parameter is set to 1, the reverse rotation control function is enabled and has nothing to with the command source selection. That is to say, the reverse control function is inenabled at the time of keyboard, terminal and communication controls.

F8-14	Setup frequency lower than frequency lower limit action			Factory default value	0
	Setup	0	Run v	Run with frequency lower limit	
		1	stop	stop	
	range	2	Runn	Running with zero speed	

It is used to select the running status of the driver when the setup frequency is lower than the frequency lower limit.

In order to avoid that the motor always runs with low speed, it can use this function to stop.

F8-15	Droop control	Factory default value		0.00Hz
	Setup range		0.00Hz~ 10.00Hz	

When multiple drivers drive the same load, the unbalanced load distribution due to difference speed causes the driver with faster speed to carry heavier load. The droop control characteristics cause the speed droop change along with the addition of load, which can lead to balanced load distribution.

This parameter is used to adjust the frequency change value of the driver with droop speed.

F9 46	Over modulation enabled			Factory default value	1
F8-10	Setup	0	Over modulation inenabled		
	range	1	Over modu		

Over modulation function means that the driver can improve the output voltage by adjusting the use ratio of the bus voltage when the input voltage is relatively low or the driver always works under heavy load. When the over modulation is enabled, the output current harmonics will slightly increase.

This function can select whether the over modulation function is enabled.

50.47	Setup running time	F	actory default value	0h
F8-17	Setup range		0h to 65535h	

It is sued to preset the running time of the driver.

When the accumulated running time (F7-09) reaches this setup running time, the multifunctional digital DO of the driver outputs the signal of running time arrival.

	Start protection selection		Factory default value	0	
F8-18	Setup	0	no protection protection		
	range	1			

This function code is used to improve the safety protection coefficient. If it is set to 1, it has two roles: first, if the running command exists upon driver power-on, it must cancel the running command to remove the running protection status.

Second, if the running command exists upon driver fault reset, it must cancel the running command to remove the running protection status.

In this way, it can prevent the automatic running of the motor under unexpected conditions.

Frequency detection value (FDT level)			Factory default value		50.00Hz
	Setup range	0.00	0Hz~ maximum frequency		
F8-20	Frequency detection hysteresis (FDT hysteresis)		Factory defa value	ult	5.0%
	Setup range 0.09		‰~ 100.0%(FDT	leve	I)

It is used to set the detection value of output frequency and hysteresis value upon removing of the output action



Fig.6-12 Schematic Diagram for FDT Level

F8-21	Frequency arrival detection amplitude		Factory default value	0.0%
	Setup range	0.00~ 100% maximum		equency

When the output frequency of the driver reaches the setup frequency value, this function can be used to adjust the detection amplitude, as shown the following figure.



Fig.6-14 Schematic Diagram for Detection Amplitude

	Earth short c	ircuit protection on power-on	Factory default value	1
F8-22	Setup range	Inenabled 1: Enabled		

It can select whether the driver checks the motor for earth short circuit failure upon power-on. If this function is enabled, the driver has short-time output at the instance of power-on.

	Running tim selection	ne to action	Factory default value	0
F8-23	Setup range	0: Continue runr 1: Stop	ning	

Group F9 Fault and Protection

	Motor overload protection selection	Factory default value 1
F9-00	Setup range: 0: Inenabled 1:Enabled	 0: The driver has no overload protection for the motor, and thermal relay is installed before the motor. 1: The driver has overload protection function for the motor. Refer to F9-01 for the protection value.

	Motor overload protection gain	Factory default value	1.00
F9-01	Setup range: 0.20 ~ 10.00	The motor overload driver time-lag curve 220%×(F9-01)× rate current: one minute; 150%×(F9-01)× rate current: 60 minutes.	protection is ; d motor d motor

	Motor overload pre-warning coefficient		Factory default value	80%
F9-02	Sotup roppo	The reference for this value is the motor overload current. When the driver detects that the output current		
	50%~ 100% the reve	s (F9-02)× motor o and lasts time as erse time-lag curve ning signal from D	verload specified by e, it outputs 00 or relay.	
F9-03	Stall gain over voltage		Factory default value	0

Setup range: 0(no stall over voltage) to 100 the suppressing capacity is. For the load with small inertia, the value should be small. Otherwise, the dynamic response of the system will be slow. For the load with large inertia, the value should be large. Otherwise, the suppressing result will be poor, and over voltage fault may occur.
Stall protection Factory default voltage over voltage value
Select the protection point for function of stall over voltage.
Setup range: When the value is exceeded, the
120% to 150% driver starts executing the
voltage

	Stall gain over	current	Factory default value	20
F9-05	Setup range: 0~ 100	It adjusts the suppressing The bigger th the suppress For the load value should dynamic resp slow. For the load value should suppressing over voltage	e driver's capacity the stall over curr ne value is, the str sing capacity is. with small inertia, be small. Otherw ponse of the syste with large inertia, be large. Otherw result will be poor fault may occur.	in ent. ronger the rise, the rm will be the the r, and

	Stall protection current over curre	ent	Factory default value	150%
F9-06	Setup range: 100% ~ 200%	Sele of st is exec stall	ct the protection p all over current. N exceeded, the cuting the protecti over current.	oint for function When the value driver starts on function for

	Transient stop non-stop function	Factory default value	0
F9-07	Setup range: 0: Inenabled 1: Enabled	This function means that the will not stop upon transient p failure. In case of transient failure or sudden reduction i voltage, the driver will reduc output speed and compensa reduced voltage with the loa feedback energy, so as to en the driver continues running short period of time.	driver cower power n e the ate the d nsure within

	Transient stop non-stop frequency falling rate	Factory value	default	10.00Hz/s
F9-08	Setup range: 0.00Hz/s ~ maximum frequency	It is used to s output freque the transient is enabled. If the value feedback ene provide effect the low voltag If the value feedback ene cause over vo Please adjust according to t	et the fal ency of th stop nor is too si ergy is r tive com ge. is too la ergy will b oltage pro t the para the load i	ling rate of the e driver when h-stop function mall, the load not enough to apensation for arge, the load e too high and otection. umeter nertia.

	Fault auto reset times	Factory default 0					
F9-09	Setup range: 0 to 3	When the driver selects fault auto reset, it is used to set the times of auto reset. If this value is exceeded, the driver will stop because of failure and wait for maintenance.					
	Fault rely action se during the fault aut	ly action selection Fa					
F9-10	Setup range: 0: No action 1: Action	After the failure auto reset function is selected, this parameter can be set to determine if it needs the action of the faulty relay so as to shield the fault alarm caused and ensure the continuous operation of the equipment during the failure reset.					

F9-11	Fault auto reset interval	Factory default value	1.0s	
	Setup range:	The waiting time of the driver from		
	0.1s ~ 100.0s	the fault alarm to auto reset.		

	Input pha protectio	ase loss on selection	Factory default value 1				
F9-12	2 Setup range: 0: Inenabled 1: Enabled		Select whether to provide protection for input phase Only the MD series driver model with over 18.5kW ca input phase loss protection function, and the P model 18.5kW has not such func matter whether F9-10 is se 1.	loss. of G an have n with tion no et to 0 or			
E0 12	Output protectic	phase loss on selection	Factory default value 1				
F9-13	Setup	0: Inenabled	Select whether to provide				
	range	1: Enabled	protection for output phase failure.				

	Speed p	rotection	Factory default	10.00Hz			
F9-14	Setup	0.50Hz ~ 50.00Hz	It is used to set the freque deviation value of the motor spe deviation. (The deviation va between motor actual opera frequency and comm frequency.				
	Speed	deviation	Factory default	10 0s			
	protectio	on time	value	10.03			
F9-15	Setup range	$\begin{array}{l} \text{0.0s disable} \\ \text{0.1s} & \sim & \text{20.0s} \\ \text{0.0s(protection} \\ \text{inenabled}) \\ \text{0.1s}{\sim}\text{20.0s} \end{array}$	Ds It is used to set speed de protection time.				
	Motor te	mperature	Factory default	0			
F9-16	protectio	on selection	value	Ũ			
	Setup	0:Inenabled	Select whether or	not to protect the			
	range	1:Enabled	motor temperature	overheating.			
	Motor te	mperature	Factory default	0			
	protectio		value				
F9-17	Setup range	input 1: Al 1:analog input 2-3: Reserved	Select the mot overheating protect	or temperature tion mode			

F9-18	The First fault type	
F9-19	The Second fault type	0~45
F9-20	The the most recent fault type	

It is used to record the fault types of driver for the resent three times: 0 indicates no fault, while 1 to 24 indicates ERR01 to ERR24. Refer to Chapter 7 for details.

F9-21	Frequency upon	Display the most recent failure of the					
1921	fault	frequency					
F9-22	Current upon fault	Display the current upon fault for the most recent one time.					
		recent one time.					
F9-23	Bus voltage upon	Display the bus voltage upon fault for the					
1020	fault	most rec	ent on	e time.			
		This value is a decimal number. Display the status of all the digital input terminal upon					ay the
		status of all the digital input terminal upon					upon
		fault for t	the mo	st recer	nt one ti	me,witl	า
		sequence of:					
		BIT	BIT	BIT	BIT	BIT	
		4	3	2	1	0	
F9-24	Input terminal	DI5				DI1	
	status upon fault	It will b	be dis	played	in de	cimal	number
		converte	d from	each d	igit stat	us.	
		When the input terminal is ON, the					
		correspo	onding	value i	s 1. W	hen th	e input
		terminal is OFF, the value is 0.					
		It can know the details regarding digital					
		output signal via this value.					
		This valu	le is a	decima	Inumbe	er.Displ	ay the
		fault for the most recent one time with					
		sequence of					
		sequenc					
		BIT	BIT	BIT			
		2	1	0			
F9-25	Output terminal	REI 3	REI 2	REI 1			
	upon fault	REL3 REL2 REL1					
		converted from each digit status				•	
		When th	e input	termina	al is ON	I. the	
		correspo	onding	value is	1. Whe	en the i	nput
		terminal	is OFF	, the va	lue is 0).	
		lt can kn	ow the	details	regardi	ing digi	tal
		output si	ignal vi	a this v	alue.		

Group FD Communication Parameters(Reserved)

Group FP User Password

FP-00	user password (Authorization for all functions code except FP-05)	Factory default value	0
	Setup range	0 to 65535	

Any non-zero number can be set, and then the password protection function will be enabled.

000: Clear the previous setup user password and disable the password protection function.

Upon setup and validation of the user password, when the user enters the parameter setting status again, the user can view the parameters only and cannot modify the parameter if the password is incorrect. Please remember the setup user password correctly. If the password is set wrongly or forgotten, please contact the manufacturer.

FP-01	Parameter initialization		Factory default value	0	
	Setup range	0	No operation		
		1	Restore the factory default setup		
			value		
		2	Clear the fault record		

1: The driver restores all the parameters except the parameters in Group F1 to the factory default ones.

2: The driver clears the recent fault records.

3: Restore the setup function code value of the FP-04 saved.

FD 00	Motor specifications solidification		Factory default value	0	
FP-02	setup instroution	Ма	tor manufacturer	Motor rated rotation orque speed divided by 10 100	

When the motor specifications solidification parameter is non-zero, the following parameters will not be able to change:

- F1-00: Motor type selection
- F1-01: Rated power
- F1-02: Rated voltage
- F1-03: Rated current
- F1-04: Rated Frequency
- F1-05: Rated rotation speed
- F1-15: Back EMF

FP-03: Injection molding machine specifications solidification

Commissioning introduction:

It can not only realize motor specifications solidification, but also set the "motor static tuning" (F1-16 = " " 1) and " AI zero drift auto correction" (A3-20 = " 0 "), after that, injection molding machine is able to realize running. Then adjust PID, and the injection molding machine parameter adjustment is ended.

FP-03	Injection moldi machine specifications solidification	ng Factory default value	0	
	setup instroution	Injection molding machine	D1 012 Injection molding machine divided by 10	

When the parameter of injection molding machine specifications solidification is non-zero, the following parameters can not be changed.

- F1-00: Motor type selection
- F1-01: Rated power
- F1-02: Rated voltage
- F1-03: Rated current
- F1-04: Rated Frequentcy
- F1-05: Rated rotation speed
- F1-15: Back EMF
- F2-00: Speed loop proportional gain 1

- F2-01: Speed loop integration time 1
- F2-03: Speed loop proportional gain 2

F2-04: Speed loop integration time 2

F2-10: Torque upper limit

FP-02: Motor specifications solidification

Commissioning introduction:

It can not only realize injection molding machine specifications solidification, but also set the "motor static tuning" (F1-16="1") and "AI zero drift auto correction" (A3-20="0"), then the injection molding machine parameter adjustment is ended.

FP-04	User Passwor (Authorization FP-05function code)	d 2 n for	Factory default value	0
	Ssetup range 0~6		5535	

Set any one of the non-zero number, password protection function is taken into effect.

0000: Clear a previously setup user passwords 2 value, and make password protection function inenabled.

After setup the user password 2, and re-entry into parameter setup State, if the user password 2 is incorrect, you can only view the parameter, you cannot modify the parameters.Please keep the user's password 2 in mind .If you accidentally by mistake or forgot, please contact the manufacturer.

FP-05	Function code setup values in real time saved		Factory default value	0	
	Setup range	0	No operation		
		1	Save the currently set values for all the		
			function code		

1: Save the currently set values for all the function code, It can be restored By FP-01="3".



Servo Pump Commissioning Steps and Prototyping of servo pump optional parts

Chapter 7 Servo Pump Commissioning Steps and Prototyping of servo pump optional parts

7.1 Servo Pump Commissioning Process



Note: (1) Detailed instructions please refer to the following corresponding contents.

(2) Do not conduct the commissioning steps with *, it can also start the injection molding machine action.

7.2 Servo Pump Commissioning Steps

7.2.1 Motor commissioning

- 1) Set group F1 motor parateters (F1-00~F1-05, F1-15)
- 2) Set rotary encoder number of pole-pairs
- 3) Set the drvier to non-oil pressure control mode: A3-00 = "0"
- Set the driver to operation panel control mode, at this time the light of LOCAL/REMOT is off.
- 5) Motor parameter tuning(automatic identification) (F1-16)
 - a) F1-16="0": No operation. It doesn't conduct the motor parameters tuning.
 - b) F1-16 = "1": Staic tuning.Adopt when the motor back EMF is known.Run the motor at the low speed without opening the overflow valve during tuning.
 - c) F1-16="2": Dynamic tuning. Adopt it when the motor back EMF is unknown. Run the motor at the low speed with opening the overflow valve during tuning. Carrier tuning will affect the precision of the motor parameters tuned, affecting the system control effectiveness.
 - If correctly set F1 group motor parameters (F1-00~F1-05, F1-15), rotary encoder number of pole-pairs (A1-04), just only conduct F1-16="1"(staic tuning).
 - 2) If it is only able to correctly set F1 group motor parameters (F1-00 ~ F1-05), rotary encoder number of pole-pairs (A1-04) was unable to determine the F1-15 (back EMF), you must conduct F1-16 =" "1" (dynamic tuning).

The numerical value of parameter F1-16 will restore to zero automaticly after tuning.

If the driver alarm Err43 in the tuning process, it indicates that the encoder feedback signal is wrong, please check the encoder signal wiring and installation precision.

- 6) When commissioning, and set running frequency (F0-08), run by using the operation panel, while detecting whether the output current is normal, whether the motor is running quietly, and the way of using the operator .Please refer to the operation and display of Chapter 4.
 - a) Look into whether the running direction of the driver is correct, if it is correct, please swap motor wiring arbitrary two-phase UVW and recheck motor parameters tuning. Then commissioning.
 - b) If abnomal running, please check the motor parameters (F1 groups) and rotary encoder number of pole-pairs (A1-04) setup, and then

restart the motor parameters tuning, then commissioning.

- c) Motor has oscillation when running or sends a low voice, please weaken the speed loop (F2-00、F2-01、F2-03、F2-04) and current loop(F2-13、F2-14、F2-15、F2-16) appropriately (Reduce the value of F2-00、F2-03、F2-13、F2-14、F2-15、F2-16, increase the value of F2-01、F2-04).
- Motor running speed is not steady, please enhance speed loop (F2-00、F2-01、F2-03、F2-04) and current loop(F2-13、F2-14、F2-15、F2-16) appropriately.(Increase the value of F2-00、F2-03、F2-13、F2-14、F2-15、F2-16.Reduce the value of F2-01、F2-04)

NOTE: The slow response of the speed and current loop will affect the pressure stability directly, if the condition allows, please set the stronger speed loop and current loop response.

- 7.2.2 Servo Pump Application Commissioning
- Oil pressure control mode selection A3-00="0": Non- Oil pressure control mode A3-00="1": Driver oil pressure control mode 1.CAN provides oil pressure command and flow command, Al3 analog Channel provides oil pressure feedback command, the driver conducts oil pressure control.
 - A3-00 = "2": Driver oil pressure control mode2. Al1 provide oil pressure command, Al2 analog Channel provide flow command, Al3 analog Channel provides oil pressure feedback command, and the driver conducts oil pressure control.
 - A3-00="3": Oil pressure control mode (For special use), the control parameters of group A3 servo pump control group are inenabled.e) A3-00="4": Reserved.
- 2) The parameters automatic setup in the Oil pressure control mode.When the non-oil pressure mode switches to oil pressure mode (A3-00≠"0"), the relevant parameters will be automatically set, as described in the following table.

Function Code	Function Code Description	Setup	
F0-01	Control mode	1(Vetor control mode)	
F0-02	Command source	1(Terminal command source)	
F0-03	Frequency source	If A3-00 = "2", F0-03 = "3 "(A I2 is frequency source).If A3-00 = "1" or "3",	

Table 7-1 Automatic setup parameters deails

Function	Function Code	Setup
oode	Description	F0-03 = "9"(Communication setup is frequency source)
F0-07	Frequency source selection	0 (Non-auxiliary frequency source)
F0-17	Speed-up time	0.0s
F0-18	Speed-down time	0.0s
F1-00	Motor type selection	2 (Synchronous motor)
F4-00	DI1 terminal function selection	11 (Running enabled)
F4-01	DI2 terminal function selection	48 (Oil pressure control PID select terminal 1)
F4-02	DI3 input function selection	49(Oil pressure control PID select terminal 2)
F4-03	DI4 input function selection	9 (Fault reset)
F4-04	DI5 input function selection	50(CAN communication enabled)
F5-01	DO1 output function selection	2 (Fault output)
F5-02	DO2 output function selection	23(Swashplate switch)
F5-03	DO3 output function selection	24 (Pressure control status output)

Modify the above-mentioned parameters in the oil pressure control mode, it may be power-failure recorded (which the driver to repower is to restore setup value automatically), When the oil pressure mode switches to non-oil pressure mode, the above parameters will be restored to switch to the numerical value which is before oil pressure control mode.

3) Al zero drift auto-correction (A3-20):

Set AI zero drift auto correction parameter A3-20 to 1, the driver will conduct an AI zero drift auto correct operation:

Write the detection value zero drift of three analog channel into the parameters, they are F4-18 (Al1 is the minimum input), F4-23 (Al2 is the minimum input), F4-28 (Al3 is the minimum input). The detection value of zero drift can be

found at U1-07, U1-08, and U1-09.

Command setup of flow and oil pressure (A3-01, A3-02, A3-03) :

- ii. A3-01: Manimum rotation speed.Set the motor running manimum rotation speed which is the motor rotation speed corresponds to flow command one hundred percent.
- iii. A3-02: System oil pressure.Set system manimum pressure.
- iv. A3-03: Manimum oil pressure.Set the pressure scale of pressure sensor.

Pressure relief setup (A3-08):

A3-08: It is the maximum reverse rotation speed when pressure relief, which corresponds to the percentage setup of manimum rotation speed. It is used to set the maximum reverse rotation speed. The greater setup value is, the faster pressure relief will be, but excessive noise cause pump reversal. The smaller setting value is, the slower pressure relief will be.

4) Minimum Flow and Minimum Pressure (A3-09, A3-10).

Due to oil pump exists internal leakage, the system is not given flow and pressure command, the hydraulic oil in oil circuit oil tanks wil reflow to the oil tank, then it will cause the air enters the oil circuit, resulting in a system running noise and unstable. So you need to set a certain minimum Flow (A3-09, corresponding the percentage of manimum rotation speed setup) and minimum Pressure (A3-10).

5) System Response (Oil pressure PID control)

The driver provides four groups PID, according to the input terminals of the DI2 and DI3 combination selection, the corresponding selection is as follows.

DI3	DI2	Group PID
0	0	The first group PID: A3-05、A3-06、 A3-07
0	1	The second group PID: A3-11、A3-12、 A3-13
1	0	The third group PID: A3-14、A3-15、 A3-16
1	1	The fourth group PID: A3-17、A3-18、 A3-19

Table 7-2 PID Combination Selection

The greater proportional gain KP is, the smaller integration time Ki will be, and the larger derivative time KD is, the faster response will be. Response too quickly can easily lead to overshoot, cause system instability and running oscillation.

In contrast, the smaller proportional gain KP is, the greater integration time Ki will be, and the smaller derivative time KD is, the lower response will be. Response too slowly can easily lead to inefficient and products unstable.

7.3 Servo oil pump optional parts prototyping

Flow is Q (L/min) ,system pressure is P1 (kgf/cm2) ,motor or oil pump manimum rotation speed is Vmax (rpm) .

7.3.1 Oil pump prototyping

Oil pumps pressure selection:

Oil pumps rated pressure should be greater than system pressure P1 $(\mbox{kgf/cm}^2)$.

Oil pump displacement selection:

Oil pump displacement per revolution I (ml/rev) =Q (L/min) ×1000 (ml/L) / Vmax (rpm)

Oil pump type selection:

Please follow the instructions below corresponding to pump type selection

Oil pump type	Price	Volumetric efficiency	Fluctuation (stability)	Noise	Reliability	Pressure (single stage)	Rotation speed
Gear pump	Low	Low	Medium	Medium	High	Low	Medium
Plunger pump	Middle	High	High	High	Low	Medium	Low
Screw pump	High	Medium	Low	Low	Medium	High	High

7.3.2 Servo Motor Prototyping

Rated rotation speed selection of servo motor

Characteristic curve of servo motor (permanent magnet synchronous servo motor) shown in Figure 7-1.



servo motor)

From the figure above, after the motor speed is higher than the rated speed, and with the motor speed, the motor torque will gradually decrease. But when the motor speed exceeds 150% of the rated speed, the motor torque will decline rapidly, so the speed segment cannot be used as the work of the servo motor speed fragment uses.

Therefore, select 140% of the rated speed to be the motor maximum speed.

Motor rated rotation speed: V (rpm) =Vmax (rpm) /140%

Note: For better control results, please select 130% of he motor rated speed to be the maximum speed.

Servo motor rated toque selection:

According to energy conservation law, plastic maximum output power is P2max (kW) =P1 (kgf/cm²) ×0.9807 (kgf/cm²/bar) ×Q (L/min)

Motor maximum output power is (Follow 80 percent of the energy conversion efficiency, Including motor efficiency, hydraulic transmission efficiency, mechanical transmission efficiency, etc.) P3max (kW) = P2max (kW) / 80% Servo motor maximum output torque is: Tmax (Nm) = P3max (kW) ×9550/ Vmax (rpm)

Due to injection molding machine requires continuous output high torque when packing pressure, according to the servo motor (servo motor) characteristic curve, servo motor overall job status is in the DT-100 $^{\circ}$ c (s1) and (S3 20 percent between 5MIN).

Therefore, select 180% of the motor rated torque to be the maximum torque. Servo motor rated torque is: Tn (Nm) = Tmax (Nm) / 180%

Note: If selecting the double displacement plunger pump or dual-gear pump,

while packing pressure by decreasing the pump displacement that can greatly reduce motor torque output, servo motors general working state is in the working state. (The S3 state is 20 percent of the working status of 5MIN), select 230% of the rated torque to be the motor maximum torque.

7.3.3 Servo Driver Prototyping

Capacity Selection of Servo Driver:

After the prototyping of servo drivers, please ask the servo motor supplier for corresponding motor torque constant values Kt (Nm/A).

Note: The torque constant value Kt (Nm/A) is relevant to the servo motor technology, materials and motor rated speed Vn (rpm) .

The packing pressure current of servo driver (Follow 93% of the energy conversion efficiency):

Imax (A) =Tmax (Nm) / Kt (Nm/A) /93%

According to the principle that the numerical value which is less than 150 percent of servo driver rated output current, it can get the desired servo driver model and the driver accessories model.



EMC(Electromagnetic Compatibility)

Chapter 8 EMC (Electromagnetic Compatibility)

8.1 Definition

Electromagnetic compatibility is the ability of the electric equipment to run in the electromagnetic interference environment and implement its function stably without interferences on the electromagnetic environment.

8.2 EMC Standard Description

In accordance with the requirements of the national standard GB/T12668.3, the servo driver needs to comply with electromagnetic interference and antielectromagnetic interference requirements.

The existing products of our company apply the latest international standard—IEC/EN61800-3: 2004 (Adjustable speed electrical power drive systems—part 3:EMC requirements and specific test methods), which is equivalent to the national standard GB/T12668.3.

IEC/EN61800-3 assesses the driver in terms of electromagnetic interference and anti-electronic interference. Electromagnetic interference mainly tests the radiation interference, conduction interference and harmonics interference on the driver (required for the driver for civil use)Anti-electromagnetic interference mainly tests the conduction interference rejection, radiation interference rejection, surge interference rejection, fast and mutable pulse group interference rejection, ESD interference rejection and power low frequency end interference rejection (specific test items including: 1. Interference rejection tests of input voltage sag, interrupt and change; 2. Phase conversion interference rejection test; 3. Harmonic input interference rejection test; 4. Input frequency change test; 5. Input voltage unbalance test; 6. input voltage fluctuation test).

The tests shall be conducted strictly in accordance with the above requirements of IEC/EN61800-3, and the products of our company are

installed and used according to Section8.3 and have good electromagnetic compatibility in general industry environment.

8.3 EMC Guide

8.3.1 Harmonic Effect

Higher harmonics of power supply may damage the driver. Thus, at some places where mains quality is rather poor, it is recommended to install AC input reactor.

8.3.2 Electromagnetic Interference and Installation Precautions

There are two kinds of electromagnetic interferences, one is interference of electromagnetic noise in the surrounding environment on the driver, and the other is interference of servo driver on the surrounding equipment.

Installation precautions:

The earth wires of the Driver and other electric products shall be well grounded;

The power input and output power cables of the driver and weak current signal cables (e.g. control line) shall not be arranged in parallel and vertical arrangement is preferable.

It is recommended that the output power cables of the driver employ shield cables or steel pipe shielded cables and that the shielding layer be earthed reliably. The lead cables of the equipment suffering interferences are recommended to employ twisted-pair shielded control cables, and the shielding layer shall be earthed reliably.

When the length of motor cable is longer than 100 meters, it needs to install output filter or reactor.

8.3.3 Handling method for the interferences of the surrounding equipment on the servo driver:

The electromagnetic interference on the servo driver is generated because plenty of relays, contactors and electromagnetic brakes are installed near the driver. When the servo driver has error action due to the interferences, the following measures can be taken:

- 1) Install surge suppressor on the devices generating interference
- 2) Install filter at the input end of the driver. Refer to Section 7.3.6 for the specific operations.
- 3) The lead cables of the control signal cable of the driver and the detection line employ shielded cable and the shielding layer shall be earthed reliably.

8.3.4 Handling method for the interferences of servo driver on the surrounding equipment:

These interferences include two types: one is radiation interference of the servo driver, and the other is conduction interference of the servo driver. These two types of interferences cause the surrounding electric equipment to suffer electromagnetic or electrostatic induction. The surrounding equipment hereby produces error action. For different interferences, it can be handled by referring to the following methods:

- 1) For the measuring meters, receivers and sensors, their signals are generally weak. If they are placed nearby the driver or together with the driver in the same control cabinet, they are easy to suffer interference and thus generate error actions. It is recommended to handle with the following methods: Put in places far away from the interference source; do not arrange the signal cables with the power cables in parallel and never bind them together; both the signal cables and power cables employ shielded cables and are well earthed; install ferrite magnetic ring (with suppressing frequency of 30 to 1,000MHz) at the output side of the driver and wind it 2 to 3 cycles; install EMC output filter in more severe conditions.
- 2) When the equipment suffering interferences and the driver use the same power supply, it may cause conduction interference. If the above methods cannot remove the interference, it shall install EMC filter between the driver and the power supply (refer to Section 7.3.6 for the prototyping operation);
- 3) The surrounding equipment is separately earthed, which can avoid the interference caused by the leakage current of the servo driver's earth wire when common earth mode is adopted.

8.3.5 Leakage current and handling

There are two forms of leakage current when using the driver. One is leakage current to the earth, and the other is leakage current between the cables.

1) Factors influencing the leakage current to the earth and the solutions:

There are distributed capacitance between the lead cables and the earth. The larger the distributed capacitance is, the larger the leakage current will be. The distributed capacitance can be reduced by effectively reducing the distance between the driver and the motor. The higher the carrier frequency is, the larger the leakage current will be. The leakage current can be reduced by reducing the carrier frequency. However, reducing the carrier frequency may result in addition of motor noise. Note that additional installation of reactor is also an effective method to remove the leakage current.

The leakage current may increase following the addition of circuit current. Therefore, when the motor power is high, the corresponding leakage current will be high too.

2) Factors of producing leakage current between the cables and solutions:

There is distributed capacitance between the output cables of the driver. If the current passing the lines has higher harmonic, it may cause resonance and thus result in leakage current. If thermal relay is used, it may generate error action.

The solution is to reduce the carrier frequency or install output reactor. It is recommended that thermal relay not be installed before the motor when using the driver, and that electronic over current protection function of the driver be used instead.

8.3.6 Precautions for Installing EMC input filter at the input end of power supply

- When installing the EMC input filter at the input end of the power supply, it is recommended to use the EMC filter produced by Shanghai Eagtop Electronic Technology Co., Ltd.
- 2) Note When using the filter, please follow its rated values strictly. Since the filter belongs to Classification I electric appliances, the metal enclosure of the filter shall be large and the metal ground

of the installing cabinet shall be well earthed and have good conduction continuity. Otherwise there may be danger of electric shock and the EMC effect may be greatly affected.

- 3) Through the EMC test, it is found that the filter ground must be connected with the PE end of the driver at the same public earth. Otherwise the EMC effect may be greatly affected.
- 4) The filter shall be installed at a place close to the input terminal of the power supply as much as possible.

9

Failure Diagnosis and Solution
Chapter 9 Failure Diagnosis and Solution

9.1 Failure Diagnosis and Solution

IS300 Servo Driver has 23 pieces of warning information and protection function. In case of abnormal fault, the protection function will be invoked, the driver will stop output, and the faulty relay contact of the driver will start, and the fault code will be displayed on the display panel of the driver. Before consulting the service department, the user can perform self-check according to the prompts of this chapter, analyze the fault cause and find out t solution. If the fault is caused by the reasons as described in the dotted frame, please consult the agents of driver or our company directly.

Err01 (Reserved)



Fig.9-1 Speed-up over current (ERR02)



Fig.9-2 Speed-down over current (ERR03)



Fig.9-3 Constant speed over current (ERR04)



Fig.9-4 Speed-up over voltage (ERR05)



Fig.9-6 Constant Speed over voltage (ERR07)

Err08 (Reserved)



Fig.9-7 Under Voltage Fault (ERR09)



Fig.9-8 Servo Driver/Motor Overload (ERR10/ERR11)







Fig.9-10 Phase Failure at Output Side (ERR13)







Fig.9-12External Equipment Fault (ERR15)







Fig.9-14 Contactor Fault (ERR17)



Fig.9-15 Current Detection Fault (ERR18)



Fig.9-16Motor Tuning Fault (ERR19)



Fig.9-17 PG Fault (ERR20)





Err22 (Reserved)





Err24~Err41 (Reserved)



Fig.9-20 CAN Communication Interrupted Fault (Err42)



Fig.9-21 Motor Parameter Identification Encoder Fault



Fig.9-22 Speed Deviation Over Large Fault (Err44)



Fig.9-23 Oil Pressure Sensor Fault ((Err4 6))

Note: Err47 and Err48 are the relevant failure contents of pumps in parallel flow.

If adopt the control single pump, please cut off DI5 input terminals.And if adopt pumps in parallel flow control, please refer to the mulitple pump control solution.

9.2 Common Fault and Resolution

During the servo driver using process, the following faults may occur. Please conduct simple fault analysis by referring to the methods below:

No.	Fault Phenomenon	Possible Cause	Solution
1	No display upon power-on	 The driver has no input power supply. 8-core bus connecting with the drive board and control bard is in poor contact. The internal parts of the driver are 	 Check the input power supply. Plug/unplug the 8-core bus once again. Consult the manufacturer.
2	HC is displayed upon power-on	 4-core bus connecting with the drive board and control bard is in poor contact. Other parts of the driver are damaged. 	 Plug/unplug the 4-core bus once again. Consult the manufacturer.
3	"ERR23" alarm is displayed upon power-on.	1. The motor or the output line is short	1. Measure the insulation of the motor and output line with magneto-ohmmeter.

No.	Fault Phenomenon	Possible Cause	Solution
		circuited to the earth. 2. The driver is damaged.	2. Consult the manufacturer.
4	The driver displays normally upon power-on, but "HC" is displayed upon running and stops immediately.	The fan is either damaged or blocked.	Replace the fan.
5	ERR14 (module overheating) fault is frequently reported.	 The carrier frequency is set too high. The fan is damaged or the air duct is blocked. The internal parts (thermal coupler or others) of the driver are damaged. 	 Reduce the carrier frequency (F0-15). Replace the fan and clear the air duct. Consult the manufacturer.
6	The motor does not rotate upon driver running.	 The motor is either damaged or blocked. The parameters are set 	 Replace the motor or remove the mechanical fault. Check and reset Group F1 parameters.

No.	Fault Phenomenon	Possible Cause	Solution
		improperly (mainly Group F1 motor parameters).	
7	DI terminal inenabled	 The parameter is set wrongly. The short circuit copper bar between OP and +24V is loosen. Control board fault. 	 Check and reset Group F4 related parameters. Reconnect the cables. Consult the manufacturer.
8	In the close loop vector control mode, the motor speed is always low.	 The PG is damaged or cable connection is wrong. The internal parts of the driver are damaged. 	 Replace the PG and reconfirm the cable connection. Consult the manufacturer.
9	The driver frequently reports over current fault and over voltage fault.	 The motor parameters are set wrongly. Speed-up and speed-down time is improper. 	 Reset Group F1 parameters or perform motor tuning. Set proper speed-up/speed-down. Consult the manufacturer.

No.	Fault Phenomenon	Possible Cause	Solution
		3. Load fluctuates.	
10	ERR17 alarm is reported upon power-on.	 The soft start contactor is not switched on. 	 Check if the contactor cables are loosened; Check if the contactor has fault; Check if the 24V power supply of the contactor has fault; Consult the manufacturer.

Appendix 1: Common Parameters Table

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
	Group	U0 Driver	Parameter Viewing	group		
U0-00	Running frequency	Running frequency	$\begin{array}{l} \text{0.00Hz} {\sim} \text{maximum} \\ \text{frequency} \ (\text{F0-10}) \end{array}$		—	•
U0-01	Setup frequency	Setup frequency	$0.00Hz \sim maximum$ frequency (F0-10)	_	_	•
U0-02	Bus voltage	Bus voltage	0V~830V	_	—	•
U0-03	Output voltage	Output voltage	$0V \sim Motor rated$ voltage (F1-02)		—	•
U0-04	Output current	Output current	0.01A~655.35A	_	—	•
U0-05	Output power	Output power	0.4kW~1000.0kW	_	_	•
U0-06	Output Torque	Output Torque	$\begin{array}{ll} 0.0\% & \sim & \text{Torque} \\ \text{upper} & \text{limit} \\ (\text{F2-10}) & \end{array}$		_	•
U0-07	Local DI/DO status	Local DI/DO status	Unused DI5 DI4 T Unused DI5 DI4 T Unused T/ $A3$	DI3 DI2 DI1 ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓	-Input status -Mark line -Output status -T/C1	•
U0-08	Expansion DI / DO status	Expansion DI / DO status	$\begin{array}{c} \downarrow \\ \downarrow $	$\begin{array}{c} 18 \\ 17 \\ 18 \\ 17 \\ 18 \\ 17 \\ 18 \\ 18 \\$	-Input status -Mark line -Output status	•

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
U0-09	AI1 voltage(afte r corrected)	AI1 voltage(afte r corrected)	-10.00V~10.000V	_	_	•
U0-10	Al2 voltage(afte r corrected)	AI2 voltage(afte r corrected)	-10.00V~10.000V	—		•
U0-11	Al3voltage(after corrected)	Al3voltage(after corrected)	-10.00V~10.000V	_	_	•
U0-12 \sim U0-29	Reserved	_	_	—	_	•
U0-30	AI1 voltage(befo re corrected)	AI1 voltage(bef ore corrected)	-10.00V~10.000V	_	_	•
U0-31	Al2voltage(before corrected)	AI2 voltage(bef ore corrected)	-10.00V~10.000V	_	_	•
U0-32	AI3 voltage(befo re corrected)	AI3 voltage(bef ore corrected)	-10.00V~10.000V	—	_	•
	Group A) Weak magn	etism and SVC con	trol grou	р	
A0-00	Weak magnetism control mode	Weak magnetism control mode	0:Direct calculation 1:Automatic adjustment	1	0	*
A0-01	Weak magnetismc urrent coefficient	Weak magnetism current coefficient	80%~200%	1	100%	*

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
A0-02	Weak magnetism current upper limit	Weak magnetism current upper limit	0~120	1	100	*
A0-03	Weak magnetism_ Integral multiples	Weak magnetism_ Integral multiples	200~1000	1	400	*
A0-04	Weak magnetism_ coefficient	Weak magnetism_ coefficient	0~100	1	4	*
A0-05	Output phase failure PWM detection time	Output phase failure PWM detection time	0~63000	1	0	*
		Group A1	Group PG Card			
A1-00~ A1-01	Reserved	-	-	-	-	*
A1-02	Encoder installation angle	Encoder installation angle	0.0°~359.9°	0.1°	0.0°	$\Sigma_{\rm c}$
A1-03	Select the reverse feedback speed	Select the reverse feedback speed	0~1	1	0	$\Sigma_{\gamma}^{\lambda}$
A1-04	Rotary transformer number of pole-pairs	Rotary transformer number of pole-pairs	1~50	1	1	*

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
A2-00	Baud rate selection	Baud rate selection	0: 20k 1: 50k 2: 125k 3: 250k 4: 500k 5: 1M	1	5	\$
A2-01	CAN communicat ion address	CAN communicati on address	1~255	1	1	Å
A2-02	CAN communicat ion continuous time	CAN communicati on continuous time	0.0s (inenabled) 0.1s \sim 5.0s	0.1s	0.3s	对
	(Group F0 Ba	asic Function Grou	р		
F0-02	Command source selection	Command source selection	0: Operation panel running command channel (LED OFF) 1: terminal command channel (LED ON) 2: serial port command channel (LED flashes)	1	0	*
	1	Group F1	Motor Parameters	i	i	
F1-00	Motor type selection	Motor type selection	Permanent magnetic synchronous motor	1	2	*
F1-01	Rated power	Rated power	0.4kW \sim 1000.0kW	0.1kW	Model depend ent	*

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
F1-02	Rated voltage	Rated voltage	0V~440V	1V	Model depend ent	*
F1-03	Rated current	Rated current	0.01A~655.35A	0.01A	Model depend ent	*
F1-04	Rated frequency	Rated frequency	0.00~maximum frequency	0.01Hz	Model depend ent	*
F1-05	Rated rotation speed	Rated rotation speed	0rpm \sim 30000rpm	1rpm	Model depend ent	*
F1-15	Back EMF	Back EMF	0~65535V	1	Model depend ent	*
F1-16	Tuning selection	Tuning selection	0: no operation1: static tuning(low speed)2: dynamic tuning (high speed)	1	0	*
		GroupF2 C	ontrol Parameters			
F2-00	speed loop proportional gain 1	Speed loop P1	0~100	1	60	${\leftrightarrow}$
F2-01	Speed loop integration time 1	Speed loop I1	0.01s~10.00s	0.01s	0.30s	${\leftrightarrow}$
F2-03	Speed loop proportional gain 2	Speed loop P2	0~100	1	60	☆
F2-04	Speed loop integration time 2	Speed loop I2	0.01s~10.00s	0.01s	0.30s	Å

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
F2-10	Torque upper limit	Torque upper limit	0.0%~250.0%	0.1%	200.0%	$\stackrel{\wedge}{\sim}$
F2-13	D axis current loop Kp	D axis current loop Kp	0~65535	1	50	${\leftrightarrow}$
F2-14	D axis current loop Ki	D axis current loop Ki	0~65535	1	50	☆
F2-15	Q axis current loop Kp	Q axis current loop Kp	0~65535	1	50	Å
F2-16	Q axis current loop Ki	Q axis current loop Ki	0~65535	1	50	☆
		Group F4	Input terminal			
F4-32	AI3 input filter time	AI3 filter time	0.00s~10.00s	0.01s	0.00s	☆
		Group F7 Ke	eyboard and Displa	<u>y</u>		
F7-10	Software version No.1	Software version No.1	-	-	-	•
F7-11	Software version No.2	Software version No.2	-	-	-	•
		Group FP	User Password			
FP-00	user password1	Authorizatio n for all functions code except FP-05	0~65535	1	0	Σ

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
FP-01	Parameter initialization	Parameter initialization	0:No operation 1::Restore the factory default setup value 2: Clear the fault record 3:Restore the setup function code value of FP-05 saved.	1	0	*
FP-02	Motor specification solidification	Motor specification	0~65535	1	0	*
FP-03	Injection molding machine specification solidification	Injection molding machine specification s	0~65535	1	0	*
FP-04	user password2	Authorizatio n for FP-05 function code	0~65535	1	0	*
FP-05	Function code setup values in real time saved	Save the currently set values for all the function code	0: No operation 1 : Save the currently set values for all the function code	1	0	*

Appendix 2 Shortcut menu parameters table

It can be quickly called function code from the shortcut menu by quick keys. The shortcut menu is set to facilitate the user to quickly view and modify the commonly used function parameters. In the shortcut menu, the parameter is displayed in the form of "Uf3-02", which indicates the function parameter F-02. Parameter modification in the shortcut menu has the same effect as the operation in the common programming status.

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
uA3-01	Maximum rotation speed	Maximum rotation speed	Maximum frequency lower limit corresponding to rotation speed~30000rpm	1rpm	2000rp m	*
uA3-02	System oil pressure	System oil pressure	$0.0 \text{kg/cm}^2 \sim \text{the}$ maximum oil pressure(A3-03)	0.0kg/c m ²	175.0kg /cm ²	${\leftarrow}$
uA3-03	Maximum oil pressure	Maximum oil pressure	system oil pressure(A3-02) \sim 500.0kg/cm ²	0.0kg/c m ²	250.0kg /cm ²	☆
uA3-04	Oil pressure command risetime	Oil pressure setup risetime	0ms~2000ms	1ms	20ms	Å

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
uA3-05	Oil pressure control Kp1	Oil pressure control Kp1	0.0~800.0	0.1	210.0	Å
uA3-06	Oil pressure control Ti1	Oil pressure control Ti1	0.001s~10.000s	0.001s	0.100s	¥
uA3-07	oil pressure control Td1	oil pressure control Td1	0.000s~1.000s	0.001s	0.000s	☆
uA3-08	Maximum reverse rotation speed	Maximum reverse rotation speed	0.0%~100.0%	0.1%	20.0%	$\Sigma_{\gamma}^{\lambda}$
uA3-09	Minimum flow	Minimum flow	0.0%~50.0%	0.1%	0.5%	\$
uA3-10	minimum pressure	minimum pressure	0.0 kg/cm ² \sim 50.0 kg/cm ²	0.1kg/c m ²	0.5kg/c m ²	\$
uA3-20	Al zero drift auto correction	Al zero drift auto correction	0:Inenabled 1:Enabled	0	0	
uF2-00	Speed loop proportional gain 1	Speed loopP1	0~100	1	60	Σ_{γ}^{\prime}
uF2-01	Speed loop integration time 1	Speed loop I1	0.01s~10.00s	0.01s	0.30s	Σ_{γ}^{\prime}
uF2-03	Speed loop proportional gain 2	Speed loopP2	0~100	1	60	₩
uF2-04	Speed loop integration time 2	Speed loopP I2	0.01s~10.00s	0.01s	0.30s	X4

Function code	Name	LED display	Setup range	Minimu m unit	Factor y default value	Modifi c-ation descri p-tion
uF4-32	AI3 input filter time	AI3 filter time	0.00s~10.00s	0.01s	0.00s	☆

Warranty Agreement



- 1. The warranty period of the product is 18 months (refer to the barcode on the equipment body). During the warranty period, if the product fails or is damaged under the condition of normal use by following the instruction, Our Company will be responsible for free maintenance.
- 2. Within the warranty period, maintenance will be charged for the damages caused by the following reasons:

a. The damage caused by improper use or repair/modification without prior permission;

b. The damage caused by fire, flood, abnormal voltage, other disasters and second disaster;

c. The hardware damage caused by dropping or transportation upon the procurement.

d. The damage caused by the improper operation;

e. The damage or failure caused by the trouble out of the equipment (e.g. external device)

- 3. If there is any failure or damage to the product, please correctly fill out the Product Warranty Card in detail.
- 4. The maintenance fee is charged according to the newly adjusted Maintenance Price List by our company.
- 5. In general, the warranty card will not be re-issued. Please keep the card and present it to the maintenance personnel when asking for maintenance.
- 6. If there is any problem during the service, please contact the agent of our company or our company directly.
- 7. This agreement shall be interpreted by Shenzhen Inovance Technology Co., Ltd.

Shenzhen Inovance Technology Co., Ltd.

Service Department

Address: Block E, Hongwei Industry Park, Liuxian Road, Baocheng No.

70 Zone, Bao'an District, Shenzhen

Tel: 400-777-1260

P.C.: 518101

Website: www.inovance.cn



	Add. of unit:				
Customer information	Name of unit: P.C.:	Contact person:			
		Tel.:			
	Product model:				
	Body barcode (Attach here):				
Product					
information					
	Name of agent:				
	(Maintenance time and content):				
Failure					
information	ation				
	Maintenance personnel:				