

Doc. No.	Pub. EM-0146-1					
Date of issue	January 5, 2010					
Products Publicity Section,						
Sales Administration Dept.						

ASE Series AC Servo Motor-Driven Pumps

Model: ASE3-4AA-G80*-B00-10

: ASE5-4BZ-G130*-B00-20

: ASE10-4CE-G200*-B00-20

- To ensure safe and correct use of the product -
- To ensure proper handling of the product, read this manual thoroughly before use.
- Be sure to follow the instructions described in the Safety Precautions section and the main body of this manual.
- Keep this manual at hand for future reference.
- When creating instruction manuals for systems equipped with the product, be sure to reflect the contents of this manual in such documents.

——————About this manual——————


- Some figures and illustrations in this manual are simplified and may not be an exact representation of the product.
- The contents of this manual are subject to change without prior notice as improvements are made to the product.
- Although this manual has been prepared with great care, please contact your supplier our customer support if you find any ambiguous explanations, errors, or omissions.
- If there are missing pages or erratic pagination in this manual, please contact our customer support. We will replace the manual.
- Reprint, reproduction, or modification of this manual without the permission of YUKEN KOGYO CO., LTD. is prohibited.

Safety Precautions

- This manual is intended for users of the product with adequate knowledge of electrics and hydraulics.
- The product should be handled by users having equivalent knowledge as stated above or under the supervision of such personnel.
- Be sure to provide end-users with the instructions, warnings, and cautions described in this manual.
- Be sure to attach this manual when transferring or reselling the product.

In this manual, safety precautions are classified into three levels: "DANGER," "WARNING," and "CAUTION." Be sure to read and understand the safety precautions before reading the main body of this manual.

Symbols and definitions for safety precautions in this manual are as follows.



Safety precautions labeled "CAUTION" may result in serious consequences depending on the situation. Regardless of their classification, all safety precautions contain important instructions. Be sure to follow them.

YUKEN KOGYO CO., LTD. assumes no liability for any accident or damage arising from the use or operation of the product in a manner other than specified in this manual.

■ Always follow the safety precautions

M DANGER

- Never use the product in an explosive atmosphere where flammable gases or explosives are handled. Doing so may result in a fatal accident, such as fire or explosion.
- Never perform wiring, assembly, or maintenance/inspection work with the product powered on.
 Doing so may cause electric shock, resulting in a fatal accident.
- Before wiring, installation, relocation, or inspection, shut off the power supply and wait 15 minutes or more. When the CHARGE lamp of the AMSE controller turns off, perform a voltage check using a tester and then conduct the work.

MARNING

- Only use input power supplied specified. Not doing so may cause overheating, resulting in fire.
- Do not modify or disassemble the product. Doing so may impair safe operation.
- Install the AMSE controller and regenerative resistors on nonflammable objects. Any flammable object near them may be heated, and causei fire.
- Be sure to connect the ground wire as a precaution against electric shock in the event of earth leakage. Never connect the ground wire to the following.
 - Gas pipe Lightning rod Water pipe/faucet Telephone line ground
- Handling of emergencies
 - •smoke from the product

The continuous use of the product under abnormal conditions, such as smokeor or unusual odors, may result in fire and/or electric shock. Immediately shut off the power supply and contact your local customer service after checking that the smoke has stopped. The repair of the product by users is dangerous. Users should never attempt repairs.

- If the product is broken
- If the product is dropped pulled down or physically damaged, immediately shut off the power supply and contact your local customer service. Continuous use without taking corrective measures may result in fire and/or electric shock.
- If water gets into the product

If water gets into the product, immediately shut off the power supply and contact your local customer service. Continuous use without taking corrective measures may result in fire and/or electric shock.

A CAUTION

- Do not put any object in the pump. Doing so may damage the pump's internal parts during operation.
- During operation or for some time after a power-off, the motor frame temperature is high. Prevent hands or other body parts from contacting the frame in order to avoid burn.
- Do not step on or put any heavy object on the product. Doing so may result in damage to the product/equipment or injury from collapse/falling.

■ Table of Contents

1. Introduction			
1.1 Intended users of the product		Ρ	5
1.2 Intended purpose		Ρ	5
1.3 Product check ·····		Ρ	5
2. About the product			
2.1 Basic structure and components		Р	6
2.2 Basic system configuration ······		Р	7
2.3 Control system		P	7
2.4 Model number designation ·····		P	8
2.5 Specifications		P	9 ₋ 10
2.6 External dimensions and mass ······		P	11-12
2.7 Interface		, D	13_18
3. Installation of the ASE pump unit			13-10
3.1 Tools for installation		D	10
		Г	19
Relocation of the ASE pump unit P 19 Reparation for installation		Ь	20
3.3 Preparation for installation		2	20
3.4 Installation of the ASE pump unit		2	21
3.5 Piping		Р	22-23
4. Installation of the AMSE controller		_	
4.1 Preparation for installation ····································		Ь	24-25
4.2 Terminal wiring diagram ·······		Р	26
4.3 Wiring of regenerative resistors ······		Р	27
4.4 Wiring type ·····		Р	28
5. Preparation for operation			
5.1 Operating environment ······		Р	29
5.2 Hydraulic fluid ·····		Р	29
5.3 Operation of the ASE pump unit		Ρ	30-31
6. Operation adjustment			
6.1 Display and operation buttons		Ρ	32
6.2 Communication cable ······		Ρ	33
6.3 Display transitions		Ρ	34
6.4 Display items		Р	35
6.5 Changing parameter settings ·····		Р	36
6.6 Parameters		Р	37-40
6.7 Parameter functions		Р	41-57
7. Troubleshooting			
7.1 Error indication·····		Р	58-59
7.2 Measures against alarms (error indication)		P	60-64
7.2 Measures against alarms (error indication) 7.3 Measures against noise		P	65-66
8. Combination use			
8.1 Overview		Р	67
8.2 Simplified diagram of the hydraulic circuit and wiring		Р	67
8.3 Component setting for combination use		Р	68
8.4 Tools for setting			
8.5 Setting		P	70 ₋ 71
8.6 Changing parameters·····		ı D	70-71
8.7 Before commissioning·····		ı D	72_7/
8.8 Troubleshooting during combination use operation		ı D	75
8.9 Returning the settings for combination use to single use		r D	75 76
		Г	70
9. Maintenance		_	77
9.1 Contamination control of hydraulic fluid		2	77
9.3 Inspection of the AC servo motor		ר	1 1 70
9.3 Inspection of the AC servo motor		۲	/ ŏ
9.4 Guideline for replacing the AC servo motor components		۲	/ ŏ
9.5 Inspection of the Aiviola controller	•••••	۲	/ ŏ
9.6 Guideline for replacing the components of the AMSE controller		۲	/8
0. Storage of unused units		۲	/9 - 0
1. Disposal·····			
2. Customer service ·····		Ρ	79

1. Introduction

1.1 Intended users of the product

The product should be handled by users with adequate knowledge of electrics and hydraulics or under the supervision of such personnel.

1.2 Intended purpose

The product is a motor-driven pump unit for hydraulic equipment. It generates and supplies hydraulic pressure, mainly as a hydraulic power source for hydraulic equipment.

1.3 Product check

Check the following points upon delivery of the product.

If there are any questions or problems, please contact the place of purchase or our local customer support.

- Check if the model is correct.

 Check the model number marked on the nameplate (refer to "2.4 Model number designation").
- Check for any damage to the product and/or loose screws.




Fig. 1.3a Product Check

2. About the product

2.1 Basic structure and components




Fig. 2.1b ASE*-**-**B-B00-*




Fig. 2.1c AMSE-**-B00-* (Attached)

Fig. 2.1d Regenerative Resistor (Attached)

2.2 Basic system configuration

The product is a compact, energy-saving, low-noise hydraulic device comprised of an AC servo motor and a piston pump. This unit can be combined with the dedicated controller to facilitate the configuration of a speed and pressure control system.




Fig. 2.2a Basic System Configuration

2.3 Control system

The control system provides the variable control of pump discharge pressure and flow by controlling the AC servo motor speed according to externally input pressure and flow commands. Pressure control is based on closed-loop control with the feedback of signals from the built in pressure sensor the pump unit.




Fig. 2.3a Control System

2.4 Model number designation

2.4.1 ASE model




Fig. 2.4a Model Number Designation for ASE

2.4.2 Components

Table 2.4a Combination of Components

	Model	AMSE Controller Model	Brake Unit	Regenerative Resistor Model		
1	ASE3-4AA-G80*-BOO-10	SE3-4AA-G80*-BOO-10 AMSE-4AE-B00-10		FR-ABR-H15K (indicated on the package) FR-ABR-15K (indicated on the body)		
	ASE5-4BZ-G130*-B00-20	AMSE-4BB-B00-11		FR-ABR-H11K-03 2 pieces		
•	ASE10-4CE-G200*-B00-20	AMSE-4DE-B00-10	FR-BU2-H30K-04	FR- ABR-H11K-03 3 pieces		

2.5 Specifications

Table 2.5a Specifications

	Model			ASE3-4AA-G80*-	ASE5-4BZ-G130*-	ASE10-4CE-G200*-		
<u></u>	Max. Flow L/min			80.8	132.7	205.4		
Flow Control		Hystere	esis		1 % or less			
<u> </u>	F	Repeatal	bility		1 % or less			
프	Input	Signal \	/oltage *1	0 to 6.25 V	0 to 5.75 V	0 to 5.00V		
_	Pres. /	Adj. Ran	ige MPa		0.1 to 17.5			
Control		Hystere	esis	1 % or less *2				
	F	Repeatal	bility	1 % or less *2				
Pres.	Input	Signal V	oltage *1	0 to 5.0 V				
	At	mosphe	re	Indoors (no direct sunlight) No corrosive gas, flammable gas, oil mist, or dust.				
Altitude				1000 m or less above sea level				
Sto	orage	Ambier	nt Temp.	0 to 40 °C (no freezing)				
	*3	Ambient	Humidity	80 %RH or less (no condensation)				

^{*1} Default value (allowable maximum input signal voltage: up to 10 V).

Table 2.5b ASE (Pump) Specifications

Model	ASE*-**-
Operating Pres.	0.1 to 17.5 MPa
Rotational Direction	Clockwise when viewed from the servo motor
Hydraulic Fluid	Petroleum based fluid equivalent to ISO VG32 or 46
Viscosity	20 to 400 mm ² /s
Fluid Temp.	0 to 60 °C

Table 2.5c AC Servo Motor Specifications

Model		ASE*-**-		
Insulation Class		Class F		
Cooling System		Totally-enclosed forced-cooling		
ental	Protection	IP44 (except for the shaft through portion)		
Environmental Condition	Ambient Temp.	0 to 40 °C (no freezing)		
Envi	Ambient Humidity	80 %RH or less (no condensation)		
Fan Power Voltage/Frequency		Single-phase, AC 180 to 220 V, 50/60 Hz		

^{*2} Pressure control accuracy depends on system tuning; this value is for reference.

^{*3} The storage temperature is different from the ambient temperature during operation.

Table 2.5d AMSE Controller Specifications


	Мс	odel	AMSE-4AE-	AMSE-4BB-	AMSE-4DE-		
<u>_</u>	Voltag	је	3-pha	ase, AC 380 to 480 V			
Main Circuit Power	Permi	ssible Voltage	3-phase, AC 323 to 528 V				
Circ	Frequ	ency		50 Hz/60 Hz			
Main	Permi Fluctu	ssible Frequency		± 5 % or less			
	Comn	nand Signal Input ge	0 to 10 V DC (Pressure/flow comman	d input)		
Φ	Comn	nand Signal Input dance	10 kΩ				
Interface	Monite	or Output Voltage	1ch. 0 to 10 V DC (The output can be changed by parameters.)				
<u>=</u>	Sequence Input Signal		12chs. Photocoupler input (current limiting resistance: 4.7 KΩ) Power voltage: DC 21 to 27 V, short-circuited current: 4 to 6 mA				
	Seque	ence Output	2chs. Relay output (contact capacity: AC 230 or DC 30 V, 0.3 A)				
	Signa	I	5chs. Open collector output (permissible load: DC 24 V, 0.1 A)				
Cooling S	system		Forced fan cooling, enclosed (IP20)				
Environm	ental	Ambient Temp.	0 to	50 °C (no freezing)			
Condition		Ambient Humidity	90 %RH or less (no condensation)				
Protective Functions			□Overcurrent □Regenerat □Motor overload □Fin ove □Undervoltage □Input ope □Stall prevention □Ground □Communication option err □CPU error □Operation p □DC 24 power output short □Analog input error □Fan □Dynamic brake pre-alarm □Parameter write error □C □Parameter copy alarm □ □USB communication error □Maintenance signal outpu □Hydraulic control board was	erheat □Instantaneous pren-phase □Output opend fault overcurrent on the or □Parameter memory anel power short circuit □Inrush current I fault □Electronic therma□PU stop □Brake tran Copy operation error □O Communication error □Internal circuit error t □Error □Hydraulic co	ower failure -phase output side device error imiting circuit error al pre-alarm sistor error peration panel lock		

Table 2.5e Facilities

Model	ASE3-4AA-	ASE5-4BZ-	ASE10-4CE-
Power Capacity	27 kVA	41 kVA	80 kVA
Current Breaker	100 A frame/60 A	100 A frame/100 A	225 A frame/175 A
Electromagnetic Switch	N25	N30	N80

2.6 External dimensions and mass

Table 2.6a Dimensions and Mass of the Motor-Driven Pump




Model		Α	В	С	D	Е	Ф	Mass kg
ASE3-4AA-G80	S-	228	284	559	194	352.5	• Ф14	85
	B-	275	269					
ASE5-4BZ-G130	S-	268	326	664	220	407.5		116
	B-	295						110
ASE10-4CE-G200	S-	240	402	991	206	621	ф22	106
	B-	340	402	991	296	021	Ф22	196

Unit (ABCDEΦ): mm

MEMO


Table 2.6b Dimensions and Mass of the AMSE Controller and Regenerative Resistor



AMSE Controller

Model	А	В	С	D	E	Ф	Mass kg
AMSE-4AE-	300	220	190	285	195	Ф6	7.5
AMSE-4BB-	400	250	190	380	230	Ф10	13.0
AMSE-4DE-	550	435	250	525	380	Ф12	35.0


Unit (ABCDEΦ): mm



Regenerative Resistor

Regenerative Resistor	F	G	Н	ı	J	К	Ф	Mass kg
FR-ABR-15K (435W-18Ω/piece)	100	300	700	50	90 F	285	- Ф5.3	2.2/piece
FR-ABR-H11K-03 (530W-52Ω/piece)		400	700	50	80.5	385		3.2/piece

Unit (FGHIJKΦ): mm




Unit: mm

*ASE10-4CE (Attached)

2.7 Interface

2.7.1 Parts of the AMSE controller (with the cover installed)



2.7.2 Removal of the AMSE controller cover

Note) It is dangerous to remove the cover with the controller powered on. Double-check that the controller power is turned off. Before starting wiring work, remove the cover in the following steps. When mounting the cover, take the reverse steps.




Fig. 2.7b Removal of the Cover

2.7.3 Parts of the AMSE controller (internal parts)




Fig. 2.7c Parts of the AMSE Controller

2.7.4 Control circuit terminals

Table 2.7a Sequence Input

Туре	Symbol	Name	Function/Use	Rating
	STF	Forward Rotation Start (Servo-on)	"ON": Forward rotation command "OFF": Stop command	
	STR	Reverse Rotation Start	<not used.=""> "ON": Reverse rotation command "OFF": Stop command</not>	
	STOP	Reserved	Disabled.	Input
			Switches the gain according to the load condition variable for each process.	resistance: 4.7 KΩ
	RH	RH Control Code x 1	Input Signal Control Code	Open-circuit voltage:
			OFF OFF No. 0 control parameter	DC 21 to 27 V
	RM		ON OFF No. 1 control parameter	
Contact Input			OFF ON No. 2 control parameter ON ON No. 3 control parameter	Short-circuit
t In				voltage:
tact	JOG	Reserved	Disabled.	DC 4 to 6 mA
out	RT	Reserved	Disabled.	
O	MRS	Emergency Stop	"OFF": Emergency stop "ON": Emergency stop reset	
	RES	Reset	Resets an alarm.	
	ΑU	Reserved	Disabled.	
	CS	Reserved	Disabled.	
	SD	Contact Input Common	Common terminal for contact input terminals. Note) This terminal is insulated from Terminals "5" and "SE."	1
	PC	DC 24 V Power Output	This terminal can be used to supply DC 24 V, 0.1 A power.	Power voltage range: DC 20 to 28 V Permissible load current: 100 mA




Fig. 2.7d Simplified Wiring Diagram

Table 2.7b Analogue I/O

Typo		Analogue I/O	Function/Use Rating						
Type	Symbol	Name		rundion/ose		Rating			
	10E	DC 10 V Power Output	This terminal can be used to supply DC 10 V, 10 mA power.			DC 10 ± 0.4 V Permissible load current: 10mA DC 5.2 ± 0.2 V			
	10	DC 5 V Power Output		This terminal can be used to supply DC 5 V, 10 mA power. A voltage of DC 0 to + 5 V (max. 10 V) is applied between Terminals "2" and "5." The span of the command voltage is set by the parameter below. Parameter No. Rated Pressure P460 Default: 175 [× 0.1 MPa/5 V] * See "Table 6.7n" for setting.					
	2	Pressure Command Voltage	between command Parame P40 * See "Tal						
Flow/Pressure Setting	4	Flow Command Voltage	between command	A voltage of DC 0 to + 5 V (max. 10 V) is applied between Terminals "4" and "5." The span of the command voltage is set by the parameter below. Parameter No. Rated Flow Rate P461 Default: 2000 [rpm/5 V] * See "Table 6.7n" for setting.					
ow/Pr	5	Control Common	Common monitoring	terminal for command vg voltage.	voltage and	-			
正	1	Reserved	Not used.	Do not connect wires.		-			
	AM	General Monitor	Selects at The setti Output Ite output of Setting 0 1 2 3 4 5	Output signal: DC 0 to 10 V Permissible load current: 1 mA Load impedance: 10 kΩ or more Resolution: 8 bits					

Table 2.7c Error Output

	Table 2.76 Error Output						
Type	Symbol	Name	Function/Use	Rating			
	A1	Warning Output					
		- Contact B	controller's warning function is activated.				
Ħ	B1	Warning Output	Warning: Electrical continuity between B and C				
욕	_ D1	 Contact A 	(Electrical discontinuity between A and C)	Contact			
ರ	C1	Warning Output	Normal: Electrical discontinuity between B and C				
헐	ਰ Common		(Electrical continuity between A and C)	capacity: AC 230 V,			
nta	B1 Varning Output - Contact A C1 Warning Output - Common Alarm Output - Contact B		This contact output indicates that the AMSE	0.3 A			
၂ က			controller's alarm function is activated to stop the	DC 30 V,			
<u> </u>	B2 Alarm Output -		output.	0.3 A			
Relay	Contact A		Warning: Electrical continuity between B and C	0.57			
<u> </u>	C2	Alarm Output - Common	(Electrical discontinuity between A and C) Normal: Electrical discontinuity between B and C (Electrical continuity between A and C)				

Table 2.7d Sequence Output

Type	Symbol	Name				-unction/Use	Rating
	RUN	Operation Ready				STF/STR is "on" and the unit is flow/pressure command.	
	0L	Swash Plate Angle Large	Not use				
	IPF	Alarm Code - 0	Outputs	s a 3			
	SU	Alarm Code - 1				oller's protection function is	
						ne output.	
				Output Terminal			
				ymbo SU	IPF	Description	
or Output			OFF (OFF	OFF	□ Parameter memory device error □ CPU error □ Inrush current limiting circuit error □ Analogue input error □ Option error □ Communication error □ Internal circuit error □ DC 24 power output short circuit □ Operation panel power	Permissible load: DC 24 V, 0.1 A (max. DC 27 V)
Open Collector Output	FU	Alarm Code - 2				short circuit □ USB communication error □ Hydraulic control board error	* Max. voltage drop with "on": 2.8 V
			OFF (OFF	ON	□ Regenerative overvoltage□ Brake transistor error detection	
			OFF	ON	OFF	□ Undervoltage□ Instantaneous power failure	
			OFF	ON	ON	 □ AMSE controller overload □ Motor overload □ Fin overheat □ Stall prevention 	
			ON C	OFF	OFF	□ Overcurrent □ Ground fault overcurrent on the output side	
				ON	ON	□ Input open-phase □ Output open-phase □ PU disconnection	
	SE	Open Collector		on te	rminal	s for RUN, OL, IPF, SU, and	-
		Output Common	FU.				

Table 2.7e Others

Туре	Symbol	Name	Function/Use		Rating
	FM	-	Not used.	Do not connect wires.	-

2.7.5 Sensor terminals

Table 2.7f Pressure Sensor/Thermistor Terminals

Type	Symbol	Name	Function/Use
nal	1 Pressure Sensor Power Supply		Supplies DC 4.9 to 5.2 V power to the pressure sensor.
Terminal	2	Pressure Sensor Input	Receives the output voltage of the pressure sensor. (0.5 to 4.5 V = 0 to 35 MPa)
0/1 e	3	Pressure Sensor Common	Common terminal for the pressure sensor.
gr	4	Pressure Sensor Shield	Wiring for a measure against radiated noise.
Analogue	5	Thermistor Input - 1	Receives the output voltage of the sensor for monitoring the
μ	6	Thermistor Input - 2	motor's internal temperature.
	7	Reserved	


2.7.6 Main circuit terminals

Table 2.7g Main Circuit Terminals

Type	Symbol	Name	Function/Use
ole	R/L1 S/L2 T/L3	AC Power Input	Connects to a commercial power supply (3-phase AC 380 to 480 V).
Power Cable	V W	Motor Output	Connects to the motor. Note) Match the U, V, and W phases for cable connection.
	N/-	Not connected	Connection is not required.
ge	P1	Not connected	Short-circuited to P/+. Do not remove the short bar.
Voltage	P/+	Regenerative Resistor Connection	Connects to the attached regenerative resistor. * The wiring method (series or parallel) varies depending
High	PR	Regenerative Resistor Connection	on the models.
		Ground	Be sure to connect the ground wire.

2.7.7 Control power terminals

The main circuit terminals R/L1 and S/L2 are internally connected with R1/L11 and S1/L21 (control power terminals in the lower low). By default, the lower terminal block is connected with the upper terminal block (control power terminals) via short bars; the control power is turned on at the same time as the main circuit power is turned on. To keep the control power active at the time of error detection, remove both short bars (shown below) and provide the control power separately.



3. Installation of the ASE pump unit

3.1 Tools for installation

Following tools required.

Table 3.1a Tool for Pump Installation

Model	Tool (Size)
ASE3/5-	Wrench (width across flats: 19 mm)
ASE10-	Wrench (width across flats: 22 mm)

Table 3.1b Tool for Suction Pipe Flange Connection

Model	Tool (Size)	
ASE3/5/10-	Allen wrench (width across flats: 10 mm)	

Table 3.1c Tool for Discharge Pipe Flange Connection

Model	Tool (Size)	
ASE3/5/10-	Allen wrench (width across flats: 8 mm)	

Table 3.1d Filling Port

Model	Tool (Size)	
ASE3/5/10-	Wrench (width across flats: 22 mm)	

3.2 Relocation Moving pump unit

Take great care not to drop, knock over, or damage the product during transport.



- Never lift or carry the product in an incorrect posture. Hand pain or backache may occur depending on the product mass or the posture of the worker.
- Do not step on or put any heavy object on the product. Doing so may result in damage to the product/equipment or injury from slipping/falling.

- 3.3 Preparation for installation
- a) Before starting installation work, clean and dust the working area, hands, and clothing to prevent foreign matter from entering the product/equipment.
- b) Remove the protective plug from the port and the protective plates from the port flange mounting surface. When removing the plates, be careful not to damage the mounting surface.




Fig. 3.3a Removal of the Protective Plug and Plates

c) Check for critical scratches on the O-ring sealing surface of each port and the port flange mounting surface. If a scratch is found, eliminate it by repairing the mounting surface. If a critical scratch that cannot be mended is found, contact our customer support.



- Any critical scratch on the mounting surface oil leakage, resulting in an accident.
- d) Clean the O-ring sealing surface of each port and the port flange mounting surface to ensure that there is no foreign matter, such as metal debris and waste cloth lint.
- e) Check for critical scratches on the O-ring mounting surface of the pipe flange and check that the O-ring is properly mounted in the groove. If required, mount it in the groove correctly.




 Improper mounting of the O-rings may cause damage to them or leakage of hydraulic fluid, resulting in an accident.

3.4 Installation of the ASE pump unit

3.4.1 Installation position

- Install the unit with the filling port facing upward.
- Bolt the unit securely using the mounting holes on the bracket.



: Bolt/plain washer location

Fig. 3.4a Installation Example

3.4.2 Bolting

Screw in the bolts listed below gradually and evenly. Note) Use the washers to prevent the bolts from loosening.

Table 3.4a Bolt Size and Tightening Torque

Model	Bolt Size	Quantity	Tightening Torque N•m
ASE3/5-	JIS B1180 Hexagon Head Bolt M12 (Strength Grade: 6.8)	4	50 to 55
ASE10-	JIS B1180 Hexagon Head Bolt M20 (Strength Grade: 6.8)	4	232 to 256

M WARNING

 Use the specified number of bolts of the same material/strength grade and apply the specified tightening torque. Failure to do so may cause damage to the bolts or leakage of hydraulic fluid, resulting in an accident.

3.5 Piping

3.5.1 Drain piping

- For piping, see the table below.
- Be sure that the pipe end is submerged in fluid.
- Do not join the drain pipe to other return lines. Run it independently.

Table 3.5a Drain Pipe Size

Model	Joint Size	Pipe Bore	Pipe Length
ASE3/5-	1/2 (Bore: Ф12 or more)	Ф12 or more	
ASE10-	3/4 (Bore: Ф19 or more)	Ф19 or more	1000 mm or less

Even when the condition above is met, install the piping in such a way that the constant pressure in the housing is less than 0.1 MPa.

3.5.2 Suction piping

- For suction piping, use pipes of the following sizes.

Table 3.5b Suction Pipe Size

Model	Nominal Diameter
ASE3-	1 1/4
ASE5-	1 1/2
ASE10-	2 1/2

- Suction port should be less than 1 m above fluid level.
- If the pump is installed higher than the fluid level, the suction pipe filter at and piping should not be higher than the pump port to prevent air accumulation in the suction line.
- Keep the suction pressure at the pump inlet between 16.7 kPa and + 50 kPa.
 When the suction pressure exceeds the prescribed value, abnormal noise/vibration may occur.

MEMO	

3.5.3 Pipe tightening

The pipe tightening torque is shown in Table 3.5c.



WARNING

Apply the pipe tightening torque as specified. Failure to do so may cause damage to screws or leakage of hydraulic fluid, resulting in an accident.

Table 3.5c Screw Size and Tightening Torque

	Model	Screw Size	Tightening Torque
Discharge Pipe ASE3/5/10-		Port Flange Screw: JIS B1176 Hexagon Socket Head Cap Screw M10 (Strength Grade: 12.9)	61 to 74
Suction Pipe	ASE3/5/10-	Port Flange Screw: JIS B1176 Hexagon Socket Head Cap Screw M12 (Strength Grade: 12.9)	104 to 127
Drain Pipe	ASE3/5-	Rc1/2	52 to 95
Diaili Fipe	ASE10-	Rc3/4	90 to 165

When using four screws for the suction pipe flange, tighten them gradually and evenly in the order shown by the numbers 1 to 4 in Fig. 3.5a and repeat this cycle two or three times.




Fig. 3.5a Screw Tightening



◆ Do not tighten the screws with the O-rings mounted improperly. Doing so may cause damage to the O-rings or leakage of hydraulic fluid, resulting in an accident.

When using steel pipes, they may place excessive load on the motor-driven pump unit, resulting in noise. If this is a possibility, use rubber hoses.

4. Installation of the AMSE controller

4.1 Preparation for installation



- ◆ The AMSE controller is fan-cooled. Be sure to observe the following installation standards and pay attention to the circulation to air circulation.
- 4.1.1 Installation standards (the values below indicate minimum clearances.)




Fig. 4.1a Installation Standards

4.1.2 Installation orientation

Install the AMSE controller vertically on the wall with its front face (with the operator panel) facing toward the operator.

4.1.3 Cooling

With reference to Fig. 4.1a, leave enough space around the AMSE controller to allow fan cooling and natural convection.

The cooling fan is required to keep the temperature in the control panel uniform so that the local AMSE ambient temperature controller does not increase.

4.1.4 Environmental condition in the control panel

Ambient temperature around the AMSE controller: 0 to 50 °C

Humidity: 90 %RH (relative humidity) or less


Vibration: 5.9 m/s² or less

No freezing or condensation is permitted. Operation at an ambient temperature of 45 °C or less is recommended to ensure long term operational reliability.

- 4.1.5 Installation of regenerative resistors
- * Double-check the model and quantity of regenerative resistors prior to installation.
- * Be sure to use all regenerative resistors supplied with the unit.
- * Regenerative resistors may get very hot. Use heat-resistant and fireproof wires do not let them touch the resistors.
- * If the regeneration capacity exceeds the standard specification level is required, regenerative resistors must be changed. Consult us separately.
- * Pay attention to the installation standards below (Fig. 4.1b).

Table 4.1a Regenerative Resistor

Applicable Model	Regenerative Indicated on the package	Resistor Model Indicated on the body	Capacity W	Mass kg	Supplied Quantity
AMSE-4AE-	FR-ABR-H15K	FR-ABR-15K	435/piece	2.2/piece	2
AMSE-4BB-	FR-ABR-H11K-03		530/piece	3.2/piece	2
AMSE-4DE-			550/piece	3.2/piece	3






Fig. 4.1b Regenerative Resistor Installation Standards




Fig. 4.1c Brake Unit Installation Standards(ASE10-4CE (Attached))




Fig. 4.2a Wiring Diagram

4.3 Wiring of regenerative resistors




Fig. 4.3a Wiring Diagram of Regenerative Resistors

4.4 Wiring type

Table 4.4a Main Circuit Terminal Wiring Types

		Main Circuit Terminal Block			
AMSE-	Item	AC Power Input (R/L1, S/L2, T/L3)	Motor Output (U, V, W)	Ground Wire	Regenerative Resistor (P/+,N/-, PR)
	Wire (mm²)	8 (AWG8)			2.1 (AWG14)
4AE	Screw Size		M5		
	Tightening Torque		2.5 N•m		
	Wire (mm ²)	14	(AWG6)		2.1 (AWG14)
4BB	Screw Size	M6			
	Tightening Torque	4.4 N•m			
	Wire (mm ²)	38 (AWG1)	38 (AV	VG2)	3.5 (AWG12)
4DE	Screw Size			M8	
	Tightening Torque	7.8 N•m			
ED 0110	Wire (mm ²)			3.5 (AWG12)	
FR-BU2-	Screw Size			M4	
H30K-04	Tightening Torque			1.5 N•m	

Table 4.4b Control Circuit Terminal/Sensor Terminal Wiring Typ

	Item	Control Circuit Terminal Block	Sensor Terminal Block
	Wire (mm ²)	0.75 to 2.1 (AWG18 to 14)	0.5 to 1.3 (AWG20 to 16)
AMSE-	Screw Size	M3.5	Push lock type
AIVIOL-	Tightening Torque	1.2 N•m	-

MEMO 		

5. Preparation for operation

5.1 Operating environment

Use the product as a hydraulic power source for hydraulic equipment.

Operate it under the conditions below. Operation in other conditions may result in malfunction.

- Installation location: Indoor environment free of combustible/corrosive/flammable gas or mist that meets the following requirements.
 - Ambient environment: See Sections 2.5 (Specifications), 3 (Installation of the ASE pump unit), and 4 (Installation of the AMSE controller).
 - No obstruction that may prevent ventilation or make the nameplate invisible.
 - The product is not waterproof and must not be used in water.



♦ Never use the product in an explosive atmosphere, including locations where flammable gases or explosives are handled. Doing so may result in fire, explosion, or any other serious and fatal accident.

5.2 Hydraulic fluid



CAUTION

♦ Use proper hydraulic fluid within the specified ranges of fluid temperature, viscosity, and contamination level. Failure to do so may result in malfunction leakage, causing fire.

5.2.1 Fluid type

- Petroleum based hydraulic fluid: Use a hydraulic fluid equivalent to ISO VG32 or 46.
 - Note) To use a hydraulic fluid other than petroleum based one (synthetic fluid, water based fluid, etc.), consult us separately.

5.2.2 Fluid viscosity and temperature during operation

Viscosity: 20 to 400 mm²/s Fluid temperature: 0 to 60 °C

5.2.3 Prevention of foreign matter invasion

Foreign matter entering hydraulic fluid may result in a shorter service life or failure of the pump. Always keep the fluid clean (contamination level: JIS B9933 (ISO 4406) 20/18/14 or NAS 9 or better).

5.3 Operation of the ASE pump unit



- ♦ always check piping before starting the motor-driven pump unit. Failure to do so may cause damage to the parts or leakage of hydraulic fluid, resulting in an accident.
- ♦ When any abnormal condition (noise, fluid leakage, smoke, etc.) occurs, immediately stop operation and take appropriate measures. Continuing the operation under such conditions may result in an accident.

CAUTION

- ♦ Use the product as specified in the catalogue, drawings, and specifications. Failure to do so may result in malfunction or damage to the product, causing injury.
- ♦ Perform adjustment work while ensuring safety, e.g. keeping people away from the moving parts of equipment.
- Note) Do not join the drain line to other return lines. Doing so may result in malfunction or failure.
 - Long-time operation with reverse rotation may cause damage and the pump to sieze.
 - Do not increase the pressure setting before the unit starts normal operation. Doing so may result in pressure oscillation or abnormal noise.

MEMO

5.3.1 Initial operation



- ♦ Upon initial operation, check in advance that the hydraulic circuit and electric wiring have been correctly installed and that there are no loose parts.
- a) Pour clean hydraulic fluid through the filling port into the pump. Failure to do so may cause damage or seizure of parts.

Table 5.3a Fluid Filling Quantity for Each Model

Model	Filling	
	Quantity	
ASE3-4AA-	600 cm ³	
ASE5-4BZ-	OUU CIII	
ASE5-4CE-	900 cm ³	




Fig. 5.3a Hydraulic Fluid Filling

- b) Adjust the control valves so that the pump discharge fluid circulates directly into the tank so that the actuator runs with no load.
 - Note) Do not start the pump with its discharge blocked.
- c) Operate the pump under the following recommended conditions and check the points below.
 - <Power-on procedure>

Start and run the ASE pump unit as follows.

Turn "on" the main circuit power and wait three seconds -> Turn "on" the servo ("on" between the terminals STF and SD).

• To avoid malfunction, wait more than three seconds after turning on the main circuit power to turn servo on.

Always follow specified procedures to avoid harm to yourself or others.

<Recommended operating conditions>

Motor speed: 1000 r/min or less

Pressure: 5 MPa or less

<Check items>

Check if the pump sucks fluid normally.

Be aware that the motor may rotate in the reverse direction due to wrong wiring of the U, V, and W phases between the AMSE controller and the motor.

d) After checking that there is no problem in Step c), perform the test run and air-bleed the system.
 Note) Upon pump startup, air enters hydraulic fluid and causes noise, but this phenomenon is not an indication of failure. If the noise persists, air-bleed the circuit.

6. Operation adjustment

Setting

Confirmation

Alarm Reset

SET

STOP/RESET

6.1 Display and operation buttons

The AMSE controller allows status display and parameter setting for the ASE pump unit. It has a 4-digit LED display for checking output and parameters.




Fig. 6.1a Display and Operation Buttons

"STOP" (Motor Stop) is enabled.

display as follows.

Resets alarms.

Pressing this button during operation switches the monitor

When the setting of the setting parameter "P_75" is changed,

"Motor Speed" -> "Output Current" -> "Output Voltage"

- 6.2 Communication cable <for setup by the manufacturer>
 - "USB2.0 Cable (Type AB)" is used as a communication cable.
 - For the ASE pump unit, monitoring and parameter adjustment can be done by using ASE-dedicated software. Manual parameter adjustment is unnecessary.





Fig. 6.2a Communication Cable Port



6.3 Display transitions

- At the time of power-on, the display appears as shown in Fig. 6.3a.




Fig. 6.3b Display Transition Chart

6.4 Display items

Table 6.4a Display Items

Note) "*" represents a number, and "□" represents a code.

Code	Name	Description	Reference	
P***	Setting Parameters	Changes settings.	Tables 6.6a to c: Setting Parameters	
C_**	Calibration Parameters	Calibrates signals.	Table 6.6d: Setting Parameters	
Pr.CL	Parameter Clear	Initializes a parameter.		
ALLC	All Parameter Clear	Initializes all parameters.		
Er.CL	<alarm clear=""> (Manufacturer-controlled)</alarm>	<pre><alarm clear="" history=""> (manufacturer-controlled).</alarm></pre>	Table 6.6c: Setting Parameters	
PCPY	Parameter Copy	Copies setting parameter data when using multiple AMSE controllers.	, and the second	
E.000	Alarms	Error detection.	Table 7.1a: Alarm Codes	
OL	Stall Prevention (Overcurrent)			
Rb	Dynamic Brake Pre-alarm			
ГН	Electronic Thermal Pre-alarm PU Stop Warnings.		Table 7.1b: Warnings	
PS			_	
СР	Parameter Copy			
Fn	Fan Fault			
οΡ	Hydraulic Control Board Warning			
HOLD	Operation Panel Lock			
Er*	Warnings	Operation errors.	Table 7.1c:	
rE * Err	Error Messages	Operation ends.	Error Messages	
P5	Operation Panel Command Stopped	Indicates that operation has been stopped by the "STOP/RESET" button on the operation panel.	Table 7.1d:	
ЕПС	Emergency Stop	Indicates that operation has been stopped by the emergency stop procedure.	Status Display	

MEMO 		

6.5 Changing parameter settings

1) Turn on the power (the motor speed is displayed).



- 2) Enable the parameter setting mode.
 - A) Press the "MODE" button.



B) Check that "P" appears on the monitor.




If "P" is not displayed, turn the "M Dial" until "P" appears.

C) Turn the "M Dial" to display the target parameter No, and then press the "SET" button. The current set value is displayed.



D) Turn the "M Dial" to change the value, and then press the "SET" button. The parameter No. and the set value are displayed alternately to indicate that the setting has been confirmed.



E) Press the "MODE" button twice to return to the initial display.

6.6 Parameters

Note) Never change the settings of manufacturer-controlled parameters.

Table 6.6a Setting Parameters "P***"

No.	Name	Setting Range	Minimum Setting Unit	Default	Reference
P 1	Upper Limit Frequency	0 to 3000 r/min	1 r/min	(Depends on the model)	
P 2	Manufacturer-controlled	-	-	0	
P 7	Acceleration Time	0 to 15 s	0.01 s	0.04	
P 8	Deceleration Time	0 to 15 s	0.01 s	0.04	
P 9	Manufacturer-controlled	-	-	(Depends on the model)	Table 6.7a
P 10	Manufacturer-controlled	_	-	8	
P 13	Manufacturer-controlled	-	-	0	
P 17	MRS Input Selection	0, 2	1	2	
P 20	Manufacturer-controlled	-	-	1500	
P 22	Manufacturer-controlled	-	-	200.0	
P 30	Manufacturer-controlled	_	-	1	
P 52	DU/PU Main Display Data Selection	0, 5 to 14, 17, 20, 23, 25, 55, 81 to 86, 100	1	0	Table 6.7b
P 54	Manufacturer-controlled	-	-	1	
P 55	Manufacturer-controlled	-	_	2250	
				(Depends on	
P 56	Manufacturer-controlled	-	-	the model)	
P 70	Manufacturer-controlled	-	-	6.0	
P 71	Manufacturer-controlled	_	-	150	
P 72	Manufacturer-controlled	-	_	6	
	Reset/PU Disconnection/PU				Table 6.7c
P 75	Stop Selection	0 to 3, 14 to 17	1	1	
P 77	Parameter Write Selection	0, 1, 2	1	2	
P 79	Manufacturer-controlled	-	-	2	
P 80	Manufacturer-controlled	-	-	(Depends on the model)	
P 81	Manufacturer-controlled	_	_	8	
P144	Manufacturer-controlled	_	-	108	
P145	Manufacturer-controlled	-	_	0	
	Button Lock Operation				
P161 P168	Selection	0, 1, 10, 11	1	10	Table 6.7d
P169	- (Read	-only, write-protected)			
P240	Manufacturer-controlled	1	_	0	
	Cooling Fan Operation	-		U	
P244	Selection	0, 1	1	1	
P251	Manufacturer-controlled	- (0.1.45)	-	1	
P255	Life Warning Status Display	(0 to 15), read-only	1	0	
P256	Inrush Current Limiting Circuit Life Display	(0 to 100), read-only	1 %	100	
P257	Control Circuit Capacitor Life Display	(0 to 100), read-only	1 %	100	
P258	Main Circuit Capacitor Life Display	(0 to 100), read-only	1 %	100	
P259	Main Circuit Capacitor Life Measurement	0, 1 (2, 3, 8, 9)	1	0	Table 6.7e
P331	Manufacturer-controlled	-	-	0	
P332	Manufacturer-controlled	-	-	96	
P333	Manufacturer-controlled	-	-	1	
P334	Manufacturer-controlled	-	-	2	
P335	Manufacturer-controlled	-	-	1	
P336	Manufacturer-controlled	-	-	0.0	
P337	Manufacturer-controlled	-	-	9999	
P338	Manufacturer-controlled	-	-	0	
P339	Manufacturer-controlled	-	-	0	
	1 11111				

Table 6.6b Setting Parameters "P***"

No.	Name	Setting Range	Minimum Setting Unit	Default	Reference
P340	Manufacturer-controlled	-	-	0	
P341	Manufacturer-controlled	-	-	1	-
P342	Manufacturer-controlled	-	-	0	1
P402	No. 0 Rise Time Gain	0 to 9999	1	1500	T.I. 0.71
P403	No. 0 Fall Time Gain	0 to 9999	1	1500	Table 6.7h
P404	No. 0 Lag Compensation	1 to 2000	1	70	
P405	No. 0 Lead Compensation	1 to 2000	1	60	Table 6.7i
	No. 0 Rise Time Pressure		-		
P406	Command Filter	1 to 2000	1	300	Table 6.7j
P407	No. 0 Fall Time Pressure Command Filter	1 to 2000	1	300	,
P408	No. 0 Pressure Response Sensitivity	1 to 2000	1	200	Table 6.7k
P409	No. 1 Rise Time Gain	0 to 9999	1	1500	
P410	No. 1 Fall Time Gain	0 to 9999	1	1500	Table 6.7h
P411	No. 1 Lag Compensation	1 to 2000	1	70	
P412	No. 1 Lead Compensation	1 to 2000	1	60	Table 6.7i
P413	No. 1 Rise Time Pressure		1		
F413	Command Filter No. 1 Fall Time Pressure	1 to 2000	'	300	Table 6.7j
P414	Command Filter	1 to 2000	1	300	
P415	No. 1 Pressure Response Sensitivity	1 to 2000	1	200	Table 6.7k
P416	No. 2 Rise Time Gain	0 to 9999	1	1500	T-1-1- 0 7'
P417	No. 2 Fall Time Gain	0 to 9999	1	1500	Table 6.7h
P418	No. 2 Lag Compensation	1 to 2000	1	70	
P419	No. 2 Lead Compensation	1 to 2000	1	60	Table 6.7i
P420	No. 2 Rise Time Pressure Command Filter	1 to 2000	1	300	
P421	No. 2 Fall Time Pressure	1 to 2000	1	300	Table 6.7j
P422	No. 2 Pressure Response	1 to 2000	1	200	Table 6.7k
	Sensitivity				10010 01111
P423	No. 3 Rise Time Gain	0 to 9999	1	1500	Table 6.7h
P424	No. 3 Fall Time Gain	0 to 9999	1	1500	10010 01111
P425	No. 3 Lag Compensation	1 to 2000	1	70	Table 6.7i
P426	No. 3 Lead Compensation	1 to 2000	1	60	10010 0.71
P427	N0. 3 Rise Time Pressure Command Filter	1 to 2000	1	300	Table 0.7:
P428	No. 3 Fall Time Pressure Command Filter	1 to 2000	1	300	Table 6.7j
P429	No. 3 Pressure Response	1 to 2000	1	200	Table 6.7k
P430	Sensitivity Manufacturer-controlled	-	-	0	-
P431	Manufacturer-controlled	-	-	0	-
P432	Manufacturer-controlled	-	-	0	-
P433	Manufacturer-controlled	-	-	0	-
P434	Manufacturer-controlled	-	_	0	-
P435	Manufacturer-controlled	-	_	0	_
P436	Manufacturer-controlled	-	_	0	_
P437	Pressure Response Gain	0 to 9999	1	300	
P438	Pressure Response Offset	0 to 9999	1	100	Table 6.7k
P439	Pressure Proportional Gain	0 to 9999	1	0	
P440	Pressure Feedforward Gain	0 to 9999	1	0	1
P441	Pressure Feedforward Filter	1 to 2000	1	1	Table 6.7I
P442	Pressure Feedforward Function Selection	0 to 3	1	0	
P443	Q-damping Gain	- 999 to 9999	1	0	
P444	Q-damping Filter	1 to 2000	1	1	1
P445	Manufacturer-controlled	-	-	0	Table 6.7m
P446	Manufacturer-controlled		_	0	
P447	Manufacturer-controlled	-		0	1
1 77/	Managarer-controlled	<u> </u>		U	ļ

Table 6.6c Setting Parameters "P***"

No.	Name	Setting Range	Minimum Setting Unit	Default	Reference
P448	Manufacturer-controlled	-	-	45	
P449	Number of Combined Units	1 to 16	1	1	Table 6.7m
P450	QIN Mini	0 to 1000	1 (0.1 %)	10	
P451	PIN Mini	0 to 1000	1 (0.1 %)	10	Table 6.7n
P452	Q-COMP	0 to 2000	1	1000	Table 6.7ft
P453	Manufacturer-controlled	-	-	0	-
P454	Flow Command Voltage (QIN) Span	0 to 9999	1 (0.001 %)	(1000)*	
P455	Flow Command Voltage (QIN) Zero	- 999 to 9999	1 (0.001 %)	(0)*	Table 6.7a
P456	Pressure Command Voltage (PIN) Span	0 to 9999	1 (0.001 %)	(1000)*	Table 6.7o
P457	Pressure Command Voltage (PIN) Zero	- 999 to 9999	1 (0.001 %)	(0)*	
P458	Pressure Sensor Voltage Span	0 to 9999	1 (0.001 %)	(1250)*	
P459	Pressure Sensor Voltage Zero	- 999 to 9999	1 mV	(500)*	Table 6.7p
P460	Rated Pressure	1 to 300	1 (0.1 MPa)	175	Table 0.7p
P461	Rated Motor Speed	1 to 2800	1 r/min	2000	
P462	Pressure Sensor Rated Value	1 to 400	1 (0.1 MPa)	350	
P463	AM Monitor Output Item Selection	0 to 99	1	3	Table 6.7q
P464	Manufacturer-controlled	-	-	0	
P488	Manufacturer-controlled	-	-	120.0	
P490	Manufacturer-controlled	-	-	15	
P491	Manufacturer-controlled	-	-	30	
P492	Manufacturer-controlled	-	-	100.0	
P493	Manufacturer-controlled	-	-	45	
P499	Manufacturer-controlled	-	-	0	
P547	Manufacturer-controlled	-	-	0	
P548	Manufacturer-controlled	-	-	9999	-
P800	Manufacturer-controlled	-	-	30	
P818	Manufacturer-controlled	-	-	2	
P819	Manufacturer-controlled	-	-	0	
P820	Manufacturer-controlled	-	-	60	
P821	Manufacturer-controlled	-	-	0.050	
P828	Manufacturer-controlled	-	-	150	
P862	Manufacturer-controlled	-	-	0	
P863	Manufacturer-controlled	-	-	0	
P866	Manufacturer-controlled	-	-	200.0	
P867	Manufacturer-controlled	-	-	0.01	
P872	Manufacturer-controlled	-	-	1	
P877	Manufacturer-controlled	-	-	2	
P879	Manufacturer-controlled	-	-	150.0	
P880	Manufacturer-controlled	-	-	0.3	Table 6.7s
P989	Manufacturer-controlled	-	-	10	
P990	Manufacturer-controlled	-	-	1	
P991	Manufacturer-controlled	-	-	58	
C	Calibration Parameters	Pressing the "SET" button displa	ays the parameters in	"Table 6.6d."	
PrCL	Parameter Clear	0, 1	1	0	
ALLC	All Parameter Clear	0, 1	1	0	
ErCL	Manufacturer-controlled	-	-	0	
PCPY	Parameter Copy	0, 1, 2, 3	1	0	Table 6.7t

^{*)} Default values set by YUKEN. The values differ depending on the ASE model. The values in parentheses are reference values.

Table 6.6d Setting Parameters "C_**"

No.	Name	Setting Range	Minimum Setting Unit	Default	Reference
C_0	Manufacturer-controlled	-	-	1	
C_1	AM Terminal Calibration	-	-	1	
C_12	Manufacturer-controlled	-	-	0	
C_13	Manufacturer-controlled	-	-	0.0	Table 6.7v
C_14	Manufacturer-controlled	-	-	900	
C_15	Manufacturer-controlled	-	-	100.0 (0)*	

^{*)} By operating the "M Dial" with "0" displayed, the setting value ("100") can be seen.

МЕМО

6.7 Parameter functions

Table 6.7a Parameter Functions

No.	Name	Function/Use		Setting Range
		Sets the upper limit of motor output speed.		
		Model Default	See the	
P 1	Upper Limit Frequency	ASE3 3000	table on	0 to 3000 r/min
		ASE5 2500	the left.	
		ASE10 2200		
P 7	Acceleration Time	Sets motor acceleration time.	0.04	0 to 15 s
	7.000.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0.0	Note) Do not set this value to less than 0.04.	0.0.	0 10 10 0
P 8	Deceleration Time	Sets motor deceleration time.	0.04	0 to 15 s
		Note) Do not set this value to less than 0.04.		
		* The setting value differs depending on the model.		
		Model Default	See the	
P 9	Manufacturer-controlled	ASE3 26.50	table on	0 to 500 A
		ASE5 44.00	the left.	
		ASE10 75.00		
		Shuts off the output by a MRS signal.		
		Setting Value Description		
P 17	MRS Input Selection	0 Normally open input	2	0, 2
		2 Normally closed input (Contact b input)		
	I	<u> </u>	1	

MEMO

Table 6.7b Parameter Functions

No.	Name	Function/Use	Default	Setting Range
P 52	Operation Panel Display Data Selection	Selects a monitoring item to be displayed on the operation panel and a monitoring item to be output to the terminal FM. * See "Table 6.7b-1" below.	0/ (100)	0, 5 to 14, 17, 20, 23, 25, 55, 81 to 86, 100

Table 6.7b-1 Operation Panel Display Data Selection

Monitoring Item	Setting Value	Unit	Description
Output Voltage	0/100	V	Output voltage supplied to the motor side.
Rotation Command	5	1 r/min	Speed command.
Motor Speed	6	1 r/min	Motor speed.
Motor Torque	7	0.1 %	Torque value with the rated motor torque taken as 100 %.
Converter Output Voltage	8	0.1 V	DC bus voltage value.
Dynamic Brake Utilization	9	0.1 %	Rate of dynamic brake utilization set by the setting parameters "P_30" and "P_70."
Electronic Thermal Load Factor	10	0.1 %	Accumulative value of motor thermal load with the electronic thermal triggering level taken as 100 %.
Output Current Peak	11	0.1 A	Retains the peak value for output current monitoring (memory is reset every time the unit starts up).
Converter Output Voltage Peak	12	0.1 V	Retains the peak value of DC bus voltage (memory is reset every time the unit starts up).
Input Voltage	13	0.01 kW	Voltage on the AMSE controller input side.
Output Voltage	14	0.01 kW	Voltage on the AMSE controller output side.
Load Meter	17	0.1 %	Displays the torque current with the set value of "P_56" taken as 100 %.
Accumulative Power-on Time	20	1 h	Accumulates the power-on time (0.001 = 1h: the value returns to 0 h after reaching 65,535 h (max.)).
Actual Operating Time	23	1 h	Accumulates the operating time (0.001 = 1 h: the value returns to 0 h after reaching 65,535 h (max.).
Accumulative Power Consumption	25	0.01 kW	Displays the accumulative power consumption based on the monitored output voltage.
Input Terminal Status	55	ı	Displays the "ON/OFF" status of the control circuit input terminals on the operation panel. See "Fig. 6.7a" below for display details.
Output Terminal Status	33	-	Displays the "ON/OFF" status of the control circuit output terminals on the operation panel. See "Fig. 6.7a" below for display details.
Pressure Input Command	81	0.01 V	Pressure command voltage.
Flow Input Command	82	0.01 V	Flow command voltage
AM Terminal Output	83	0.01 V	Outputs an item selected by the setting parameter "P463."
Manufacturer-controlled	-	-	An output value is invalid.
Manufacturer-controlled	-	-	An output value is invalid.
Manufacturer-controlled	-	-	An output value is invalid.




Fig. 6.7a Status of Input/Output Terminals

Table 6.7c Parameter Functions

No.	Name		Fund		Default	Setting Range	
P 56	Manufacturer-controlled	* The setting va Model ASE3 ASE5 ASE10	Defau 26.50 44.00 75.00			See the table on the left.	0 to 500 A
P 75	Reset/ PU Disconnection/ PU Stop Selection	setting Regarder of Alwarder Allocations and Allocations and Allocations are setting as a setting and allocations are setting as a setting and allocations are setting as a setting are setting as	onnection (PU		operation panel and stop via the Stop via the STOP/RESET Button "STOP" is disabled. "STOP" is always enabled.	1	0 to 3, 14 to 17
P 77	Parameter Write Selection	This function ca overwritten by r Setting Range 0 Writ 1 Writ	sables write protection for parameters. on can be used to prevent the parameters from being by mistake. Description Writable only during stop. Write-protected. Writable regardless of the operation status.				0, 1, 2
P 80	Manufacturer-controlled	Model ASE3 ASE5	The setting value differs depending on the model. Model Default ASE3 11.00				0.40 to 55.00

Table 6.7d Parameter Functions

No.	Name			Function/Use	Default	Setting Range	
P161	Button Lock Operation Selection	Enabling the button on a operation. When butto operation properation properation properation properation seconds to setting	When button operation is disabled, "HOLd" is displayed on the operation panel. To enable button operation, press the "MODE" button for 2 seconds to cancel the button lock mode.			10	0, 1, 10, 11
		0	mo	s the M dial into the tor speed setting mode. s the M dial into the time mode.	Button lock disabled		
		10	mo	s the M dial into the tor speed setting mode s the M dial into the ume mode.	Button lock enabled		
		Controls th	е ор	eration of the cooling fan b	uilt in the inverter.		
		Setting Range		Descripti	ion		
P244	Cooling Fan Operation Selection	0		Starts the cooling fan when the power is turned "on." The fan stays "on" while the power is "on."		1	0, 1
		1	The cooling fan stays "on" during inverter				

Table 6.7e Parameter Functions

No.	Name	Function/Use	Default	Setting Range
		If the inrush current limiting circuit, control circuit capacitor, or main circuit capacitor reaches the life expiration warning level, the parameter value is displayed as follows.		
		Display Inrush current Cooling Main circuit circuit capacitor capacitor		
	Life Warning Status	15		
P255	Display	11	(0)	(0 to 15)
		7		
		3		
		* o: With warning, ×: Without warning		
P256	Inrush Current Limiting Circuit Life Display	Counts the number of times of a contact (relay, contactor, or thyristor) turning "on" and performs a countdown from 100 % (1000,000 times) by 1 % per 10,000 times. When the count reaches 10 % (900,000), a life expiration warning is issued.	(100)	(0 to 100)
P257	Control Circuit Capacitor Life Display	Calculates the remaining service life of the control circuit capacitor based on the power-on time and humidity and performs a countdown from 100 %. When the count falls below 10 %, a life expiration warning is issued.	(100)	(0 to 100)
P258	Main Circuit Capacitor Life Display	Issues a life expiration warning when the measured capacity of the main circuit capacitor falls below 85 %, with the default capacity level taken as 100 %. * The measurement is not performed automatically. The	(100)	(0 to 100)
P259	Main Circuit Capacitor Life Measurement	Measures the capacity of the main circuit capacitor as follows. (1) Connect the motor and place the unit in the emergency stop state. (2) Set "P259" to "1." (3) Power "off" the AMSE controller. In 5 seconds, power it "on." (4) After Checking that P259 indicates "3" (Complete), read the measured value by using P258. Display Description Remark	0	0, 1 (2, 3, 8, 9)

Table 6.7h Parameter Functions

No.	Name	Function/Use	Default	Setting Range
P402	No. 0 Rise Time Gain	Sets the pressure control gain at the pressure rise time. Increasing the setting value improves the response, but an excessively high value may result in vibration.		
P409	No. 1 Rise Time Gain			
P416	No. 2 Rise Time Gain	The value	1500	0 to 9999
P423	No. 3 Rise Time Gain	increases.		
		Time		
P403	No. 0 Fall Time Gain	Sets the pressure control gain at the pressure fall time. Increasing the setting value improves the response, but an excessively high value may result in vibration.		
P410	No. 1 Fall Time Gain			
P417	No. 2 Fall Time Gain	The value	1500	0 to 9999
P424	No. 3 Fall Time Gain	Time Time		

Table 6.7i Parameter Functions

No.	Name	Function/Use	Default	Setting Range
P404 P411 P418	No. 0 Lag Compensation No. 1 Lag Compensation No. 2 Lag Compensation	Sets the pressure control lag time constant. Lag compensation is used when the control gain cannot be increased, and the operation is not stable. It can prevent oscillations in a frequency band of several Hz. Excessively increasing the value deteriorates the response and overshoot characteristics; it is recommended to adjust it in combination with lead compensation.		
P425	No. 3 Lag Compensation	Time	70	1 to 2000
P405	No. 0 Lead Compensation No. 1 Lead Compensation	Sets the pressure control lead time constant. Lead compensation is used to improve the damping characteristics by preventing overshooting. Excessively increasing the value may result in oscillations in a high frequency band.		
P419	No. 2 Lead Compensation No. 3 Lead Compensation	Time	60	1 to 2000

Table 6.7j Parameter Functions

No.	Name	Function/Use	Default	Setting Range
P406	No. 0 Rise Time Pressure Command Filter	Sets the first-order lag filter for pressure command input. It can be set at the pressure rise time. It prevents overshooting in the case of stepped changes in pressure command voltage.		
P413	No. 1 Rise Time Pressure Command Filter	٩		
P420	No. 2 Rise Time Pressure Command Filter	The value increases.	300	1 to 2000
P427	No. 3 Rise Time Pressure Command Filter			
		Time		
P407	No. 0 Fall Time Pressure Command Filter	Sets the first-order lag filter for pressure command input. It can be set at the pressure fall time. It prevents undershooting in the case of stepped changes in pressure command voltage.		
P414	No. 1 Fall Time Pressure Command Filter	e i		
P421	No. 2 Fall Time Pressure Command Filter	The value increases.	300	1 to 2000
P428	No. 3 Fall Time Pressure Command Filter			
		Time →		

Table 6.7k Parameter Functions

No.	Name	Function/Use	Default	Setting Range
P408 P415 P422	No. 0 Pressure Response Sensitivity No. 1 Pressure Response Sensitivity No. 2 Pressure Response Sensitivity No. 3 Pressure Response Sensitivity	Sets the pressure response sensitivity for switching from flow control to pressure control. Increasing the value reduces the surge upon switching to pressure control but deteriorates the override characteristics. The value increases. The value increases.	200	1 to 2000
P437	Pressure Response Gain	Sets the pressure response gain for the above deviation.	300	0 to 9999
P438	Pressure Response Offset	Sets the pressure deviation for switching from flow control to pressure control. The timing of switching from flow control to pressure control is changed to reduce the surge pressure. Note that the parameter also affects the override characteristics. The value increases. The value increases.	100	0 to 9999

Table 6.7I Parameter Functions

No.	Name	Function/Use	Default	Setting Range
P439	Pressure Proportional Gain	This proportional gain is independent of control compensation, unlike the rise or fall time gain. It improves the response and minimizes disturbance. Since the response is not regulated by control compensation, an excessively high value may result in oscillations.	0	0 to 9999
P440	Pressure Feedforward Gain	Performs the feedforward control of changes in pressure command voltage (derivative) to improve the pressure wave	0	0 to 9999
P441	Pressure Feedforward Filter	response.	1	1 to 2000
P442	Pressure Feedforward Function Selection	- Feedforward Gain: Sets the sensitivity added to pressure control in relation to the change described above. - Feedforward Filter: Filters the return of feedforward signals to keep the function effective against sudden changes. - Feedforward Function Selection: Selects the method of adding feedforward signals. 0: Adding to pressure control at both the pressure rise and fall times. 1: Adding to pressure control at the pressure rise time only. 2: Adding to flow control at both the pressure rise and fall times. 3: Adding to flow control at the pressure rise time only. Pressure Command [V] Filter Gain Filter	0	0, 1, 2, 3

Table 6.7m Parameter Functions

No.	Name	Function/Use	Default	Setting Range
P443	Q-damping Gain	Detects the motor speed during pressure control and adds its derivative to pressure control. This function is effective when the pressure trackability is not good due to a large compression volume on the load side. - Q-damping Gain: Sets the sensitivity added to pressure control in relation to the change described above. - Q-damping Filter: Filters the return of Q-damping control signals to keep the function effective against sudden changes.	0	- 999 to 9999
P444	Q-damping filter	Motor Speed [r/min] Gain Q-damping Signal	1	1 to 2000
P449	Number of Combined Units	Inputs the required number of units for combination use. Sets the lower limit of the motor speed in relation to flow (motor	1	1 to 16
P450	QIN Mini	speed) command voltage. It prevents reverse rotation of the pump due to command voltage variations caused by noise or due to improper operation/input. e.g.) If the parameter is set to 10 (1.0 %) with a rated motor speed of 2000 rpm, the minimum motor speed is 20 rpm. 2000 Motor Speed [rpm] Setting Value of Command Voltage 0.0 0.05 5.0 [V] Voltage [1.0] 100.0 [%]	10	0 to 1000 × 0.1 %

Table 6.7n Parameter Functions

No.	Name	Function/Use	Default	Setting Range
P451	PIN Mini	Sets the lower limit of the pressure in relation to pressure command voltage. It prevents reverse rotation of the pump due to command voltage variations caused by noise or due to improper operation/input. e.g.) If the parameter is set to 10 (1.0 %) with a rated pressure of 17.5 MPa, the minimum pressure is 0.175 MPa (calculated value). 17.5 Pressure [MPa] 0.175 Setting Value 0.0 0.05 5.0 [V] of Command Voltage [1.0] 100.0 [%]	10	0 to 1000 × 0.1 %
P452	Q-COMP	Compensates for leakage inside the pump in relation to load pressure. As load pressure increases, the leakage level in the pump rises, resulting in lower flow. To prevent this problem, a compensation value proportional to load pressure is added to the flow command. The value increases. Motor Speed [rpm] O.0 Pressure 17.5 [MPa]	1000	0 to 2000

MEMO

Table 6.70 Parameter Functions

No.	Name	Function/Use	Default	Setting Range
P454	Flow Command Voltage Span	Adjusts the span of flow (motor speed) command voltage. This parameter provides the variable control of pump motor speed in relation to command voltage. At the default value, or 1000 (100.0 %), the rated motor speed is achieved with the input of a command voltage of 5 V. The zero point of command voltage is adjusted by "P455."	1000	0 to 9999 × 0.1 %
P455	Flow Command Voltage Zero	Motor Speed [rpm] P454 P455 0.0 5.0 [V] QIN Command Voltage	0	- 999 to 9999 × 0.1 %
P456	Pressure Command Voltage Span	Adjusts the span of pressure command voltage. This parameter provides the variable control of pressure in relation to command voltage. At the default value, or 1000 (100.0 %), the rated pressure is achieved with the input of a command voltage of 5 V. The zero point of command voltage is adjusted by "P457."	1000	0 to 9999 × 0.1 %
P457	Pressure Command Voltage Zero	Pressure [MPa] 0.0 PIN Command Voltage	0	- 999 to 9999 × 0.1 %

MEMO

Table 6.7p Parameter Functions

No.	Name			Default	Setting Range	
P458	Pressure Sensor Span	Adjusts the zero poin	t/span of pressure se	nsor input voltage.	1250	0 to 9999 × 0.1 %
P459	Pressure Sensor Span Pressure Sensor Zero Rated Pressure	According to the output voltage specification of the pressure sensor. Parameters are set as follows. Pressure Sensor				- 999 to 9999 Mv 1 to 300 × 0.1 MPa
P461	Rated Motor Speed	Sets the motor speed. This parameter is use without changing the When motor speed monitoring output, the Motor Speed monitoring output if Ir/mir	ed to change the rated flow command voltage nonitoring (SMN) is see e set motor speed is of 2000	d motor speed ge. elected for AM output at DC + 5 V.	2000	1 to 3000 r/min

Table 6.7q Parameter Functions

No.	Name		Function/Use		Default	Setting Range
P462	Pressure Sensor Rated Value	Sets the rated pressure for the pressure sensor. The rated output of the pressure sensor for the ASE pump system is obtained at DC 0.5 to 4.5 V/0 to 35 MPa. Thus, the rated value is 350 (35.0 MPa). 4.5 Output Voltage [V] 0.5 0 35[MPa] Pressure Sensor Value			350	1 to 400 × 0.1 MPa
P463	AM Monitoring Output Item Selection	Parameter Selection Items Setting Value Name Code Motor Speed Command PIN Pressure Command QIN Pressure Sensor Monitor Motor Speed Monitor (Calculated Value) TRQ Load Factor SMF		3	0 to 99	

Table 6.7s Parameter Functions

No.	Name	Function/Use	Default	Setting Range
c	Calibration Parameters	Automatically calibrates the input/output of each terminal. * See "Table 6.7v" for details.	-	-
PrCL	Parameter Clear	Initializes a parameter. * Calibration parameters are not initialized. * Parameters are not initialized when "P_77" is set to "1." Setting Range 0 Not initialize 1 Initialize	0	0, 1
ALLC	All Parameter Clear	<do be="" circumstances.="" not="" only="" parameter.="" special="" this="" to="" under="" use="" used=""> Initializes all parameters. * Parameters are not initialized when "P_77" is set to "1." Setting Range Description Not initialize 1 Initialize all parameters</do>	0	0, 1
Ercl	Manufacturer-controlled	Protected.	0	-

Table 6.7t Parameter Functions

No.	Name	Function/Use	Default	Setting Range
No.	Parameter Copy	Function/Use Copies setting parameter data when using multiple AMSE controllers. Setting Range Description 0 Cancel. 1 Copies the original data of parameters to the operation panel. 2 Writes the copied setting parameter data to the destination AMSE controller. Cross checks the setting parameter data written to the destination AMSE controller against the data on the operation panel. Setting method Note) Do not perform this work during operation. 1) Copy the original data of setting parameters to the operation panel. 1. Display the setting parameter "PCPY" and press the "SET" button. 2. Turn the "M Dial" to change from "0: Default" to "1." 3. Then, press the "SET" button. After the display flickers for about 30 seconds, "PCPY" appears to indicate the completion of the copy. 2) Write the copied setting parameter data to the destination AMSE controller and power on the operation panel. 2. Display the setting parameter "PCPY" and press the "SET" button. 3. Turn the "M Dial" to change to "2." 4. Then, press the "SET" button. After the display flickers for about 30 seconds, "PCPY" appears, indicating writing completed. 5. For the setting parameters to take effect, power "off" and then on the AMSE controller. 3) Cross check the setting parameter data. 1. Connect the operation panel retaining the setting parameter data to the destination AMSE controller and power on the operation panel. 2. Display the setting parameters to take effect, power "off" and then on the AMSE controller. 3) Cross check the setting parameter data. 1. Connect the operation panel retaining the setting parameter data to the destination AMSE controller and power on the operation panel. 2. Display the setting parameter "PCPY" and press the "SET" button. 3. Turn the "M Dial" to change to "3." 4. Then, press the "SET" button. The setting parameter data is loaded from the destination AMSE controller in about 30 seconds. 5. If any difference is found, the related setting parameter No. and "FE_3" are displayed alternately. Every	Default	Setting Range 0, 1, 2, 3

Table 6.7v Parameter Functions

No.	Name	Function/Use		Setting Range
C 1	C 1 AM Terminal Calibration	Calibrates the scale of the meter connected to the control circuit		
C_1	AW Terrillial Calibration	terminal "AM."	-	-

MEMO	

7. Troubleshooting

cause by referring to this manual.

7.1 Error indication

The ASE pump unit can issue "alarms" that are generated with the detection of system errors and stop system operation, "warnings" that are generated with the detection of system errors but allow continued system operation, and "error messages" generated by improper operation. The operation panel monitor indicates a code for each error. The user can identify the error

7.1.1 Alarms

An alarm is displayed when significant failure occurs to the ASE pump unit. Take appropriate measures in the event of an alarm. Any alarm shuts off the output and stops system operation, while the AMSE controller outputs an alarm signal.

The operation panel displays the code for the alarm (see Table 7.1a below).

Reset the alarm after removing the error cause and then restart system operation.

Note) Alarms are output via relay contacts. For details, see "Table 2.7c: Alarm Output."

Note) Alarm codes are output via the open collector. For details, see "Table 2.7d: Sequence Output."

Table 7.1a Alarm Codes

Alarm	Alarm Code		le	Name	Reference	Alarm Reset	
Alailli	FU	SU	IPF	Ivallie	Kelelelice	Aldilli Reset	
EPE				Parameter Memory Device		1)	
				Error		To reset an alarm, press	
E6				ODI F		STOP on the energtion panel	
E7				CPU Error		RESET) on the operation panel.	
E.CPU				Innuals Company Limiting			
E.IOH				Inrush Current Limiting Circuit Error	Table 7.2a	2)	
E.AIE				Analog Input Error		Turn "off" and the on the power.	
Е.ОРГ				Option Error		3)	
E.SEr	OFF	OFF	OFF	Communication Error		Turn "on" RES (Reset Signal) for	
E13	011	011	011	Internal Circuit Error		at least 0.1 second.	
E.P24				DC 24 Power Output Short		Note) For details, see "Table	
				Circuit		2.7a: Sequence Input."	
E.CFE				Operation Panel Power Short Circuit			
E.USb				USB Communication Error			
				Hydraulic Control Board			
E.OP3				Error			
				Hydraulic Control Board			
E3				Communication Error	T-1-1- 7 01-		
E.Ov3				Regeneration Overvoltage	Table 7.2b		
EbE	OFF	OFF	ON	Brake Transistor Error			
				Detection			
E.UuΓ	OFF	ON	OFF	Undervoltage			
E.IPF	• • •			Instantaneous Power Failure			
E.FHF				AMSE Controller Overload			
Е.ГНП	OFF	ON	ON	Motor Overload			
E.Fin				Fin Overheat			
E.OLF				Stall Prevention			
E.OC3	ON	OFF	OFF	Overcurrent Ground Fault Overcurrent on			
EGF	ON	OFF	UFF	the Output Side	Table 7.2c		
E.ILF				Input Phase Failure			
E. LF	ON	ON	ON	Output Phase Failure			
E.PUE	0.,	0.,	0.,	PU Disconnection			

Note 1) After removing the error cause, wait about 30 minutes until the unit cools down.

7.1.2 Warnings

When the probability of the failure of the ASE pump unit is determined, warnings are displayed before alarm output.

Take appropriate measures in the event of a warning. While the system continues operation, the AMSE controller outputs a warning signal, and the operation panel displays the code for the warning.

When any warning is output, take measures to prevent the occurrence of serious failure.

Table 7.1b Warnings

Warning	Name	Reference
OL	Stall Prevention (Overcurrent)	
Rb	Dynamic Brake Pre-alarm	
ГН	Electronic Thermal Pre-alarm	
PS	PU Stop	Table 7.2d
CP	Parameter Copy	
Fn	Fan Fault	
οΡ	Hydraulic Control Board Warning	

Note) Contact us when other warning codes are displayed.

7.1.3 Error messages

In the event of setting failure due to improper operation, an error code is displayed on the operation panel.

Set the relevant parameter properly by referring to this manual.

Table 7.1c Error Messages

Error Message	Name	Reference
HOLD	Operation Panel Lock	
Er 1	Parameter Write Error - 1	
Er 2	Parameter Write Error - 2	
Er 3	Parameter Write Error - 3	
Er 4	Parameter Write Error - 4	Table 7.2e
rE 1	Copy Operation Error - 1	Table 1.2e
rE 2	Copy Operation Error - 2	
rE 3	Copy Operation Error - 3	
rE 4	Copy Operation Error - 4	
Err	Error	

7.1.4 Status display

During operation, the operation status code is displayed on the operation panel.

Table 7.1d Status Display

Status	Name	Reference
ЕПС	Emergency Stop	Table 7.2f

7.2 Measures against alarms (error indication)

A CAUTION

- ♦ When an alarm occurs, remove its cause and ensure safety. Then, reset the alarm and restart system operation.
- ♦ When an alarm occurs, immediately turn "off" STF (Serve-on) and shut off the power supply.
- ♦ If any of the following alarms occurs, do not restart operation by resetting the alarm. Doing so may cause failure of the servo amplifier or motor. In such cases, remove the alarm cause and wait 30 minutes or more until the unit cools down. Then, restart operation:
 □E.ΙΟΗ, □Ε.ΓΗΓ, or □Ε.ΓΗΠ.

An alarm can be reset by powering off and then on the unit, pressing the "STOP/RESET" button on the operation panel, or turning on RES (Reset).

Table 7.2a Measures Against Alarms

Alarm	Name	Description	Cause	Remedy
E. PE	Parameter Memory Device Error	EEPROM failure (control board).	Excessive parameter write operations.	- Replace the AMSE controller
E. 6 E. 7 E.CPU	CPU Error	Communication error of the built-in CPU.	Noise.	 Take measures against devices producing excessive noise near the AMSE controller.
E.IOH	Inrush Current Limiting Circuit Error	The resistor of the inrush current limiting circuit has overheated.	Repeated power-on/off cycles.	Replace the circuit with the one that does not perform frequent power-on/off cycles.
E.AIE	Analogue Input Error	Input of 30 mA or more or voltage input after changing the control circuit terminals "2" and "4" to the settings for current command specifications.	Change of the setting of the voltage/current switch.	Correct the setting of the voltage/current switch.
Е.ОРГ	Option Error	Communication circuit error of a communication	Failure of the hydraulic control board connector.	Check the connection of the hydraulic control board.
		option.	Communication error due to a parameter setting change.	Initialize the setting parameter.
E.SEr	Communication Error	RS-485 communication error	The number of communication errors has exceeded the allowable threshold set by the setting parameter "335: RS-485 Communication Retry Count" (excluding "9999"). The communication downtime is longer than the threshold set by the setting parameter "336: RS-485 Communication Check Time Interval."	 Set the parameter with sufficient margin. Modify the wiring to ensure the availability of RS-485 communication.
E. 13	Internal Circuit Error	Internal circuit error.	Failure.	Contact the place of purchase.
E.P24	DC 24 Power Output Short Circuit	Short circuit of DC 24 V power supplied from the control circuit terminal "PC."	Short circuit of the PC terminal.	Disconnect the wire from the PC terminal to check whether the error can be removed. Then, check whether the wire connected to the PC terminal is short-circuited.

Table 7.2b Measures to rectify Alarms

Alarm	Name	Description	Cause	Remedy
E.CFE	Operation Panel Power Short Circuit RS-485 Terminal Power Short Circuit	Short circuit of the operation panel power (PU connector). Short circuit of the RS-485 terminal power.	Short circuit of the power cable of each power supply.	Check the short-circuited part. Replace the operation panel.
E.USb	USB Communication Error	Interruption of USB communication.	Contact failure.	Check the cable.
E.OP3	Hydraulic Control Board Error	Pressure sensor output error. EEPROM error.	Disconnection of the pressure sensor. EEPROM read error.	Check the wiring. Replace the wiring. Replace the pressure sensor.
E3	Hydraulic Control Board Communication Error	Interruption of communication between the hydraulic control board and the driver.	Contact failure of the connector. Board failure.	Replace the AMSE controller.
E.Ov3	Regenerative overvoltage	Regeneration during deceleration/stop. Overvoltage shutdown.	Rapid deceleration.	Increase the deceleration time. Reduce the braking frequency. Use a brake unit/power regenerative converter, if required.
E. bE	Brake Transistor Error Detection	Damage to the brake transistor or brake circuit failure.	A large volume of released pressure. High braking frequency (the cycle time must be set with sufficient margin).	The replacement of the AMSE controller is required.
Ε.ՍսΓ	Undervoltage	The primary power voltage applied to "R/L1," "S/L2," and "T/L3" of the main circuit terminal block is 300 V or less. The short bar between "P/+" and "P1" of the main circuit terminal block or DC reactor is connected.	Low power voltage. Any factor that reduces the main power voltage and causes the error (startup of a large-size motor, etc.).	Check the power facilities. If a DC reactor is in use, check the wiring.
E.IPF	Instantaneous Power Failure	Power failure lasting more than 15 ms. *1: This error is not output in the case of a power failure of more than 100 ms. *2: The operation continues in the event of an instantaneous power failure of 15 ms or less.	Interruption of power supply for more than 15 ms but less than 100 ms.	Remove the cause of instantaneous power failure. Prepare a backup power supply for instantaneous power failure.
Е.ГНГ	AMSE Controller Overload Shutdown	When the rated output current is exceeded and if overcurrent shutdown does not occur, the electronic thermal with inverse time characteristics is activated for output transistor protection.	The motor's rated load factor has been exceeded.	Reduce the load Reduce the pressure setting Reduce the cycle load by operating the system at intervals.
Е.ГНП	Motor Overload Shutdown	The electronic thermal in the AMSE controller has detected a motor overheat caused by overload or reduced cooling capability during constant speed operation.	High overload factor of the motor. The set value of the setting parameter "71: Applicable Motor" is improper.	Modify the motor environment (ambient temperature). Check that the motor fan works normally.

Table 7.2c Measures to rectify Alarms

Alarm	Name	Description	Cause	Remedy
E.Fin	Fin Overheat	The cooling fin of the AMSE controller has overheated.	1) Ambient temperature around the AMSE controller is high. 2) The cooling fin has been clogged. 3) The cooling fan has stopped.	1) Check that the ambient temperature is as specified. 2) Clean the cooling fin. 3) Replace the cooling fan.
E.OLГ	Stall Prevention	The operation has been stopped by the torque limiting function.	Overload.	Reduce the load.
E.OC3	Overcurrent	The current level during deceleration is higher than the specified current value.	Rapid deceleration. Output short circuit.	Increase the deceleration time. Check the wiring.
EGF	Ground Fault Overcurrent on the Output Side	A ground fault has occurred on the output side of the AMSE controller.		Restore the section where the ground fault has occurred.
E.ILF	Input Open-phase	One of the three input power phases has opened.	Disconnection of the 3-phase power cable.	Check the wiring.
E.PUE	PU Disconnection	Interruption of communication between the operation panel and the PU terminals.	Disconnection of the operation panel. Setting of the setting parameter "P_75: Reset" at "2," "3," "16," or "17."	Reset "P_75" to "0," "1," "14," or "15" so that the operation continues when the operation panel is disconnected.

Table 7.2d Measures to rectify Warnings

Alarm	Name	Description	Cause	Remedy
OL	Stall Prevention (Overcurrent)	The threshold set by the setting parameter "P_22: Stall Prevention Operation Level" has been exceeded.	The load is too high.	Reduce the load. Increase the settings of "P7: Acceleration Time" and "P8: Deceleration Time." Check that the setting parameter "P_13" has been set to "0."
rb	Dynamic Brake Pre-alarm	The dynamic brake utilization has exceeded 85 % of the set value.	The frequency of the dynamic brake utilization is high.	Increase the setting of "P_8: Deceleration Time" (extend the deceleration time).
ГН	Electronic Thermal Pre-alarm	The value has exceeded 85 % of the set value of "P_9: Electronic Thermal."	The load is too high. Too frequent rapid acceleration/ deceleration.	Reduce the load and operation frequency.
PS	PU Stop	The "STOP" button has been enabled by the setting parameter "P_75: Reset."	The operation has been stopped by the "STOP" button.	After turning off the servo, press the "STOP/RESET" button for recovery. Turn "on" the terminal "RES" for recovery.
СР	Parameter Copy	Parameter data has been copied between different AMSE controllers.		Initialize the setting parameter "P989: Parameter Copy Warning Reset."
Fn	Fan Fault	The fan in the AMSE controller has failed and stopped, or its rotational speed has decreased.	Fan failure.	Contact the place of purchase.
оР	Hydraulic Control Board Warning	Setting error.	Mismatch between the combination use setting area and the combination use setting parameter.	See "8: Combination use" to check the setting of combination/single use.

Table 7.2e Measures to rectify Error Messages

Alarm	Name	Description/Cause	Remedy		
HOLD	Operation Panel Lock	The operation lock mode is active.	Press the "MODE" button on the operation panel for 2 seconds or more (to disable the operation lock).		
s	Write	The setting parameter "P_77: Parameter Write Selection" has been set to "1."	Change the setting of "P_77: Parameter Write Selection."		
Er 1	Protection Error	The operation panel has not been mounted to the AMSE controller properly.	Check the connection between the operation panel and the PU connector.		
Er 2	Write During Operation	A write was performed during operation with STF (STR) - SD set to "on."	Stop the operation. Change the setting of "P_77: Parameter Write Selection."		
Er 3	Modify the setting	gs of the setting parameters (default settings are recomm	nended)		
Er 4					
rE 1	Parameter	3	Perform the work again.		
	Read Error	work.	Operation panel failure.		
	Parameter Write Error	A write of copied parameter data was attempted during operation. EEPROM failure on the operation panel side during work.	Stop the operation and perform the work again.		
rE 2 Writ			Operation panel failure.		
rE 3	Parameter Cross Check	Inconsistency of data on the operation panel with data on the AMSE controller. EEPROM failure on the operation panel side during	Press the "SET" button to continue the cross check process. When the error indication remains		
	Error	work.	on, operation panel failure should be suspected.		
-F 4	Madal France	The AMSE controller model is different upon parameter copy, write, or cross check.	Check that the same model is used.		
rE 4	Model Error	Termination of parameter write after termination of parameter copy.	Perform the work again.		
		The "RES" signal is "on." Failure of communication between the operation	Turn "off" the "RES" signal.		
Err	Error	panel and the AMSE controller. The main circuit power separate from the control circuit power has been turned "on."	Check the connection between the operation panel and the AMSE controller.		

Table 7.2f Status Display

ЕПС	Emergency Stop	The unit is in an emergency stop.	Reset the emergency stop state. For the setting for combination use,
	оюр		see "8: Combination use."

7.3 Measures to rectify noise

□ There are two types of noises: external noise causing malfunction of the AMSE controller and noise from the AMSE controller and causing malfunction of peripheral devices. The AMSE controller is designed to be noise resistant; however, basic measures described in 7.3.1 are required because the AMSE controller is an electronic device handling weak signals. The AMSE controller chops output signals at high carrier frequencies and may generate noises. If such noises cause malfunction of peripheral devices, noise control measures must be taken. Measures slightly differ depending on where the noise comes from.

7.3.1 Basic measures

- For the AMSE controller's power cable (I/O cable) and signal cable, avoid running the cables in parallel or bundling them. Wire the cables separately.
- For the encoder connection cable and control signal cable, use twisted pair shielded cables. Connect the outer conductor of the shielded cable to the terminal SD.
- Provide single point grounding for the "AMSE controller" and "motor."

7.3.2 Measures against external noises causing malfunction of the AMSE controller

- □ Take the following measures if noise-generating devices (electromagnetic contactor, electromagnetic brake, and many relays) are installed near the AMSE controller and may cause malfunction of the controller.
- Provide surge suppressors to the noise-generating devices for noise reduction.
- Use a "ferrite core" for the signal cable.
- Use metallic cable clamps to attach the shield of the encoder connection cable and control signal cable.

7.3.3 Measures against noises from the AMSE controller and causing malfunction of peripheral devices

□ Noises generated by the AMSE controller are roughly classified into three types: noises from the cables connected to the AMSE controller and its main circuit (I/O), those electromagnetically or electrostatically induced in the signal cables of peripheral devices near the main circuit power cable, and those through power lines.





Fig. 7.3a Classification of Noise Types

Table 7.3b Measures Against Noises

Noise Path	Measures
(1), (2), (3)	If devices or signal cables that handle weak signals and are susceptible to noise (gauges, receivers, sensors, etc.) are housed together with the AMSE controller or installed near the controller, they may malfunction due to noise. Thus, the following measures must be taken. 1) Design the system so that noise-susceptible devices are away from the AMSE controller as far as possible. 2) Install noise-susceptible signal cables away from the AMSE controller and its I/O cable as far as possible. 3) Avoid running the signal cables and power cable (AMSE controller's I/O cable) in parallel or bundling them. 4) Turn "on" the EMC filter on/off connector of the AMSE controller. 5) Provide a line noise filter for output to suppress radiation noises from wires. 6) The use of shielded wires for signal and power cables or the housing of such cables in separate metal ducts is effective.
(4), (5), (6)	If a signal cable is run in parallel to the power cable or bundled with the power cable, electromagnetic or electrostatic noise may propagate through the signal cable, causing malfunction. Thus, the following measures must be taken. 1) Design the system so that noise-susceptible devices are away from the AMSE controller as far as possible. 2) Install noise-susceptible signal cables away from the AMSE controller and its I/O cable as far as possible. 3) Avoid running the signal cables and power cable (AMSE controller's I/O cable) in parallel or bundling them. 4) The use of shielded wires for signal and power cables or the housing of such cables in separate metal ducts is effective.
(7)	If peripheral devices are connected to the same power line as for the AMSE controller, noise generated by the AMSE controller propagates through the power cable, causing malfunction of the devices. Thus, the following measures must be taken. 1) Turn "on" the EMC filter on/off connector of the AMSE controller. 2) Provide a line noise filter for the power cable (output cable) of the AMSE controller.
(8)	If peripheral devices are wired to the AMSE controller to form a closed-loop circuit, leak current may flow through the ground wire of the AMSE controller, causing malfunction of the devices. In such cases, remove the ground wire of the devices to prevent malfunction.

Note) Turning "on" the EMC filter may cause the earth leakage circuit breaker to malfunction. Therefore, an earth leakage circuit breaker for high frequencies range must be used.



8. Combination use

8.1 Overview

For systems that require high flow it is possible to combine multiple ASE units.

The control of combined units is performed by the "master ASE" unit, and this unit makes sure that all the other units perform the same function at the same speed. Therefore, it is only the master ASE unit that receives and processes pressure/flow commands and sequence signals. This mechanism reduces the load of the main system's sequence signals.

For the combination use operation, the communication network is configured so that if a failure occurs in unit, the fail safe function stops the entire ASE system. This control system is capable of controlling up to 16 combined units, or 2080-L/min flow (ASE5- × 16 units).

The controller can be used for both combination and single use operation; the operation mode can be switched by changing the settings.

8.2 Simplified diagram of the hydraulic circuit and wiring

- Directly connect all discharge lines.
- Only one pressure sensor, mounted on the master ASE is used. (No pressure sensor of the slave ASE units is used.)

Sequence signals received by one unit for combination use operation are used for all combined units.
 When providing a stop valve for maintenance, considerations must




Fig. 8.2a Simplified Circuit Diagram for Combination Use

8.3 Component setting for combination use

* For components other than those shown below, see Section 4.




Fig. 8.3a Component Setting for Combination Use

8.4 Tools for setting

- * The master ASE requires all cables.
- * The slave ASE units require no cable connection to the control circuit/pressure sensor terminals.

Prepare a required number of "RJ11 modular cables" for configuring a communication network.

<u>"Required number = Number of combined units - 1"</u>

Our recommendation (for reference)



Name: Modular cable with ferrite core

(sealed twisted pair)

Model: TEL-FST-*S

Do not tie network cables with high voltage power lines.



Fig. 8.4a Modular Cable

MEMO

8.5 Setting

Settings selected by the switches described in this section are not reflected if they are changed during operation. To make settings valid, changes should be made when main power is "off," then, turn it "on."

8.5.1 Network No. selection switch for combination use (SW2)



Set network Nos. to each AMSE controller according to the number of combined units. Referring to the table below, set Nos. and roles to each AMSE controller. The default setting is "0."

* Turn the switch so that the arrow points to desired No.

Fig. 8.5a Network No. Selection Switch for Combination Use

Table 8.5a

Number of combined units	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
No.	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
Role	М	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	S13	S14	S15

Note) Meaning of Role: M = Master ASE, S* = Slave ASE

- * No. for the AMSE controller for the master ASE is "0."
- * Set Nos. other than "0" for the AMSE controllers for the slave ASE units. Setting the same No. for different slave units displays a warning "oP," rendering the system inoperable.
- * The switch turns 360 degrees clockwise and counterclockwise. Turn the switch so that the arrow points to desired No.

8.5.2 Control switch for combination use (SW1)

Select settings by switching each bit between ON and OFF.



Fig. 8.5b Control Switch for Combination Use

Table 8.5b

bit	Name	ON/OFF	Description	Default
1	Manufacturer-controlled		the setting from "OFF" to	OFF
2	Reserved	"ON" is no	t allowed.	0
3	Switching combination/	ON	Single use operation	ON
3	single use operation	OFF	Combination use operation	ON
4	Network	ON	w/ termination resistor	OFF
4	termination resistor	OFF	w/o termination resistor	OFF

- bit.1 (manufacturer-controlled)
 - * The default setting is "OFF."

Table 8.5c

ON/OFF	Mode
ON	Do not set to "ON."
OFF	Normal mode

■ bit.2 Reserved

This bit is reserved.

- * The default setting is "OFF."
- bit.3 Switching combination/single use operation

This bit is used for a model with a controller for combination use to perform single use operation.

- * Switching this switch alone does not allow single use operation. For details, see Section "8.9."
- * The default setting is "ON (single use operation mode)."

Table 8.5d

ON/OFF	Mode
ON	Single use operation
OFF	Combination use operation

■ bit.4 Network termination resistor

In the combination use operation of the ASE units connected by a communication network, only one modular cable is connected to each of the AMSE controllers at both ends.

For such AMSE controllers, of which only one port of the modular connector is used, set bit.4 Network termination resistor to "ON." Failure to do so may cause communication errors.

Table 8.5e

ON/OFF	Mode
ON	w/ termination resistor
OFF	w/o termination resistor

<Example of termination resistor setting>




Fig. 8.5c Network Cable Connection

8.5.3 Modular connector (CN3)



This connector is used for connecting modular cables to configure a communication network connecting between the Master ASE and a slave ASE unit and also between the slave ASE units.

Though two cable ports are provided, there is no priority order between the two cable ports. When using only one cable, it can be connected to either port.

Connect cables, paying attention to the direction of the connector.

Fig. 8.5d Modular Connector

^{*} The default setting is "OFF (w/o termination resistor)."

8.6 Changing parameters



This section describes adjustment with control power turned "on." Incorrect settings may result in a failure. Be sure to power "on" in Stand-by state, not in Servo On state. Take precautions, e.g. removing the "STF-SD" cable from the control circuit terminal of the AMSE controller for the master ASE, to ensure that Servo On does not start with main power application.

8.6.1 Number of combined units

Set the parameter for each of all combined AMSE controllers.

- Parameter No.: P449
- Parameter Name: Number of combined units

Set a value representing the "number of units to be combined."

* The default setting is "1." A value between 1 and 16 can be set.

8.6.2 MRS signal input selection

Servo emergency stop (EMG) can be deactivated. Set the parameter for all AMSE controllers for the slave ASE units, excluding that for the master ASE.

- Parameter No.: P 17
- Parameter Name: MRS signal input selection

Set "0."

MEMO

* The default setting is "2." A value between 0 and 2 can be set.

8.7 Before commissioning



CAUTION

Preparation for operation is assumed to be completed. However, a breakage in combination use system may cause damage. Recheck the followings before commissioning.

8.7.1 Check the hydraulic circuit

Check that all discharge hydraulic lines are connected directly to the discharge hydraulic circuit without valves in line.



DANGER

If any discharge port of the slave ASE units is connected to another line or blocked for some reason, abnormal pressure may occur.

When stop valves are provided in pump discharge hydraulic lines for maintenance purpose, be sure they are "open".

8.7.2 Checkinstallation

Ensure that ASE pump and AMSE controllers are correctly installed.

In particular, pay attention to the cooling (distance between the fan and the wall).

8.7.3 Check cable connection

Only the master ASE requires the same cable connection as in single use operation. The slave ASE units require no pressure sensor cable.



DANGER

Incorrect cable connection may cause damage to the system and result in a fatal accident. Refer to this manual, and make sure that the cable connection is correct.

8.7.4 Check the setting of the combination use controllers

- 1) Check that network No. selection switch is for combination use
 - (1) For the AMSE controller for the master ASE, the setting should be "0."
 - (2) For the AMSE controllers for the slave ASE units, the setting should be "1 to F." The same No. cannot be shared between the combined slave ASE units.
- 2) Control switch
 - (1) For the controllers with one modular cable connected, only bit "4" should be set at "ON."
 - (2) For the AMSE controllers for the slave ASE units with two modular cables connected, all bits should be set at "OFF."



WARNING

When bit "3" of the control switch is set at "ON," single unit operation may start. This may result in burnout of the AMSE controllers for other ASE units.

8.7.5 Checking the control parameter

- * This involves powering on of all ASE units. Check that all cable connections are correct.
 - (1) Switch on the slave ASE units. There is no priority order between the units. Note) This operation displays a warning "oP" but this does not matter.
 - (2) Check that the correct number of combined units is set for Parameter P449 (Number of combined units) of all the AMSE controllers for the slave ASE units.
 - (3) After checking the above (1) and (2) above, switch on the master ASE.
 Note) When Servo On starts concurrently with powering on, the system may start abruptly.
 Check the safety around the system before powering on.
 - (4) Switch on the master ASE. After setting the parameter, the preparation is completed.
 - (5) After checking the safety around the system, start commissioning by applying Servo On signals.
 - Note) If the system does not start, see "8. 8 Troubleshooting during combination use operation."
- Setting procedure (for reference)
 - (1) Check that the AMSE controller is switched on.
 - (2) Display P*** by pressing "MODE" for several times.
 - (3) Display P449 or P_17 by turning the "M dial."
 - (4) Keeping this setting, turn the "M dial" to display a desired value and press "SET."
 - (5) When the parameter is properly set, the parameter No. and the set value blink alternately.
 - (6) After setting, power "off" the AMSE controller, and then, power it "on" again.
 - (7) The setting is completed.
 - * Repeat this procedure to all applicable AMSE controllers.
 - * If the parameters are set improperly, the unit may become inoperable.

1EMO 	

8.8 Troubleshooting during combination use operation

No alarm is displayed for the controllers for combination use.

When a setting error occurs, a warning "oP" is displayed on the operation panel.

While "oP" is displayed, the system becomes inoperable. The system remains inoperable until proper setting is achieved. If "oP" is displayed in Servo On state, be careful because the system starts as soon as "oP" is turned off after the error cause is removed.

For other alarms and warnings, see "7. Troubleshooting."

The table below lists conditions where alarms are displayed.

Table 8.8a

Item	Condition
(1)	When power is not applied to all combined ASE units yet, the warning is displayed on
(1)	the AMSE controllers for the ASE units with power already applied.
	When the "network No. selection switch for combination use (SW2)" of the AMSE
(2)	controller for the master ASE is set at a value other than "0," the warning is displayed
	on all AMSE controllers.
(3)	When the same No. is set to the "network No. selection switch for combination use
(3)	(SW2)" of different slave ASE units, the warning is displayed on all AMSE controllers.
(4)	When all ASE units are not connected with modular cables, the warning is displayed
(4)	on all AMSE controllers.
(5)	When an alarm occurs in one of the combined ASE units, the warning is displayed on
(5)	all AMSE controllers, excluding that for the unit generating the alarm.
	When the set value for Parameter No. P449 is not consistent with the number of
(6)	combined units in any one of the combined ASE units, the warning is displayed on all
	AMSE controllers.
(7)	During emergency stop, the warning is displayed on all AMSE controllers, excluding
(7)	that for the master ASE (master "oP").
	"EΠG" is displayed on the AMSE controllers for the slave ASE units for which
(8)	"deactivation of servo emergency stop (EMG) (see Section 8)" is not set, while "oP" is
	displayed on the other AMSE controllers.

If a warning "oP" is displayed, the system returns to normal operation with the removal of the cause.

To prevent unexpected accidents, consider and check the safety around the system in its power-on state.

8.9 Returning the settings for combination use to single use		
(1) With the AMSE controller switched "off," set "bit 3" of "8.5.2 Control switch for combination use (SW1)" to "ON."		
(2) In Servo Off state, power "on" the AMSE controller.		
(3) Change the setting of Parameter "P449 (Number of combined units)" to "1."		
(4) Change the setting of Parameter "P_17 (MRS signal input selection)" to "2."		
(5) After completing the above (1) to (4), power "off" the AMSE controller again.		
(6) The new settings will be applied the next time the unit is powered on.		
MEMO		

9. Maintenance

This product requires no periodic overhaul during normal operation.



CAUTION

• Maintenance should be performed by a qualified person who has adequate knowledge of electrics and hydraulics (skilled worker equivalent to the 2nd grade Certified Skilled Worker of Hydraulic Device Assembly (Yuatsu Kiki Chosei Ginoshi) or higher or who has received our technical training).

9.1 Contamination control of hydraulic fluid

Foreign matter in hydraulic fluid often obstructs normal operation of the pump. It may cause failure or shorten the pump life. Keep hydraulic fluid clean (contamination level: JIS B9933 (ISO 4406) 20/18/14 or within NAS 9 class or better). Also, apply 100 μ m (150 mesh) filters to the suction line and 10 μ m or less filters to the discharge or return line.

9.2 Daily inspection

Perform daily inspections for items in Table 9.2a.

The items liste.d below are standard check points for general hydraulic equipment understandard operation. The frequency of inspection should be increased for a while after the initial operation. Taking into account the operational status/operating environment, perform maintenance, including maintenance of the actuator, as cohesively as possible.

Table 9.2a Daily Inspection Items

Inspection Place/Item	Frequency	Inspection Method and Measure
(1) Pump Noise	Once a day	When abnormal noise (differing from the normal sound of operation) occurs, stop operation and check the pump.
(2) Operating Condition of the Cylinder	Once a day	Check for any unstable phenomenon, including knocking. When detected, stop operation and check the cylinder.
(3) Rusty/Loose Joint	Once a day	Check that there is no looseness of or no dust/water entering the joints.
(4) Fluid Leakage	Once a day	Perform periodic inspection to prevent fluid leakage. If the fluid level drops, pump performance will be affected. Fluid leakage must be avoided to ensure against fire.

9.3 Inspection of the AC servo motor

Employing a brushless motor makes daily inspection of the AC servo motor easy. Use Table 9.3a for reference. Determine the appropriate inspection frequency in terms of the operational status/operating environment.

Table 9.3a Inspection of the AC Servo Motor

Inspection Place/Item	Frequency	Inspection Method and Measure	
(1) Vibration and Acoustic Check	Once a day	Comparing to normal conditions, check that there is no increase in vibration and noise by touch and by listening.	
(2) External Inspection	Depending on damage	Clean with cloth or air, if required.	
(3) Overall Check	Once every 20000 hours or every 5 years	Contact your supplier or our customer	

9.4 Guideline for replacing the AC servo motor components

See Table 9.4a for component replacement intervals. The replacement period may vary depending on the condition of use or the operating environment. Replacement is required every time any failure is found. Contact your supplier or our customer support to request component replacement. Following inspection, it may be necessary to replace the component.

Table 9.4a Component Replacement Intervals for the AC Servo Motor

Component	Replacement Interval	Remarks
(1) Bearing	20 thousand hours	When any failure is found, replacement is
(2)Cooling Fan	20 thousand hours	required even before the specified interval reached.

9.5 Inspection of the AMSE controller

No daily inspection is required. Inspect the controller at least once a year.

Table 9.5a Inspection of the AMSE Controller

rable died mepeeden er die 7 die 2 dendener		
Inspection Place/Item	Interval	Inspection Method and Measure
(1) External Inspection	Once a year (at	Check that there is no dust, dirt, or oil contamination. If required, clean with cloth or air.
(2) Check for Loose Screws	least)	Check for loose mounting screws for the terminal block or connectors. If required, retighten them.

9.6 Guideline for replacing the components of the AMSE controller

The electric or electronic components of the AMSE controller are subject to mechanical wear and aging. Periodically inspect them as part of preventive maintenance. Also, contact your supplier or our customer support according to Table 9.6a Component Replacement Intervals for the AMSE Controller. Following inspection, it may be necessary to replace the component. When an AMSE controller returned to/overhauled by us, parameter settings are reset to default values before shipment. Be sure to reset to your required parameters.

Table 9.6a Component Replacement Intervals for the AMSE Controller

Component	Standard Replacement Interval	Remarks
(1) Cooling Fan	10 years	When any failure is found, replacement is required even before the specified interval is reached.
(2) Main circuit smoothing capacitor	(assuming the annual average	
(3) On-board smoothing capacitor	10 years	

10. Storage of unused units

Store and manage unused and spare units in a proper indoor storage place.

- Storage temperature range: 0 to 40 °C (no freezing)
- Storage humidity range: 80 % or less (no condensation)
- o avoid rust, corrosion, degradation of seals, etc., do not store the unit in the following and similar places.
- a) Places potentially exposed to the direct influence of weather
- b) Places where chemicals, such as organic solvents, acids, and alkalis, are present or the effect of vaporized gas potentially exists
- c) Places where dew condensation potentially occurs due to substantial temperature fluctuations.

11. Disposal

This unit is categorised as industrial waste disposal purposes. When disposing of the unit, its components, and hydraulic fluid, follow the procedures set out under your local laws and have them disposed of by an industrial waste disposal contractor.

12. Customer service

If there are requests regarding our products or if any services are required, please contact your supplier, our customer support, or the following sales department.

• YUKEN KOGYO CO., LTD.

International Sales Department Hamamatsucho Seiwa Bldg., 4-8, Shiba-Daimon 1-Chome Minato-ku, Tokyo 105-0012, Japan Phone: +81-3-3432-2110

Fax: +81-3-3436-2344

History of Publication

ASE AC Servo Motor-Driven Pump Operation Manual

December 2009 First edition of the English version Pub. EM-0146

January 2010 Second edition of the English version Pub.EM-0146-1

• Published by:

• YUKEN KOGYO CO., LTD.

Products Publicity Section, Sales Administration Dept.

Hamamatsucho Seiwa Bldg., 4-8, Shiba-Daimon 1-Chome Minato-ku, Tokyo 105-0012, Japan

Phone: +81-3-3432-2110 Fax: +81-3-3436-2344