



*The Chen Hsong Group*  
震雄集團

## **MPC 4.0**

# Multi-functional Computer Operation Manual

震雄机械(宁波)有限公司  
ChenHsong Machinery (ningbo) Co., Ltd.

## **Chen Hsong MPC40 Multifunction Computer**

### **Features:**

Imported from Japan, MPC40 PC is compliance with all types of JIS inspection standards. Equipped with a 640 x 480 colorful extra-large LCD screen, it has a wide operating voltage range: AC 110V~AC 280V 50/60 Hz, plus ultra high stability. The data stored may be kept for 5 years or above under the condition of power failure.

Chinese, English or Japanese language can be freely selected and they can be switched over from one to the other, facilitating learning to operate the computer.

### **Basic performance :**

1. Enlarged memory which may store 150 sets of mold information (e.g. time, counting times, pressure, speed, stroke, quantity, mold thickness, explanation of mold number, conditions for selection, barrel temperature. All data can be stored either in floppy disk or PC alternatively
2. Data lock function prevents unauthorized access and mistaken amendment.
3. Detailed online operation instruction and multiple user management.
4. Temperature holding of nozzle: heating time setting for the nozzle with up to 100% temperature being maintained, or control in PID way.
5. 8-stage PID temperature control with an adjusting range of 30°C—500°C, with K type thermocouple.
6. Cold start prevention, automatic preheat function.
7. Alarm setting on the control of high and low oil temperature and breakage of the thermocouple cable during running is available.
8. Automatic detection of blocked nozzle and material overflow
9. 10-stage injection speed, 10-stage injection pressure and 10-stage holding pressure.
10. 10-stage plasticizing speed, 10-stage plasticizing pressure and 10-stage back pressure.
11. 3-group pneumatic ejection setting and 3-group core pulling setting

12. High-accuracy electronic ruler used for clamping, injection and ejection.
13. Data input error prevention and prompting.
14. Production volume setting for auto-stop function
15. Super lubrication setting for toggle unit, setting of the frequency of lubrication form mechanical links and alarm for lacking in oil.
16. Operation diagram display for monitoring operating process of the plastic injection machine
17. Diagnostic function can check the status of 48 input devices, 48 output devices, as well as monitoring 100 timers and 32 counters.
18. Mold data can be overwritten or deleted freely. Default mold data can be selected to save time.
19. Using the most advanced SMT for the I/O board.
20. Using two Intel IC with 32 bits.

MPC40 is a new generation product of Chen Hsong with even more powerful function. Comparing with CH-3.8PC, MPC400 is equipped with newer hardware and more enhanced software.

FUNCTION	MPC40	CH3.8PC
LCD display	640×480	320×240
Plasticizing control	10-stage speed, pressure, back pressure and free switch over	2-stage speed, pressure, back pressure control
Injection control	Holding 10-stage speed, pressure and back pressure settings	Holding 5-stage injection speed and pressure, 2-stage back pressure settings
Opening/clamping control	5-stage speed and 5-stage pressure	3-stage speed and 3-stage
Location control	4-stage liner input (clamp/injection/ejector/ejection chassis)	3-channel decoder (clamp/ejection chassis/ejector)
Gas-assisted injection	Yes, with 6-stage pressure control	No
Real time clock control	Yes, provide clock for preheating control, historical alarm information, and etc.	No

Ratio voltage output	4-stage pulse width modulation and 4-stage voltage output	4-stage pulse width modulation and 3-stage voltage output
----------------------	---	---

**Notes:** All functions that are described in the instruction manual are not necessarily equipped in the machine. The function of the machine is determined by the standard configuration of the model plus the purchased option device.

## Index


3.1	Introduction on the computer panel			
3.1.1	Diagram of the computer panel	.....	4	
3.1.3	Forming condition control button	.....	6	
3.1.3	Forming condition numeric data button	.....	6	
3.1.4	Manual operation button and instruction	.....	8	
3.1.5	Power switch	.....	8	
3.2	Instruction on the computer operation screen			
3.2.1	Power on test	(00) Screen	.....	9
3.2.2	Running and temperature setting	(01) Screen	.....	10
3.2.3	Temperature and temperature discrepancy alarm setting	(02) Screen	.....	11
3.2.4	Opening/clamping parameter setting	(03-04) Screen	.....	12
3.2.5	Ejection and blow	(05-06) Screen	.....	14
3.2.6	Core and unscrew	(07) Screen	.....	17
3.2.7	Injection setting	(08) Screen	.....	19
3.2.8	Barrel setting	(09) Screen	.....	21
3.2.9	Injection/barrel stage setting	(10) Screen	.....	23
3.2.10	Gas-assisted injection and multi-group pump	(11) Screen	.....	24
3.2.11	Mold adjustment setting	(12) Screen	.....	25
3.2.12	Injection chassis and auto clearing setting	(13-15) Screen	.....	26
3.2.13	Initial data setting	(16-23) Screen	.....	29

3.2.14	Forming mold no. and time setting	(24) Screen	.....	41
3.2.15	Mold no. selection and mold no. overwriting	(25) Screen	.....	42
3.2.16	Quality record setting	(26-27) Screen	.....	43
3.2.17	Diagrams of injection	(28-32) Screen	.....	45
3.2.18	Program status test	(33) Screen	.....	50
3.2.19	Input and output test	(34-35) Screen	.....	51
3.2.20	Status test	(36) Screen	.....	53
3.2.21	Timer test	(37-39) Screen	.....	54
3.2.22	Counter test	(40) Screen	.....	57
3.2.23	Language selection and clock setting	(41) Screen	.....	58
3.2.24	Historical alarm	(42) Screen	.....	59
3.2.24	Help	(43) Screen	.....	60
3.2.26	Notes on password	(44-48) Screen	.....	61


### 3.3 Introduction on the computer alarm

### 3.1 Introduction on the computer panel

#### 3.1.1 Computer panel




### 3.1.2 Forming condition control button




The keyboard has the following function:

- (1) Select the forming operation status



- (2) Able to set the location, speed, pressure, time and counter in the forming condition
- (3) Able to set the data needed by the auto mold adjustment
- (4) Able to amend the mold and overwrite the mold no.
- (5) Able to select the function or movement that are needed in the forming as per the need of product and die design



- (6) Able to press  to move to the intended location for data amendment under any operation screen
- (7)
- (8) Mold and auto door operation share the same button. When using the mold adjustment function, you need to switch to the mold adjustment screen at first. (refer to the second chapter for notes)

### 3.1.3 Forming condition numeric data button

The keyboard has the following function

- (1) Input the numeric data that is needed in the forming condition

Speed setting range: 00~99, when setting as 00, the speed is zero

Pressure setting range: 00~99, when setting as 00, pressure is zero

Location setting range: 0000~999.9mm


Time setting range: 0~6553.5 sec

Counter setting range 0~65535.


Mold thickness value range 0~6553.5 mm.

- (2) Able to check if the keyboard functions normal or not


- (3) Able to read the computer control program




#### (4) Notes for each button




: Number "0" or blank text



: Number "1" or letter "S", "T", "U"



: Number "2" or letter "V", "W", "X"



: Number "3" or letter "Y", "Z", "\_"



: Number "4" or letter "J", "K", "L"



: Number "5" or letter "M", "N", "O"




: Number "6" or letter "P", "Q", "R"




: Number "7" or letter "A", "B", "C"




: Number "8" or letter "D", "E", "F"




: Number "9" or letter "G", "H", "I"



: Reconfirm the data input



: Turn the function on or increase the value by "1"



: Turn the function off or decrease the value by "1"



: Data input



: Adjust the contrast




: Move the cursor to the left



: Move the cursor downward



: Move the cursor to the right








: Move the cursor upward

### 3.1.4 Manual operation buttons and notes



(1) The manual operation keyboard can independently manipulate a single movement in the whole cycle

### 3.1.5 Power switch

#### (1) Emergency stop button



This red button is located in the right bottom of the operation panel of the computer. Press this button to power off the machine. To restart the machine, you need to rotate the button as per the direction of the arrow to loosen the button.

#### (2) Start-up button

This green button is located below the emergency stop button. Press this button to power on the control unit of the machine. This function can effectively protect the computer system.

(3) There is a high performance manostat within the machine, which is able to beat the voltage input ranging AC90V – AC265V 50/60HZ

### 3.2 Instruction on the operation screen


#### 3.2.1 Power on test



Screen 00




- (1) Screen (00) appears when the system runs an auto test after power on. This screen shows the machine model, machine no. program, and etc. It is automatically switched to the running screen after 3 seconds.
- (2) In case of maintenance or technical inquiry is needed, please advise the machine model, machine no. and program shown above to the customer service staff to obtain fast service.


## 3.2.2 Running and temperature setting





Screen 01


Screen (01) is displayed when running

If you press  button or  button or  button, then screen (01) will also be brought forward. You can find various parameters such as filling time, cycle time, formed no., temperature in each stage, and the current operation of the machine. You can also set the injection time, cooling time, and the recycle time by moving the cursor to the corresponding location


with  button and input the intended time with the numeric button,

followed by pressing  button to complete the modification.


When you activate the parameter to be modified with the cursor  button. The maximum and minimum value of the parameter will be prompted on the screen.


When you activate the function to be modified with the cursor  button. The buttons to be needed to press will be prompted on the screen.

## 3.2.3 Alarm setting on temperature and temperature discrepancy




Screen 02




Press  button to bring forward the screen (02). Screen (01) and screen (02) can be freely switched over. In screen (02) as shown above, from the left to the right there are setting on nozzle temperature, 1<sup>st</sup> stage temperature, 2<sup>nd</sup> stage temperature, 3<sup>rd</sup> stage temperature, 4<sup>th</sup> stage temperature, 5<sup>th</sup> stage temperature (as needed by the tonnage of the machine), 6<sup>th</sup> stage temperature (as needed by the tonnage of the machine) and oil temperature. In the setting of each stage temperature, there is alarm setting on the maximum and minimum value. The maximum value can be set to +50 and the minimum value -50. In addition, MPC40 has the function of holding temperature, and setting the time daily for starting the temperature holding.

The setting methods of various function and parameters are as below,








Press  button to activate the parameter to be modified, then input the

INPUT

intended value and press  to complete. When one parameter is activated, the input range of it will be shown at the bottom of the screen.


The temperature holding function and daily temperature starting function can

be activated by press  button to get activated, followed by press  or  button to select enable or disable the function.

Setting on the group B temperature: press  button and move the cursor to group A till it turns black, then press  and wait the appearance of "?", then just press the confirmation button to set group B temperature.

### 3.2.4 Parameter setting for opening/clamping



#### 1、Parameter setting



OPENING/CLAMPING				2008/01/04(FRI) 13:51			
MAX STROKE		480.0mm		CLAMP PRESS. SW		0 bar	
MAX OIL PRESS.		175bar					
OPEN	SP	PR	POS.	CLAMP	SP	PR	POS.
BREAK	40 %	150 bar	5.0 mm	FAST	85 %	120 bar	12.0 mm
OPEN2				CLAMP2			
OPEN3				CLAMP3			
FAST	85 %	100 bar	440.0 mm	LOW PR	20 %	1 bar	5.0 mm
SLOW	10 %	10 bar	470.0 mm	HIGH PR	40 %	150 bar	20 p
AUX			0.0 mm	AUX			0.0 mm
				LOW PRES.			3.0 s

0bar 1.1mm 1.0mm A 121.5mm B 121.5mm


Screen 03


- (1) Press  or  button to call up screen (03), in which you can set the speed, pressure and location for all stages of opening/clamping mold

- (2) The minimum and maximum stage of mold open is 3 and 5 respectively. 3 stages mean slow, fast and decelerate. 5 stages mean slow, 2<sup>nd</sup> stage, 3<sup>rd</sup> stage, fast and decelerate.


Similarly, the minimum and maximum stage of mold clamp is 3 and 5

respectively. 3 stages mean fast, low pressure and high pressure. Press

cursor button  to select the parameter setting for mold

opening/clamping. Input the intended value followed by pressing  button to complete the setting.

## 2、Accelerate and decelerate setting



Screen 04 displays the settings for mold opening and clamping stages and acceleration/deceleration parameters.

**OPEN CNT. [3] step**

RAMP	SP	PR
OPENING	0.10 s	0.10 s
SLOW OPEN	0.00 s	0.00 s

**M.ADJ OPEN** SP: 0 % PR: 0 bar



**CLAMP CNT. [3] step**

RAMP	SP	PR
FAST CLAMP	0.15 s	0.35 s
CLAMPING	0.10 s	0.10 s

**M.ADJ CLAMP** SP: 0 % PR: 0 bar

Bottom status bar: 0bar, 1.1mm, 1.0mm, 121.5mm, 121.5mm

Screen 04

(1) Press  +  button in screen 03 to call up screen 04, in which you can make setting on the accelerate and decelerate parameter in mold opening/clamping.

(2) The stages of mold opening/clamping can be set here. The maximum and minimum stages are 3 and 5 respectively.

(3) The speed pressure parameter for accelerate/decelerate means the time to be consumed to reach the movement.


(4) To modify the setting, press  button to activate the parameter

first, then input the intended value followed by pressing  button to


complete the setting.

### 3、Notes on mold open/clamp time

#### <1> Notes on mold open time



#### <2> Notes on mold clamp time



### 3.2.5 Ejection and air blow

#### 1、Parameter setting

**EJECTOR/AIR BLOW** 2008/01/04 (FRI) 15:54

MAX STR. 175.0mm EJECT MODE **MULTIPLE**

EJECT PAUSE 0.5 s EJECT COUNT 1 t VIBRATION 0 t

---

	SP	PR	POS.
EJECT OUT1	80 %	80 bar	100.0 mm
EJECT OUT2	50 %	50 bar	175.0 mm

---

	SP	PR	POS.
EJECT IN	80 %	80 bar	100.0 mm
EJECT SLOW	50 %	50 bar	2.0 mm

---

AIR1 OPERATION **OFF**

OPEN END

AIR 1 BLOW 0.0 s

AIR 1 DELAY 0.0 s

---

AIR2 OPERATION **OFF**

AIR2 ST. AT OPEN POS. 0.0 mm

AIR 2 BLOW 0.0 s

AIR 2 DELAY 0.0 s

---

AIR3 OPERATION **OFF**

AIR3 ST. AT OPEN POS. 0.0 mm


AIR 3 BLOW 0.0 s

AIR 3 DELAY 0.0 s

---

0bar 1.1mm 1.0mm A 121.5mm B 121.5mm

Screen 5


- (1) Press  to call up screen (05). You can set various parameters for ejection and blow.

- (2) Press cursor button  to select the parameter setting for

ejection and blow, input the intended value followed by pressing




button to complete the setting.

- (3) Press   button to set the movement style of ejector


- (1) No move
- (2) Ejector stop
- (3) Multiple ejection
- (5) Time setting for ejector stop TIM11 (0~99.9 seconds)
- (4) Times of ejection CNT04 (0~99 times)





- (5) Press cursor button to select ejector forward 1, ejector forward 2, ejector backward or ejector decelerate and etc. Input the


intended value followed by pressing  button to complete the setting.

- (6) Notes for ejector location



- (7) Press cursor button to select blow setting. Input the intended value followed by pressing  to complete the setting.

- (1) You can turn on or off the "Blow movement 1" by pressing  or




to make the setting. This operation starts until the completion of mold open.




Blow time 1: time needed for blow 1

Blow delay 1: time delayed for blow after mold open



(2) You can turn on or off the “Blow movement 2” by pressing



or to make the setting. This operation starts during mold open.


Mold position when blow 2 starts: set the start position of blow 2 during mold open

Blow time 2: time needed for blow 2

Blow delay 2: time delayed for the start of blow 2 after mold positioning.



(3) You can turn on or off the “Blow movement 3” by pressing




or to make the setting. This operation starts during mold open.

Mold position when blow 3 starts: set the start position of blow 3 during mold open


Blow time 3: time needed for blow 3

Blow delay 3: time delayed for the start of blow 3 after mold positioning.

2、Setting for ejector accelerate/decelerate



Screen 06




- (1) Press + in screen 05 to enter the password inputting screen. Screen 06 will be called up after the correct password is input, in which you can make settings on the ejector accelerate/decelerate parameters.

- (2) You can set the add/minus parameter for the ejector and mold adjustment ejector. The mold adjustment ejector is a special function.




- (3) Press the cursor button to select the parameter that needs to be modified. Input the intended value followed by pressing to complete the setting.

### 3.2.6 Core and unscrew




Screen 07



- (1) Press to call up the screen 07
- (2) Within this screen, you can set the parameters for three groups of core.




Press  to activate the parameter, then input the intended value


INPUT

followed by pressing  to complete the setting.

(3) For the 1<sup>st</sup> group you can set as Core 1, Unscrew 1, No move. Press







or



to select.

(4) "Move Style": Press   to select within the following three modes: "Time", "Count" and "Limited Position", of which "Count" is only valid in case of Unscrew.

(5) "Sync Move": Press   to select within the following two modes: "On" and "Off"

(6) "Hold": Press   to select within the following two modes: "On" and "Off"

(7) Core 1 forward position: the position that Core 1 or Unscrew 1 starts to fill core

(8) Core 1 backward position: the position that Core 1 or Unscrew starts to retreat core

(9) Setting on forward 1 speed, pressure or time

Speed: 0% ~ 99%

Pressure: 0 ~ 999bar

Time: 0 ~ 99.9 seconds

(10) Setting on backward 1 speed, pressure or time

Speed: 0% ~ 99%

Pressure: 0 ~ 999bar

Time: 0 ~ 99.9 seconds

(11) The settings for the other two groups are the same of that of the first group

(12) The setting of the other two group are the same with .group one.

## 3.2.7 Injection settings

2008/01/04 (FRI) 13:01

A



MAX STR.	200.0mm	FILLING	0.00s	H.P. TERM	0.0mm
INJ TIME	1.50 s	H.P. CH.	TIME		


H.P.	SP	PR	TIME	INJ	SP	PR	POS.
H.P.1	80 %	150 bar	1.0 s	INJ1	99 %	175 bar	1.0 mm
H.P.2				INJ2			
H.P.3				INJ3			
H.P.4				INJ4			
H.P.5				INJ5			
H.P.6				INJ6			
H.P.7				INJ7			
H.P.8				INJ8			
H.P.9				INJ9			
H.P.10				INJ10			

HOLD REL OFF

0bar 1.1mm 1.0mm A 121.5mm B 121.5mm

Screen 08

- (1) Press  to call up screen (08). Press the cursor button  to select the setting for injection. Input the intended value followed by

pressing  to complete the setting.

- (2) Injection time: 0~999.9 seconds  
 (3) Three modes for holding-pressure switch: "Time" "Location" and "Pressure"  
 (4) 0~999bar  
 (5) Pressure holding stages: 10 stages in total

Speed: 0~99%. The speed for each stage can be set independently.

Pressure: 0~999bar. The pressure for each stage can be set independently.

Time: 0~99.9 seconds. The pressure holding time for each stage can be set independently.



- (6) Injection stages

Speed: 0~99%. The speed for each stage can be set independently.


Pressure: 0~999bar. The pressure for each stage can be set independently.

Position: 0~1999.9mm. The position for each stage injection can be set


independently.


- (7) “Release the holding pressure”: Press   to select to enable or disable to release the holding pressure.

- (8) Time for holding pressure and injection



**Injection B setting:** First press  button and move cursor to group A

until it turns black, then press . After the appearance of “?” just press



button can switch to the screen of setting. The setting method is the same with group A.


## 3.2.8 Plasticization setting

A				2008/01/04 (FRI) 13:00	
MAX STR.	200.0mm		PLAST.	0.00s	
SCR. END	0.0mm				
PLAST.	SP	PR	POS.		
PLAST1	99 %	175 bar	0.0 mm	ALARM T1 0.0 s	
PLAST2				PLAST DL 0.0 s	
PLAST3					
PLAST4					
PLAST5					
PLAST6					
PLAST7					
PLAST8					
PLAST9					
PLAST10					
M.DEC	60 %	50 bar	120.0 mm	PRE.DEC	OFF 0.0 s
<div>  0bar            1.1mm            1.0mm            A 121.5mm            B 121.5mm         </div>					

Screen 09

- (1) There are 10 stages in total in plasticization, each of which has four parameters, including speed, pressure, back pressure and location. To

set the parameter, press



to call up screen (09). Then press

the cursor button



to select the plasticization settings. Input

the intended value followed by pressing

INPUT

to complete the setting.

- (2) Notes on various parameters:



Speed 0~99%



Pressure: 0~999bar (maximum value of the system)

Back pressure: 0~999bar (maximum value of the system)

Location: 0~1999.9mm (the position that the current stage of plast ends)

Backward injection: Speed (0~99%) , Pressure (0~999bar) , Stop position (0~999.9mm)





Backward injection before plast: You can press  or  to enable or disable the function. In the “On” status, the time setting can be 0~999.9 second.


Plasticising time delay: 0~99.9 seconds

Alarm break: 0~999.9 seconds



### (3) Notes on different stage of time of plast



### 3.2.9 Setting on stages of injection/plast





Screen (10)

(1) In screen 09, press  +  to call up the screen 10, within which you can make settings on injection/plast stage and accelerate/decelerate


(2) The stage of injection, holding pressure and plast can be set in screen 10. You can set for 10 stages at most.

(3) The pressure parameter of accelerate/decelerate refers to the time that is consumed to reach the move.

(4) To make setting on the parameter, press  button to activate the parameter to be modified, then input the intended value followed by pressing  to complete the setting.









## 3.2.10 Gas-assisted injection and multiple group pump





Screen(11)

- (1) The function of gas-assisted injection/multiple group pump is newly added

in MCP40. Press  +  in screen 10 to call up the password input screen, and then input the correct password and press  +  twice to call up screen 11.

- (2) By pressing  or , you can enable or disable the gas-assisted injection function. In the "On" status, you can set the gas-assisted time and gas-assisted stop location. To set the parameter,


press  to active the parameter, and then input the intended value followed by pressing  to complete the setting.

- (3) At the same time, we can set 6 group of pump for spare use. You can set the speed or pressure (0~99%) and working time (0~99.99 seconds) for


each pump. You can press  button to activate the parameter,




and then input the intended value followed by pressing INPUT to complete the setting. (Optional)




### 3.2.11 Mold adjustment setting




Screen (12)

(1) Press 
  
 MOLD ADJ.
  to call up the screen 12

(2) Auto mold adjustment: Press the cursor button  to active the setting. Press 
  
 ON
  or 
 OFF  

 to enable or disable the auto mold adjustment function

(3) Teeth mold adjustment: Press the cursor button  to active the setting. Press 
  
 ON
  or 
 OFF  

 button to enable or disable the single teeth mold adjustment function. This function is optional.

(4) Mold thickness selection: 0~6553.5mm. Press the cursor button



to active the setting, then input the intended mold thickness value followed by pressing  to complete the setting.

- (5) The setting for mold adjustment speed (0~99%) and pressure (0~999bar) can be activated by pressing the cursor button






, then input the intended value followed by pressing  to complete the setting.



### 3.2.12 Injection chassis and auto clearing setting

#### 1、Parameter setting



《 NOZZ/COLOR CH./LUBE 》				2008/01/04 (FRI) 15:56	
<input type="text" value="A"/>					
NOZZ OUT MODE <input type="text" value="NOZZ LOCK"/>					
FST.IN <input type="text" value="50"/> % <input type="text" value="50"/> bar <input type="text" value="LIMIT SW"/>			OUT <input type="text" value="50"/> % <input type="text" value="50"/> bar <input type="text" value="1.5"/> s		
SL.IN <input type="text" value="50"/> % <input type="text" value="50"/> bar <input type="text" value="1.0"/> s					
AT COL. CH. <input type="text" value="OFF"/>			EVERY 10CYC. LUB ONECE		
CH.COUNT <input type="text" value="0"/> t			REMAINING 10CYCLE TO LUBE		
CH.TIME <input type="text" value="0.0"/> s			TOTAL LUBE 0.0s		
			LUBE PERIOD 15.0s		
			ALARM TIME 0.1s		
INJ <input type="text" value="0"/> % <input type="text" value="0"/> bar <input type="text" value="0.0"/> mm					
PLAST. <input type="text" value="0"/> % <input type="text" value="0"/> bar <input type="text" value="0.0"/> s					
M.DEC <input type="text" value="0"/> % <input type="text" value="0"/> bar <input type="text" value="0.0"/> mm					
<div> <input type="text" value="0bar"/> <input type="text" value="1.1mm"/> <input type="text" value="1.0mm"/> <input type="text" value="121.5mm"/> <input type="text" value="121.5mm"/> </div>					



图 13

(1) Press  or  or  to call up the screen (13)

(2) Press  button to select the parameter, input the intended value followed by pressing  button to complete the setting.

Of which there are:

Injection chassis movement: there are three styles including before plast, after plast and fixed, the setting of which can be achieved by pressing  or  button.


The “Auto Clearing” function can be enabled or disabled, which can be achieved by pressing  or  button.

Various movements including fast chassis, slow chassis, chassis backward, injection, plast, injection backward can be determined by three parameters including speed, pressure, and location. The value shown in the screen is the maximum value.


The “Auto Clearing” function is determined by two parameters “Times” and “Time”.

(3) Other data shown in the screen are tested data by the computer.

(4)





## 2、Setting on accelerate/decelerate



Screen (14)

(1) In the chassis screen, press  +  to call up the screen (14)


(2) Press  button to select the parameter to be modified, then input the intended value followed by pressing  button to complete the setting.

Of which there are:




The speed and pressure parameter behind the chassis refers to the time that is needed by accelerate/decelerate until the chassis reaches the ultimate speed.

The speed and pressure parameter behind the mold adjustment chassis refers to the speed and pressure that the chassis reaches in the end.

### 3、Setting on backup speed and pressure



Screen (15)




- (1) Press  +chassis to call up the screen (15)
- (2) Press  button to select the parameter to be modified, input the intended value followed by pressing  button to complete the setting.


### 3.2.13 Setting on initial data

#### 1、Use of special function



《ORIGIN DATA》		2011/10/19(WED) 9:25	
LUB MODE	TIME		
OPEN DOOR GATE	OFF	NOZZLE	PID
SYN. FUNC	OFF	TEMP1 (1-A)	PID
EJECT→GATE	ENA	TEMP2 (2-A)	PID
B EJECTOR USE	ON	TEMP3 (3-A)	OFF
MD HI SP	TYPE1	TEMP4 (NOZZ)	PID
GATE MANU	ENA	TEMP5 (1-B)	PID
B.P. SEL	OFF	TEMP6 (2-B)	PID
OP CL FAST	OFF	OIL TEMP	WATCH
NOZZ A USE	ENA	TELEPHONE	852-26653222
PHOTO DET.	ENA	FACSIMILE	852-26641115
PUMP QUA	1pc	MODEL	JN268-S
SPEC CORE	DIS	SER. No.	123456
INJ PRESS	ENA	DATE	2006/05/05
PLA.TORQUE	ENA		
915:PLS SEARCH GATE ORIGIN			
0bar	498.1mm	0.0mm	2.2mm

Screen(16)

- (1) Press  + mould open to enter the password screen, input the correct password, then press  +  to enter the screen (16)



- (2) Press  to select the function  
Of which there are:

Lubrication style: three styles including “Spare”, “Time” and “Switch”.



Press  or  to make settings.

Chassis movement style: you can choose “Location: or “Time” control.  
The standard machine uses the “Time” control.



Rear safety door: there are two statuses, “On” and “Off”, which can be

selected by pressing  or  button. “On” means to inspect the rear safety door, and “Off” means not to inspect the rear safety door (Optional)



Interlink function: there are two statuses: "On" and "off", which can be

selected by pressing  or  button (Optional)



Fast injection: there are two statuses: "Use" and "Not in use", which can

be selected by pressing  or  button (Optional)



Ejection B use: there are two statuses: "In use" and "Not in use", which

can be selected by pressing  or  button.


Fast style: there are two statuses: "Style 1" and "Style 2", which can be

selected by pressing  or  button.



Turnplate manual operation: there are two statuses: "In use" and "Not in

use", which can be selected by pressing  or  button (Optional)

Rear pressure selection: there are two statuses: "On" and "off", which

can be selected by pressing  or  button.

Fast opening clamping: there are two statuses: "On" and "Off", which can

be selected by pressing  or  button.(Optional)

Injection platform A use: there are two status: "Use" and "Not in use",






which can be selected by pressing  or  button.

Photo sensor test: there are two statuses: "Use" and "Not in use", which

can be selected by pressing  or  button.


Number of pump: The number can be selected by pressing  or






button (Optional).

Special core: there are five statuses: “Style 1”, “Style 2”, “Style 3”, “Style 4”, “Style 5” and “Not in use”, which can be selected by pressing




or




button.

Injection pressure: there are two status: “Use” and “Not in use”, which




or




button (Optional).

can be selected by pressing  
This is an optional function.

Plast torque: there are two statuses: “Use” and “Not in use”, which can




or




button (Optional).

be selected by pressing  
This is an optional function.

There are three settings: “Manual”, “PID”, and “Not in use” for “Nozzle”, “Temperature 1”, “Temperature 2”, “Temperature 3”, “Temperature 4”, “Temperature 5”, “Temperature 6”, which can be selected by pressing



or



button.

(3) “Tel”, “Fax”, “Machine Model”, “Model number”, “Manufacture Date”: Press





the intended value followed by pressing to completing the setting.



## 2、Adjust the function setting.

	UPPER		LOWER
OIL PRESS.	175	bar	
LOW PRES.	7.0	s	3.0 s
L.P.CLAMP POS.	50.0	mm	1.0 mm
L.P.CLAMP PR	30	bar	
H.P.CLAMP POS.	500	p	
M.DEC SP	60	%	
M.DEC PR	60	bar	
MOLD THICK	510.0	mm	200.0 mm
SLOW EJECT POS.	5.0	mm	
OPEN END RANGE	0.0	mm	0.0 mm
OIL TEMP	60	°C	
M.ADJ FOR SP	50	%	
M.ADJ FOR PR	80	bar	
M.ADJ BACK SP	50	%	
M.ADJ BACK PR	80	bar	
COOL TEMP	0	°C	0 °C
			BK LIGHT OFF 30 min
			RPM Gear 1

0bar 1.1mm 1.0mm A 121.5mm B 121.5mm

Screen(17)

(1) In screen (16), keep pressing  +  button to enter screen (17)

(2) Press  button to select the function, input the intended value followed by press  button to complete the setting.

(3) The value shown in the screen above is the maximum value of the parameters. The maximum and minimum values that are set here are used to define the parameter setting of various functions under their owing setting screen.

## 3、Setting on location of mold clamp

**ORIGIN DATA** 2008/01/04 (FRI) 14:09

	MOLD POS.	EJECT	SCREW A	SCREW B
MAX STROKE	480.0 mm	175.0 mm	200.0 mm	160.0 mm

	ACTUAL	MIN	MAX
MOLD POS.	2070 1.1mm	2068 1.0 mm	15603 480.0 mm
EJECT POS.	81 1.0mm	80 1.0 mm	13513 175.0 mm
SCREW POS. A	8422 121.5mm	78 1.0 mm	13855 200.0 mm
SCREW POS. B	10980 121.5mm	237 1.0 mm	14409 160.0 mm

	OIL PRESS.
	0 0bar 0 0 bar 175 175 bar



	ACT.	MIN	MAX
MOLD THICK.	0.0 mm	200.0mm	510.0mm



  

FLASH ALL SAVE LOAD FD FORMAT

0bar 1.1mm 1.0mm A 121.5mm B 121.5mm

Screen (18)

- (1) In screen (17), press  +  button to call up screen (18), which is the adjust screen of electronic ruler.

- (2) Press  button to select the parameter, input the intended value followed by pressing  button to complete the setting.

Of which there are:



There are three parameters are available for adjustment: “Current”, “Minimum” and “Maximum” for the four function positions, which are “Clamp position”, “Injection A position”, “Injection B position”, and “Ejection position”. Each parameter has two values. The left value is the sensor data of the position sensor, and the right value is the actual stroke to be needed.

There are three parameters are available for adjustment: “Current”, “Minimum” and “Maximum” for the “Oil pressure” function. Each parameter has two values. The left value is the data of the pressure sensor, and the right value is the

actual pressure to be needed.

There are three parameters available for adjustment: "Current", "Minimum" and "Maximum" for the "Mold Adjust thickness" function. The "Minimum" parameter refers to the thickness of the thinnest mold that can be installed on the machine. The "Maximum" parameter refers to the thickness of the max mold that can be installed on the machine. The "Current" parameter refers to the actual thickness of the mold that is installed on the machine.

- (3) At the bottom of the screen shows the save function. There are two parameters available for adjustment. The first parameter is the store device with two selections "FLASH" and "FD". The second parameter is the type of parameter that is saved with three selections "ALL", "LIMIT" and "MOLD COM". The selection of the parameter can be achieved by

pressing the  or  button. In addition there are three function button "SAVE", "LOAD" and "FD FORMAT", which can save the data to the storage device, or read the data from the storage device, or format the floppy the disk.

FLASH means to save the current parameters to the storage device of MPC40.

FD means to save the current parameters to the 3.5" floppy disk.

ALL means to select all parameters.

LIMIT means to select the position parameter only.

MOLD COM means to only save the forming condition.

- (4) Data adjustment method for the position sensor

In all the parameters above, the mold clamp position, injection A position, injection B position and ejection position are corresponding to the position sensor. Take the mold clamp position as an example. The adjustment is as below,

- A. Set the maximum stroke of the mould clamp position, i.e. as 3000
- B. Set the minimum value of the mould clamp position as "0". Then take the mold clamp position to the end, and read the sensor data of the position sensor at the left of the current parameter. Put the data into the input area at the left of the minimum parameter. (In the actual test, to prevent the interference of the electronic noise, the input value should be more than the actual value by 2. For example, if the sensor data of the position sensor is 500, then the input should be 502)
- C. Set the maximum value: Set the data of the position sensor as the maximum at the left to the parameter. (For example as 16383). Set the right parameter as the maximum stroke (For example as 3000), and then open the mold to the end. Read the sensor data of the

position sensor at the left to the current parameter, and input the value to the input area at the left to the maximum parameter. (In the actual test, to prevent the interference of the electronic noise, the input value should be less than the actual value by 2. For example, if the sensor date of the position sensor is 16383, then the input should be 16381)

- D. Apply the same procedure to the other parameters. By take the move to the maximum or minimum end you can get the corresponding value.

#### 4、Output revision setting

《ORIGIN DATA》 2008/01/04 (FRI) 15:06

D/A ADJ



SP		PR		BP		SP2	
1	% 20	10	bar 8	10	bar 50	1	% 20
15	% 185	25	bar 95	30	bar 150	15	% 170
30	% 290	50	bar 190	60	bar 270	30	% 280
50	% 410	75	bar 305	80	bar 350	50	% 395
60	% 475	100	bar 365	100	bar 420	60	% 450
75	% 560	125	bar 450	120	bar 490	75	% 535
90	% 640	150	bar 545	140	bar 555	90	% 615
99	% 700	175	bar 680	160	bar 630	99	% 680

MUL. PUMP

	SP		SP		SP		SP
R511	0 %	R512	0 %	R513	0 %	R514	0 %
R515	0 %	R516	0 %	R517	0 %	R518	0 %

0bar 1.1mm 1.0mm A 121.5mm B 121.5mm

Screen (19)

- (1) In screen (18), press  +  to enter the screen (19)

- (2) Press  to select the function. Then input the intended value

followed by pressing  button to complete the setting.

- (3) The value shown on the screen is the maximum value of the parameter. The maximum and minimum values are used to limit the range of setting of various functions.

- (4) This screen shows the function when the machine makes a linear adjustment

There are four parameters including “speed”, “pressure”, “backup pressure” and “speed 2”. The “speed” parameter is used to adjust the linear function of system flow valve. The “pressure” parameter is used to adjust the linear function of the system pressure valve. The “backup pressure” and “speed 2” are special parameters, which are optional and should be selected as per the function of the machine.

The instruction on the adjustment of the parameters is shown as below,

“Pressure”: This parameter corresponds two parameters. The left parameter is the actual output pressure of the machine. The right parameter is the volume that the computer outputs to the system pressure valve.

To adjust the parameter, set the output pressure value at the bottom as the maximum pressure of the machine, i.e. 175 bar. Then set the speed and pressure of the chassis moving forward. Check if the value in the pressure gauge is the giving value, i.e. 175bar. If not, then change the value corresponding the “output pressure value” until the pressure shown in the pressure gauge matches the given pressure, i.e. 175bar. For the other parameters, just set at a step-by-step reduction by 10% or 20%.

“Speed” parameter: the setting is similar to that of the “pressure” parameter. Set the maximum value first, then reduce step-by-step pro rata. The left parameter is the percentage of the actual output of the machine. The right parameter is the volume that the computer outputs to the system pressure valve.

To adjust the parameter, just set the percentage of the final output as the maximum value (99%). Then set the maximum speed (99%) of a specific stage of plast (i.e. the last stage) in the plast screen. Give a certain pressure (i.e. 50 bar), then start the plast (pasticising) operation. Check if the rotation speed of the gauge matches. Of not, then adjust the right parameter to make it consistent. Set other parameters by a step-by-step reduction at 10% or 20% pro rata.

“Backup pressure” and “speed 2” can be adjusted accordingly, too.





- (5) The “multiple oil pump” is an optional function.

## 5、Setting on various time relay.


SET		SET		SET	
EJT DLY	0.0 s	ACC. DLY	0.10 s	T60	0.1 s
T09	0.1 s	AUX	0.10 s	T61	0.2 s
T10	0.1 s	T39	0.30 s	T62	0.0 s
SCREW1	3.0 s	SCREW2	0.1 s	T63	0.1 s
UNSCR1	0.3 s	UNSCR2	0.1 s	T64	0.0 s
S.SCREW1	0.5 s	S.SCREW2	3.0 s	T65	1.5 s
S.UNSCR1	1.5 s	S.UNSCR2	0.0 s	T66	1.0 s
Y → Δ	3.0 s			T67	0.0 s
MOLD ADJ CNT	2.0 s			T68	0.0 s
VENT	0.10 s	T53	1.0 s	T69	0.0 s
CLA. DLY	0.10 s	T54	0.0 s		
CORE DLY	0.00 s	T55	0.0 s		
SCREW DL	0.00 s				
LUBE PERIOD	15.0 s				
ALARM TIME	0.1 s				
DECOMP	0.1 s	T59	0.1 s		

0bar 1.1mm 1.0mm A 121.5mm B 121.5mm

Screen (20)

- (1) In screen (19), press  +  to enter screen (20), which is to set the time of various relay during the control
- (2) Press  to select the function, input the intended value followed by pressing  button to complete the setting.
- (3) The values shown in the screen are the maximum value of various parameters. The maximum value and the minimum value that are set here are used to limit the setting range of the parameters of various functions.

## 6、Setting on the special time relay



Screen (21)

- (1) In screen (20), press + button to enter the screen (21), in which you can set the time for the special time relay in the control of the machine.

- (2) Press button to select the function. Input the intended value

followed by pressing button to complete the setting.

- (3) The values shown in the screen are the maximum value of various parameters. The maximum value and the minimum value that are set here are used to limit the setting range of the parameters of various functions.



## 7、Setting on various counters

《ORIGIN DATA》 2011/10/19 (WED) 14:58



	SET		SET
BATCH SIZE	65000 t	GATE CORE	1 t
EVERY	5 t	COL.CH CNTB	0 t
AUX	0 t	GATE AUTO 2	1 t
AUX	0 t	C25	0 t
AUX	0 t	C26	0 t
C12	0 t	C27	0 t
C13	0 t	C28	0 t
NOS.OFEJE.B	1 t	C29	0 t
C15	0 t	C30	0 t
GATE AUTO 1	1 t	C31	0 t

915:PLS SEARCH GATE ORIGIN

0bar 486.5mm 0.1mm A 115.5mm B 1.0mm

Screen (22)

- (1) In screen (21), press  +  button to enter the screen (22), in which you can set various counters in the control of the machine.

- (2) Press  button to select the function. Input the intended value followed by pressing  button to complete the setting.





- (3) The values shown in the screen are the maximum value of various parameters. The maximum value and the minimum value that are set here are used to limit the setting range of the parameters of various functions.

## 8、 Setting on closed ring control function

《ORIGIN DATA》		2008/01/04 (FRI) 15:08	
INJ SPEED FEEDBACK	DIS	HOLD PRESS FEEDBACK	DIS
P PARAMETER	0	P PARAMETER	0
I PARAMETER	0	I PARAMETER	0
D PARAMETER	0	D PARAMETER	0
PLAST FEEDBACK	DIS	INJ MAX SPEED	0.0 mm/s
P PARAMETER	0	PLAST MAX SPEED	0 rpm
I PARAMETER	0		
D PARAMETER	0		
1	0		
2	0		
3	0		
4	0		
5	0		

0bar 1.0mm 1.0mm A 121.5mm B 121.5mm


Screen (23)



- (1) In screen (22), press  +  button to enter the screen (23), in which you can set the P.I.D parameters in the closed ring function of the machine.
- (2) Press  button to select the function. Input the intended value followed by pressing  button to complete the setting.
- (3) The values shown in the screen are the maximum value of various parameters. The maximum value and the minimum value that are set here are sued to limit the setting range of the parameters of various functions.

## 3.2.14 Setting on forming and time

《TIMER/COUNTER》				2008/01/04 (FRI) 15:57	
	SET		ACTUAL		
COOLING	6.0 s		0.0s		
RECYCLE	1.0 s		0.0s		
CYC. ALAR	60.0 s		0.0s		
	SET		ACTUAL		
CYCLE NO	300 t		260 t		
DEFECT	0 t		0 t		
PRODU. TIME	0.0 Hr		0.0 Hr		
	0bar		1.1mm		1.0mm
	A 121.5mm		B 121.5mm		

Screen (24)

(1) Press  to call up the screen (24)



(2) Press  button to select the function. Input the intended value followed by pressing  button to complete the setting.

The “set” parameters of various functions can be set, while the “current” parameter is the actual parameter that has been tested by the computer. The values shown in the screen are the maximum value of various parameters.

## 3.2.15 Selection on mold number and mold number overwrite



MOLD DATA		2008/01/04 (FRI) 15:58	
001:	008:	015:	022:
002:	009:	016:	023:
003:	010:	017:	024:
004:	011:	018:	025:
005:	012:	019:	026:
006:	013:	020:	027:
007:	014:	021:	028:
MOLD POS. <input type="text" value="RAM"/> MOLD No. <input type="text" value="1"/> NAME <input type="text"/>			
MOLD DATA SAVE&COPY <input type="text" value="FORMAT"/>			
MOLD	<input type="text" value="1"/>	COPY TO MOLD	<input type="text" value="1"/>
MOLD	<input type="text" value="1"/> TO <input type="text" value="1"/>	SAVE TO FD	<input type="text" value="1"/>
FD	<input type="text" value="1"/> TO <input type="text" value="1"/>	COPY TO MOLD	<input type="text" value="1"/>
MOLD SELECT <input type="text" value="1"/>			
<input type="button" value="0bar"/> 0bar <input type="button" value="1.1mm"/> 1.1mm <input type="button" value="1.0mm"/> 1.0mm <input type="button" value="A 121.5mm"/> A 121.5mm <input type="button" value="B 121.5mm"/> B 121.5mm			

Screen (25)

- (1) Press  to call up screen (25)
- (2) Press  button to select the function. Input the intended value followed by pressing  button to complete the setting.

Of which, there are:

Find location: there are two locations, which are “computer memory” and

“floppy disk”. You can press  or  to select.

During the access operation on the mold number data, you can save the data corresponding to the mold number to the floppy disk. In addition, you can also save the data corresponding to the mold number in the floppy disk to the computer.

## 3.2.16 Setting on quality statistics







## 1、Parameter setting

《QUALITY STATISTIC》 2008/01/04 (FRI) 15:59

EACH  CYCLE

	STD.	TOL.				MAX	MIN	AVE.
CYCLE				260	260	260		
OPEN TIME	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="text" value="OFF"/>	0.00	0.00	1.92	90.01	0.00 3.58
CLAMP TIME	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="text" value="OFF"/>	0.00	0.00	2.83	2.86	0.00 2.58
INJ TIME	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="text" value="OFF"/>	0.00	0.00	1.50	1.50	0.00 1.41
PLAST. TIME	<input type="text" value="0.00"/>	<input type="text" value="0.00"/>	<input type="text" value="OFF"/>	0.00	0.00	0.00	0.00	0.00 0.00
CYCLE TIME	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>	<input type="text" value="OFF"/>	0.0	0.0	4.4	***.*	0.0 40.3
H.P.CH.POS.	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>	<input type="text" value="OFF"/>	0.0	0.0	1.0	1.0	0.0 0.9
H.P.END POS.	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>	<input type="text" value="OFF"/>	0.0	0.0	1.0	1.0	0.0 0.9
PLA.END POS.	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>	<input type="text" value="OFF"/>	121.5	121.5	94.5	122.4	6.6 119.7
OPEN END POS.	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>	<input type="text" value="OFF"/>	1.1	1.1	1.0	480.1	1.0 411.5
MAX INJ SP.	<input type="text" value="0.0"/>	<input type="text" value="0.0"/>	<input type="text" value="OFF"/>	0.0	0.0	166.1	191.4	0.0 140.7
QUALITY				0	0	0		
PRO.TIME	0.0h	GOOD PROD.	260t	DEFECT	0t	RATIO	0.0%	
<input type="button" value="0bar"/> <input type="button" value="1.1mm"/> <input type="button" value="1.0mm"/> <input type="button" value="A 121.5mm"/> <input type="button" value="B 121.5mm"/>								

Screen (26)

- (1) Press  to call up the screen (26)
- (2) Press  button to select the function.  
There are two parameters "Standard" and "Offset" available for selection.
- Input the intended value followed by pressing  to complete the setting.
- Each function has two status "Enabled" and "Disabled". You can press  or  button to select between them.
- (3) There are "Data reset" and "Save" function in the screen. You can press  button to activate the button, then press  button to complete the setting.

## 2、 Quality statistics display

《 QUALITY STATISTIC 》											2008/01/04 (FRI) 15:59	
	OPEN	CLAMP	T I M E			A	HLD PR	E N D P O S .			MAX SPEED	
			INJ	PLAST	CYCLE	CH POS		H.P.	PLAST.	OPEN	INJ	
MAX	0.00	0.00	0.00	0.00	0.0	0.0		0.0	0.0	0.0	0.0	
MIN	0.00	0.00	0.00	0.00	0.0	0.0		0.0	0.0	0.0	0.0	
AVE.	0.00	0.00	0.00	0.00	0.0	0.0		0.0	0.0	0.0	0.0	
0bar            1.1mm            1.0mm            A 121.5mm            B 121.5mm												

Screen (27)

- (1) Press “Statistics” twice, or press + in screen (26) to call up the screen (27)
- (2) The values shown in this screen cannot be modified. They are the parameters that have been tested by the computer.

## 3.2.17 Screen display of plasticizing

## 1、Screen display of plasticizing end







图 (28) Screen (28)





- (1) Press  to call up the screen (28)
- (2) The central position 0 is the setting value of position when the 4<sup>th</sup> stage plasticizing ends. The screen display is the  $\pm$  value that the position when the actual plasticizing ends comparing with the position when the 4<sup>th</sup> stage plasticizing ends.
- (3) To clear the screen, you can reset the data in the quality statistics screen.
- (4) The screen display can be printed out by the computer.
- (5) The maximum value of the coordinator in the screen display is 9.9mm, which can be set by inputting the value.

## 2、 Display of injection pressure curve




Screen (29)



- (1) In screen (28), press  +  button to call up the screen (29).
- (2) This screen displays the pressure curve when the injection controlled by position switches to the pressing holding process controlled by time. The left is time control, the right is position control, and the 0 line in the middle is pressure holding switching position.
- (3) This function has two items: "Standard save" and "Standard line display". The "Standard save" function can define the current curve as the standard curve and save it. The "Standard line display" can read the saved standard line to compare with the actual curve.
- (4) To clear the screen, you can reset the data in the quality statistics screen.
- (5) The screen display can be printed out by the computer.



## 3、Display of injection speed curve



Screen (30)

- (1) In screen (29), press  +  button to call up the screen (30).
- (2) This screen displays the speed curve when the injection controlled by position switches to the pressing holding process controlled by time. The left is time control, the right is position control, and the 0 line in the middle is pressure holding switching position. The maximum value of the speed parameter in the screen is 1999.9mm/s, which can be determined by inputting the intended value.
- (3) This function has two items: “Standard save” and “Standard line display”. The “Standard save” function can define the current curve as the standard curve and save it. The “Standard line display” can read the saved standard line to compare with the actual curve.
- (4) To clear the screen, you can reset the data in the quality statistics screen.
- (5) The screen display can be printed out by the computer.

## 4、Display of plast back pressure curve









图 (31) Screen (31)

- (1) In screen (30), press  +  button to call up the screen (31).
- (2) The position coordinator in the screen refers to the position of the shaft when the plast is in process. The back pressure coordinator refers to the back pressure of the plast.
- (3) This function has two items: "Standard save" and "Standard line display". The "Standard save" function can define the current curve as the standard curve and save it. The "Standard line display" can read the saved standard line to compare with the actual curve.
- (4) To clear the screen, you can reset the data in the quality statistics screen.
- (5) The screen display can be printed out by the computer.

## 5、Display of plast speed curve



Screen (32)

- (6) In screen (31), press  +  button to call the screen (32).
- (7) The position coordinator in the screen refers to the position of the shaft when the plast is in process. The speed coordinator refers to the speed of the plast.
- (8) This function has two items: “Standard save” and “Standard line display”. The “Standard save” function can define the current curve as the standard curve and save it. The “Standard line display” can read the saved standard line to compare with the actual curve.
- (9) To clear the screen, you can reset the data in the quality statistics screen.
- (6) The screen display can be printed out by the computer.

## 3.2.18 Program contents and status check

CIRCUIT MONITOR					2008/01/04 (FRI) 14:04	
					● : ON SET	○ : OFF ACTUAL
0000	LD	0104	○			
0001	TIM	T54	○		0.0	0.0
0002	LD	0116	○			
0003	TIM	T62	○		0.0	0.0
0004	LD	0625	○			
0005	AND	0617	○			
0006	OR	0121	○			
0007	AND	1091	○			
0008	AND	0007	●			
0009	AND	0018	○			
0010	ANI	1072	○			
0011	AND	1221	○			
0012	AND	0600	●			
0013	OUT	0121	○			


  




OUT	0	TIM	0	CNT	0
-----	---	-----	---	-----	---

0bar	1.1mm	1.0mm	121.5mm	121.5mm
------	-------	-------	---------	---------


Screen (33)




- (1) Press  to call up the screen (33)
- (2) This is a trapeziform graphics in the computer. When the dot below the status bar is black, it means there is signal. When the dot is with no color, it means there is no signal. You can press  button to scroll the display.
- (3) There is a search function. Just input the circuit node value in the text area next to “OUT” “TIM” “CNT” and press  button. The circuit node to be searched will be shown in the screen.



## 3.2.19 Inspection on input and output

## 1、Monitor the input point




Screen (34)





- (1) Keep pressing  button to call up the screen (34)
- (2) This screen shows the status of the input point of the machine. When the dot is black, it means there is signal. When the dot is white, it means there is signal. You can press  button to scroll the display.

## 2、Monitor the output point



Screen (35)



- (1) Keep pressing  button to call up the screen (35)
- (2) This screen shows the status of the input point of the machine. When the dot is black, it means there is signal. When the dot is white, it means there

is signal. You can press  button to scroll the display.

## 3.2.20 Status monitor






图 (36) Screen (36)


- (1) Press  to call up the screen (36)
- (2) This screen shows the status of the internal relay in the program. The location of the dot is “××××” plus the column number. When the dot is black, it means there is signal. When the dot is white, it means there is signal. You can press  button to scroll the display.





【TIMER MONITOR】			2011/10/19 (WED) 15:02		
	SET	ACTUAL		SET	ACTUAL
CORE2 OUT	0.0s	0.0s	AIR 2 DELAY	0.0s	0.0s
NOZ. IN FAST	0.5s	0.0s	COL.CH PLA.	0.0s	0.0s
SEARC ALARM	80.0s	0.0s	T53	0.0s	0.0s
EJT. DLY B	0.20s	0.20s	NOZ. IN A	5.0s	0.0s
EJT DLY B	0.50s	0.50s	PLAST DL B	0.2s	0.2s
T39	0.50s	0.50s	COLOR CH.	0.0s	0.0s
CORE3 IN	0.0s	0.0s	TOTAL LUBE	***. *s	0.0s
CORE3 OUT	0.0s	0.0s	T58	***. *s	0.0s
CLP DLY OFF	0.3s	0.3s	EJT DLY B	0.2s	0.0s
OP MOLD OFF	0.3s	0.3s	OP END DLY	0.5s	0.5s
ORIGI REVER	2.0s	0.0s	EJT VIC A	0.5s	0.0s
OPEN BP	0.5s	0.0s	NOZ. IN B	5.0s	0.0s
AIR 1 BLOW	0.0s	0.0s	STOPT DLY OF	0.2s	0.2s
AIR 2 BLOW	0.0s	0.0s	T64	0.0s	0.0s
AIR 3 DELAY	0.0s	0.0s	NOZ BACK B	1.0s	0.0s
AIR 3 BLOW	0.0s	0.0s	NOZ. IN FASTB	0.5s	0.0s
AIR 1 DELAY	0.0s	0.0s	T67	0.3s	0.0s
915:PLS SEARCH GATE ORIGIN					
0bar		486.5mm		0.1mm	
A 115.5mm		B 1.0mm			

Screen (38)

(1) Keep pressing  to call up the screen (38)

(2) This screen can check the set value and current value of various time

relays. Press  to scroll the display.


《TIMER MONITOR》			2011/10/19 (WED) 15:03		
	SET	ACTUAL		SET	ACTUAL
COLOR CH. B	0.0s	0.0s	HOLD B 6	0.0s	0.0s
T69	0.0s	0.0s	HOLD B 7	0.0s	0.0s
TIM70	0.00s	0.00s	HOLD B 8	0.0s	0.0s
TIM71	0.00s	0.00s	HOLD B 9	0.0s	0.0s
TIM72	0.00s	0.00s	HOLD B 10	0.0s	0.0s
TIM73	0.00s	0.00s	HOLD 1	0.0s	0.0s
TIM74	0.00s	0.00s	HOLD 2	0.0s	0.0s
TIM75	0.00s	0.00s	HOLD 3	0.0s	0.0s
PLAST DL B	0.0s	0.0s	HOLD 4	0.0s	0.0s
T77	0.0s	0.0s	HOLD 5	0.0s	0.0s
T78	0.0s	0.0s	HOLD 6	0.0s	0.0s
INJECT B	5.00s	0.00s	HOLD 7	0.0s	0.0s
HOLD B 1	0.0s	0.0s	HOLD 8	0.0s	0.0s
HOLD B 2	0.0s	0.0s	HOLD 9	0.0s	0.0s
HOLD B 3	0.0s	0.0s	HOLD 10	0.0s	0.0s
HOLD B 4	0.0s	0.0s			
HOLD B 5	0.0s	0.0s			

915:PLS SEARCH GATE ORIGIN

0bar 486.5mm 0.1mm A 115.5mm B 1.0mm

Screen (39)




- (1) Keep pressing  to call up the screen (39)
- (2) This screen can check the set value and current value of various time

relays. Press  to scroll the display.

## 3.2.22 Monitor counters

COUNTER MONITOR			2011/10/19 (WED) 15:01		
	SET	ACTUAL		SET	ACTUAL
CYCLE NO	65535 t	0t	UNSCR2	***** t	*****t
DEFECT	0 t	0t	GATE AUTO 1	1 t	*****t
PRODU.TIME	0.0 h	0.0h	GATE CORE	1 t	1t
BATCH SIZE	65000 t	*****t	SCREW3	***** t	*****t
NOS.OFEJE.	***** t	*****t	UNSCR3	***** t	*****t
VIBRATION	***** t	*****t	COL.CH CNT	0 t	0t
SCREW1	***** t	*****t	COL.CH CNTB	0 t	0t
UNSCR1	***** t	*****t	GATE AUTO 2	1 t	1t
EVERY	5 t	5t	C25	0 t	*****t
AUX	0 t	*****t	C26	0 t	*****t
AUX	0 t	*****t	C27	0 t	*****t
AUX	0 t	*****t	C28	0 t	*****t
C12	0 t	*****t	C29	0 t	*****t
C13	0 t	*****t	C30	0 t	*****t
NOS.OFEJE.B	1 t	*****t	C31	0 t	*****t
C15	0 t	0t			
SCREW2	***** t	*****t			
915:PLS SEARCH GATE ORIGIN					
0bar            486.5mm            0.1mm            A 115.5mm            B 1.0mm					

Screen (40)



(1) Press to call up the screen (40)





(2) This screen can check the set value and current value of various counters.

Press to scroll the display.



## 3.2.23 Language setting and clock setting

《 ADDITION 》		2008/01/04 (FRI) 16:02	
LANGUAGE	ENGLISH		
DATE	2008/01/04	(yyyy/mm/dd)	
TIME	16:02	(hh:mm)	
BK LIGHT OFF	30	min	
DISP CHANGE	999	s	
TELEPHONE : 852-26653222 FACSIMILE : 852-26641115 MODEL : JN268-DM SERIAL No. : 04652 DATE : 2007/08/30 PROGRAM : 268BZ-2 DISP : 19 CTRL : 9 EPROM : 12			
<div>  0bar            1.1mm            1.0mm            121.5mm            121.5mm </div>			


Screen (41)

- (1) Press  +  to call up the screen (41)
- (2) Press  button to select the parameter to be modified. Input the intended value followed by pressing  button to complete the setting.

The display is available in three languages: Chinese, Japanese and


English. You can press  or  to make the setting.

## 3.2.24 Historical alarm




Screen (42)




- (1) Press  to call up the screen (42), which has the records of all previous alarms. Press “Data reset” to delete the records.

## 3.2.25 Help




Screen (43)

- (1) Press  to call up the screen (43), which has some brief instructions on the machine.



## 3.2.26 Notes on password



(1) This machine is equipped with a strict password protection function, which can prevent unauthorized data change. When the operator wants to make amendment on the important data, the follow screen (38) will show up to require the password input. The password change screen will appear after the correct password is input.




Screen (44)


(2) To allow the authorized operator to modify the data in a convenient way,

the password can be removed. Press  +  to call up the screen (44). After the correct password is input, the screen (45) will appear, which means the password has been successfully removed. No password input will be required for further amendment on the data.

To resume the password protection function, just press  +  to input the correct password, or just reboot the system.



Screen (45)



Screen (46)



## (3) Password change

《PASSWORD CHANGE》 2008/01/04 (FRI) 15:11

NOW PASSWORD

NEW PASSWORD

CONF. PASSWORD

ENT.

Øbar 1.1mm 1.0mm A 121.5mm B 121.5mm

Screen (47)

《PASSWORD CHANGE》 2008/01/04 (FRI) 15:11


NEW PASSWORD SETTING



Øbar 1.0mm 1.0mm A 121.5mm B 121.5mm

Screen (48)



+



Press  +  to call up the screen (47) and input the password. When the screen (48) appears, it means the password has been successfully changed.

## 3.3 Introduction on the computer alarm

## RELA

YN <sub>0</sub>	中国語	英語
800	800:警报 1	800:ALARM 1
801	801:警报 2	801:ALARM 2
802	802:料管温度未达设定	802:BARREL TEMP NOT REACH
803	803:润滑油量不足	803:LUBRICATION OIL NOT REACH
804	804: 润滑器排水阀阻塞	804:LUBRICATION RELEASE VAVE CLOG
805	805:潤滑油漏油或不足	805:LUBRICATION OIL PRESS. TOO LOW
806	806:油馬達超過負荷	806:PUMP MOTOR OVERLOAD
807	807:調模馬達超負荷	807:MOLD ADJUST MOTOR OVERLOAD
808	808:後安全門未關閉	808:REAR DOOR NOT CLOSE
809	809:前安全門未關閉	809:FRONT DOOR NOT CLOSE
810	810:調模超出最小尺寸	810:MOLD ADJ MIN LIMIT
811	811:調模超出最大尺寸	811:MOLD ADJ MAX LIMIT
812	812:警報 3	812:ALARM 3
813	813:油馬達未啓動	813:PUMP MOTOR NOT START
814	814:鎖模行程已終止	814:CLAMP END
815	815:開模行程已終止	815:OPEN END 了
816	816:開模行程未終止	816:OPEN NOT END
817	817:頂針行程已終止	817:EJT FOR END
818	818:退針行程已終止	818:EJT BACK END
819	819:熔膠行程已終止	819:PLAST END
820	820:鬆退行程已終止	820:SCREW BACK END
821	821:請檢查射咀前進限位	821:CHECK NOZ FOR LIMIT
822	822:射咀保護蓋未關閉	822:NOZZLE GUARD NOT CLOSE
823	823:射咀孔異物阻塞	823:NOZZLE BLOCK
824	824:熔膠量不足或溢料	824:SHORT SHOT OR OVER SHOT
825	825:料斗無料或阻塞	825:NO MATERIAL OR BLOCKED
826	826:成型模數已達設定	826:CYCLE COUNT COMPLETED
827	827:週期時間過長	827:CYCLE TIME TOO LONG
828	828:請清理模具內異物	828:PLEASE CLEAN UP THE MOLD
829	829:調模時間過長	829:MOLD ADJUST TOO LONG
830	830:潤滑中	830:LUBRICATION IN PROGRESS
831	831:請檢查機械手取出物	831:PLEASE CHECK ROBOT FIXTURE
832	832:製品確認訊號異常	832:TAKE OUT FAILURE
833	833:電眼感應片被遮	833:PHOTO CUT ALARM
834	834:切斷電源重新開機	834:POWER OFF THEN ON AGAIN

835	835:油過濾網阻塞	835:OIL FILTER CLOG
836	836:循環油度過低	836:OIL TEMP TOO LOW
837	837:循環油度過高	837:OIL TEMP TOO HIGH
838	838:自動模具替換中	838:AUTO MOLD CHANGE
839	839:半螺母位置不對	839:NUT CLOSING NOT ALIGN
840	840:請檢查抽芯限位開關	840:CHECK CORE PULL LIMIT
841	841:請檢查旋轉盆限位開關	841:CHECK GATE IN/OUT LIMIT
842	842:請檢查頂針限位開關	842:CHECK EJECTOR LIMIT
843	843:請檢查自動門安全閥	843:CHECK VALVE FOR DOOR
844	844:大油缸未回定位	844:BIG CYLINDER NOT LOCATED
845	845:開模洩壓異常	845:OPEN PRESSURE RELEASE TROUBLE
847	847:鎖模力受力中	847:CLAMPING IN PROGRESS
848	848:蓄壓器充壓異常	848:ACC CHARGE ALARM
849	849:液壓油油量不足	849:OIL LEVEL TOO LOW
850	850:調模計數開關故障	850:MOLD ADJUST SENSOR TROUBLE
851	851:調模齒輪異常檢查	851:MOLD ADJUST GEAR TROUBLE
852	852:模具安裝位置檢查	852:MOLD FITTING POSITION CHECK
853	853:油壓夾模異常檢查	853:HYDRAULIC CLAMP TROUBLE
854	854:鎖模力不足檢查	854:CLAMP FORCE NOT ENOUGH
855	855:機械手氣壓不足	855:AIR PRESSURE FOR ROBOT TOO LOW
856	856:背壓調整過高	856:BACK PRESSURE TOO HIGH
857	857:自動原料替換運行	857:MATERIAL CHANGE IN PROGRESS
858	858:料管度預熱中	858:PREHEAT IN PROGRESS
859	859:絞芽計數開關檢查	859:CHECK UNSCREW COUNTING SENSOR
860	860:模厚自動調整中	860:AUTO MD THICK ADJ IN PROGRESS
861	861:鎖模力自動調整中	861:AUTO MD CLA FORCE ADJ IN PROG
862	862:換模台限位器檢查	862:AMC TABLE L.S. ERROR
863	863:壓力檢測訊號異常	863:PRESSURE SENSOR DETECT ERROR
864	864:熔膠轉測開關檢查	864:PLAST RPM SENSOR DETECT ERROR
865	865:電箱門未關	865:CONTROL CABINET DOOR NOT CLOSE
866	866:電腦內部電池更換	866:CHANGE BATTERY
867	867:鎖模力自動調整完成	867:AUTO MD CLA FORCE COMPLETE
868	868:模厚自動調整完成	868:AUTO MD THICK ADJ COMPLETE

	869:成品不良、檢查四段位置時間設定	869:INJECTION SETTING NO GOOD
869	定	870:BARREL TEMPERATURE TOO HIGH
870	870:料管實際度過高	871:PLASTICIZATION DELAY
871	871:熔膠延時中	872:MOLD ADJUST IN PROGRESS
872	872:調模中	873:TABLE IN ROTATION
873	873:轉盤中	874:STOPPER NOT RETURN
874	874:定位桿未退	875:AUTO MOLD ADJUST ERROR
875	875:自動調模故障	876:STEPPER ERROR
876	876:踏板故障	877:PUSH POWER ON SWITCH TWICE
877	877:請按電源制時	878:EJECTOR PLATE NOT RETURN
878	878:頂針板未退	879:SAFETY VALVE ERROR
879	879:安全閥故障	880:MOLD CLAMP OPEN ALARM
880	880:開鎖模故障	881:DOOR LIMIT SWITCH ERROR
881	881:安全門限位器故障	882:DOOR LATCH ERROR
882	882:門機械鎖故障	883:AIR PRESSURE NOT ENOUGH
883	883:氣壓不足	884:SAFETY VALVE ERROR
884	884:安全鎖油掣故障	885:PLASTICIZATION NOT DONE
885	885:未熔膠	886:PREFORM NOT DROP
886	886:成品未脫	887:MOLD OPEN END ERROR
887	887:開模終止故障	888:PLASTICIZATION INPROGRESS
888	888:熔膠中	889:ROBOT SAFETY CHECK ERROR
889	889:機械手安全限位故障	890:ROBOT NOT ZERO RETURN
890	890:機械手末回零位	891:ROBOT ALARM
891	891:機械手故障	892:SERVO CONTROL ALARM
892	892:伺服控制故障	893:PRODUT EJECT OUT ERROR
893	893:成品頂出故障	894:OPEN END POSITION ERROR
894	894:開模終止位置故障	895:SAFETY CLOSE CHECK ERROR
895	895:安全鎖模檢出故障	896:PLASTICIZATION NOT END
896	896:熔膠未終止	897:PREFORM NOT DROP
897	897:模胚未脫	898:CLEAN UP BARREL
898	898:清除料筒膠料	899:ADJUSTMENT!
899	899:調整功能動中	900:GATE IN NOT END
900	900:入閘未終止	901:BARREL TEMPERATURE TOO LOW
901	901:料筒实际温度过低	902:SAFETY DOOR LIMIT ERROR
902	902:安全門限位故障	903:SAFETY DOOR LATCH ERROR
903	903:安全門互鎖故障	904:STOPR NOT FWD TO LIMIT
904	904:定位針未頂出至限位	905:STOPR FWD TO LIMIT
905	905 定位針已出至限位	906:STOPR BWD TO LIMIT
906	906:定位針已退至限位	

---

907	907:辅顶针已退	907:EJECTOR B BWD TO LIMIT
908	908:辅顶针已顶出	908:EJECTOR B FWD TO LIMIT
909	909:辅熔胶已完成	909:PLAST B END
910	910:辅松退已完成	910:SCREW BACK B END
911	911:B 顶针未退	911:EJT BACK B NOT END
912	912:转盘未回零位	912:GATE NOT COME ORIGIN
913	913:定位针未退	913:STOPR NOT BWD TO LIMIT
914	914:A 顶针未退	914:EJT BACK A NOT END
915	915:请寻转盘零位	915:PLS SEARCH GATE ORIGIN
916	916:请按手动逆转	916:PLS PRESS MANU REVER
917	907:请按手动顺转	917:PLS PRESS MANU DIREC
918	918:转轴已出至限位	918:SHAFT FWD TO LIMIT
919	919:转轴已退至限位	919:SHAFT BWD TO LIMIT
920	920:寻转盘零位故障	920:SEARCH GATE ORIGIN ERROR