

Contents

I. Characteristics	1
II. Basic Features	2
III. Function Comparison	3
IV. Introduction to the Computer Panel	4
4.1 Computer Panel	4
4.2 Keys for Operation Mode Control	5
4.3 Keys for Forming Conditions Setting	5
4.4 Number Keyboard, Cursor Keys and Auxiliary Operation Function	5
4.5 Keys and Instructions for Manual Operation	6
4.6 Power Switch	7
V. Operational Instructions for Computer Interfaces	8
5.1 Starting the Computer	8
5.2 Normal Operation Setting	10
5.2.1 Normal Operation Screen	10
5.2.2 Cycle Monitor	12
5.2.3 Mould Opening Setting	13
5.2.4 Mould Clamping Setting	15
5.2.5 Injection Setting	17
5.2.6 Pressure Holding Setting	19
5.2.7 Sequential Injection Control (Heat Channel Needle Valve Control) Setting	21
5.2.8 Automatic Purge Setting	22
5.2.9 Plasticization/Decompression Setting	23
5.2.10 Ejector Setting	24
5.2.11 Blowing Setting	25
5.2.12 Carriage Setting	26
5.2.13 Core Pulling Setting	27
5.2.14 Timer Setting	29
5.2.15 Counter Setting	30
5.2.16 Temperature Deviation Alarm Setting	31
5.2.17 Heat Channel Setting	32
5.2.18 Function Setting	34
5.2.19 Mould Data Selection	36
5.2.20 Statistic Value	37
5.2.21 Timer Monitor	38
5.2.22 Counter Monitor	40
5.2.23 Input Monitor	41
5.2.24 Output Monitor	42
5.2.25 Relay Monitor	44
5.2.26 Program Monitor	56
5.2.27 Injection End Position	57
5.2.28 Injection Speed Curve	58
5.2.29 Injection Pressure Curve	59

5.2.30 Help	60
5.2.32 Action Stroke Stage Number Selection	66
5.2.33 Ramp Setting	67
5.2.34 Speed 1 Output Setting	68
5.2.35 Pressure Output Setting	69
5.2.36 Back Pressure Output Setting	70
5.2.37 Speed 2 output setting	71
5.2.38 Initial Setting (Origin setting for decoder)	72
5.2.39 Auxiliary Speed and Pressure Setting	74
5.2.40 Timer Setting	76
5.2.41 Counter Setting	78
5.2.42 Factory Setting	80
5.2.43 Maintenance Setting	82
5.2.44 Alarm History	84
5.2.45 Network	85
5.2.46 Change Password	86
5.2.47 Manual Lubrication Setting	87
5.2.48 Mould Adjustment Setting	88
5.2.49 Machine Adjustment	89
VI. Advanced Computer Operation	90
6.1 Initial Position Reset Procedure	90
6.1.1 Clamping	90
6.1.2 Ejector	91
6.1.3 Injection	91
6.2 Decoder Initial Position Setting	92
6.3 Alarm and Treatment	95
6.4 Moulding Operation Instruction	99
6.4.1 Setting of Temperature Control	99
6.4.2 Setting of the Temperature Deviation (Alarm)	100
6.4.3 Setting of the Temperature Preheat Function	100
6.4.5 Setting of Position, Speed and Pressure Data	101
6.4.6 Setting of the Numerical Data for Moulding Conditions	101
6.4.7 Adjustment of Proportional Numerical Control	102
6.4.8 Description of the Computer Internal Counters	103
6.4.9 Description of the Computer Internal Timer	104
6.4.10 Description of the Computer Inputs and Outputs	108
6.5 Ai-11 Special Screen Operation	113
VII. Appendix (Ai-11 Electrical Diagram)	114
7.1 Ai-11 Main Circuit Diagram	114
7.2 Ai-11 Main Circuit Diagram (UPS)	115
7.3 Ai-11 Main Cabinet Wiring Diagram	116
7.4 Ai-11 I/O Board Layout Diagram	117
7.5 Ai-11 I/O Board Input Connection	118
7.6 Ai-11 I/O Board Input Connection (Large Machine)	119

7.7 Ai-11 I/O Board Output Connection	120
7.8 Ai-11 I/O Board Output Connection (CE)	121
7.9 Ai-11 I/O Board Output Connection (Large Machine)	122
7.10 Ai-11 Extend Board 1 Wiring Diagram	123
7.11 Ai-11 Extend Board 1 Wiring Diagram (CE)	124
7.12 Ai-11 Extend Board 1 Wiring Diagram (Large Machine)	125
7.13 Ai-11 Extend Board 1 Layout Diagram	126
7.14 Ai-11 Extend Board 2 Wiring Diagram	127
7.15 Ai-11 Extend Board 2 Layout Diagram	128
7.16 Ai-11 Hydraulic Semi-closed Loop Wiring Diagram A	129
7.17 Ai-11 Hydraulic Semi-closed Loop Wiring Diagram B	130
7.18 Ai-11 Hydraulic Semi-closed Loop Wiring Diagram C	131
7.19 Ai-11 Hydraulic Semi-closed Loop Wiring Diagram D	132
7.20 Ai-11 Hydraulic Semi-closed Loop Wiring Diagram E	133
7.21 Ai-11 Digital MOOG Injection Closed Loop Wiring Diagram	134
7.22 Ai-11 MOOG Injection Closed Loop Input Connection	135
7.23 Ai-11 MOOG Injection Closed Loop Output Connection	136
7.24 Ai-11 Robot Interface (CE67A) Wiring Diagram	137
7.25 Ai-11 Safety Relay Wiring Diagram	138

Operating Instructions of Chen Hsong Ai-11 Multi-function Computer

I. Characteristics

- § Designed and developed by Japan technology and complying with JIS inspection standards.
- § 640×480 color LCD.
- § Power range applied: AC110V~AC280V 50/60HZ.
- § The light source of luminescence pipe has a high brightness with a long service life.
- § The electronic components and production technique adopt the most advanced SMT technology with highest stability and reliability.
- § Data can be stored for over 5 years safely.
- § Freely choose from Chinese, English and another language for the convenience of study and operation.
- § Intelligent fault detection and auxiliary operation instructions.
- § Fully support the wireless network system – iChen.

II. Basic Features

- Effective storage capacity of 150 groups of forming data (like time, times, pressure, speed, stroke, metering, mould thickness, mould name, selection condition, temperature of raw materials, etc.)
- Detailed tips on online operation.
- Lock the software data by stage encryption.
- Mistake-proof tips when inputting data in case of unsuitable modification.
- Data modification can be stored in the central server online through iChen System.
- Most advanced SMT electric plate assembling technology with a high reliability.
- 32 bit high speed CPU.
- Automatic setting of high pressure clamping position.
- Proportional temperature control of nozzle (standard), supporting additional nozzle thermometer (optional).
- 8 groups of PID temperature control, adjustment between 30℃ and 500℃ with a high degree of accuracy.
- Cold material startup prevention, automatic temperature-keeping setting, nozzle block and material overflow detection.
- High and low temperature deviation setting and temperature sensor line break detection in operation.
- Injection 10 stage speed, 10 stage pressure and 10 stage pressure holding setting.
- Plasticizing 10 stage speed, 10 stage pressure and 10 stage back pressure setting.
- Support the function of 3 groups of blowing and 6 groups of core pulling (or 6 groups of unscrewing).
- Clamping, injection and ejector all adopt high precision optics encoder (standard) or potentiometer (optional).
- Storage of alarms historical records, convenient for the technique debugging and maintenance.
- Production quantity and batch setting, auto stop as per production quantity.
- Cooperate with iChen order arrangement system.
- Auto toggle lubrication setting. Oil starvation alarm.
- Figure display of operation actions, convenient for the supervision of injection moulding machine operation.
- Monitor of the cycle operation time, convenient for adjustment to shorten the cycle time.
- Injection speed and pressure standard graph and current graph comparison. Injection terminal statistics.
- Online monitor of the program running condition and all the status of inputs, outputs, timers and counters, convenient for debugging and maintenance.
- Support the monitor of 56 outputs, 56 inputs, 100 timers and 20 counters status.
- Free selection, duplication and erasion of mould data. The setting time can be saved by using the preset mould data inside the computer. Data can also be inputted through external SD card.
- Intelligent fault detection and auxiliary operation instructions.
- Support the temperature control of at most 60 groups of heat channels.
- Fully support the iChen network workshop management system.
- Fully support the iChen Wireless Network.


III. Function Comparison

Ai-11 Multi-function computer is the function enhancing edition of Ai-01 computer. The added functions include two stage of ejector, synchronizing core pulling and plasticizing, three groups of blowing, etc. The detailed comparison is as follows:

Function	CHAi-01	CHAi-11
Display	6 inch (320*240 points) Color screen	10.4 inch (640*480 points) Color screen
Input/Output	32 points	56 points
Injection control	5 stage	10 stage
Pressure holding control	5 stage	10 stage
Core pulling/Unscrewing	3 groups of core pulling, 1 group of unscrewing	6 groups of core pulling, or 6 groups of unscrewing
Heat channel	40 groups	60 groups

IV. Introduction to the Computer Panel

4.1 Computer Panel



4.2 Keys for Operation Mode Control



This keyboard is responsible for the switch of forming operation mode.


4.3 Keys for Forming Conditions Setting










This keyboard has the following functions:

- 1) Set the forming conditions like position, speed, pressure, time, counter, temperature, etc.
- 2) Change and rewrite the mould data.
- 3) According to the requirements of finished products and mould design, choose the forming functions or actions.
- 4) Under any operation interface, the cursor can be moved to the expected position for changing data.

4.4 Number Keyboard, Cursor Keys and Auxiliary Operation Function



This keyboard has the following functions:

- 1) If press  +  +  at the same time, then turn on the power of the computer, the mould data and system setting inside the computer can be initialized. After hearing the alarm of a long “beep”, the initialization is completed. Release the three keys, and the operation on computer can be continued.
- 2) When operating the computer, press  and  simultaneously, the function of pageup can be realized; press  and  simultaneously, the function of pagedown can be realized.
- 3) Input the digital data required by forming conditions:
 - Speed setting ranges 00%~99%; 00% means no speed.
 - Pressure setting ranges 00%~99%; 00% means no pressure.
 - Position setting ranges 0000~999.9 mm.
 - Time setting ranges 0~999.9 sec.
 - Counter setting ranges 0~65535.
 - Mould thickness setting ranges 0~999.9 mm.
- 4) Inspection of the keyboard function.
- 5) Monitor of the operation status of all inputs, outputs, timers and counters.
- 6) Injection graph display.
- 7) Help information search.


4.5 Keys and Instructions for Manual Operation




The keyboard for manual operation can individually operate some certain actions of entire action cycle.

4.6 Power Switch

1) Emergency Stop Button

The Emergency Stop Button  locates in the bottom-right of the computer operation panel. If press it, the power can be cut off. If restart is required, the button must be released by turning rightward.

2) Start Button

The Start Button  locates on the right under the computer operation panel. If the Emergency Stop Button has been released, the power of the machine can be switched on by pressing the Start Button. This function can effectively protect the control system.

3) A high-powered voltage regulation apparatus in the controller can bear the power supply of AC90V – AC265V 50/60HZ.


V. Operational Instructions for Computer Interfaces


5.1 Starting the Computer

Computer Startup Screen (01)



Computer Startup Screen (02)




- 1) After turning on the computer, the system is under automatic inspection. If press  , the interface (01), which shows the machine type, machine model, serial number and program, will appear. If the machine needs maintenance or technical inquiry, please inform this information to the customer service department of our company for instant service.
- 2) If no action is conducted, the system will automatically switch to the interface (02) after about 3 seconds, which reminds you to input the 6 digits password or press any screen keys for skip. The password is classified into 3 levels of authorities: Operator, Supervisor and Factory. Each password will allow you to login the corresponding level of screens without inputting the password again. It will switch into operation interface (03) automatically after 3 seconds.



5.2 Normal Operation Setting

5.2.1 Normal Operation Screen

Normal Operation Screen (03)

The screenshot displays the 'Normal Operation Screen (03)' with a yellow background. At the top, there is a status bar with 'MANUAL' in orange, 'MoldName: No. 1', and the date/time '2008-1-17 14:34'. Below this, there are several input fields for parameters: Sp. (A1 %), Pr. (A2 %), Bp. (A3 %), S2. (A4 %), Nozz. (AAA %), T1 (BBB), T2 (CCC), T3 (DDD), T4 (EEE), T5 (FFF), T6 (GGG), and Oil (HHH). A diagram of the machine's barrel and nozzle is shown with corresponding labels: Nozz. (red), T1 (red), T2 (white), T3 (white), T4 (red), T5 (white), T6 (white), and Oil (red). Below the diagram, there are fields for CYCLE No. (WWWWW), REJECT No. (XXXXX), CYCLE TIME (MMMM.M), FILLING (KKKK K S), COOLING (LLLL L S), and RECYCLE (NNNN.N S). At the bottom, there is a diagram of the machine's internal components and a row of four input fields: 0000.0 mm, P P P P mm, 0000.0 mm, and S S S bar.

Press  one time to display this interface (After the normal start of the system, the default is manual operation. After the start is completed, this interface will appear automatically).

To modify the set value of temperature (Nozzle, T1~T6、Oil), use  to select the temperature stage to be set, input the numerical value and press , then the setting is complete.

This interface is used to monitor the relevant parameters of operation and each stage temperature settings of the barrel.

Of which:

"AAA": Nozzle heating proportional value setting

"BBB": Stage 1 temperature setting

"CCC": Stage 2 temperature setting

"DDD": Stage 3 temperature setting


"EEE": Stage 4 temperature setting

"FFF": Stage 5 temperature setting (depends on the machine capacity)
"GGG": Stage 6 temperature setting (depends on the machine capacity)
"HHH": Oil temperature setting
"W": No. of moulding produced display
"X": No. of rejected parts display
"K": Injection filling time display
"M": Cycle time display
"L": Cooling time display
"N": Recycle time display

"A1": Corresponding operation stage speed display
"A2": Corresponding operation stage pressure display
"A3": Corresponding operation stage back pressure display
"A4": Corresponding operation stage speed B display

5.2.2 Cycle Monitor

Cycle Monitor Screen (04)



Press twice to enter the cycle monitor screen (04), which shows the entire action cycle:

Clamping → Carriage Forward → Injection → Pressure Holding
→ Delay..... → Ejector → Recycle


The numerical value of each step is the time consumption of this step. The frame in the middle of the interface shows the cycle time, product number, cycle number and rejected part number.



5.2.3 Mould Opening Setting

Mould Opening Setting Screen (05)

Mould Open Close Setting		Mold Name:	No.	1	2008-1-17 15:28
MANUAL					
Maximum Mould Stroke		505.0mm			
Maximum Press		175bar		LOW PR.DETEC 0 s	
Open1	Sp. B1 %	Pr. C1 %	Pos. D1 p	Clamp1	Sp. E1 %
Open2	B2 %	C2 %	D2 mm	Clamp2	E2 %
Open3	B3 %	C3 %	D3 mm	Clamp3	E3 %
Open4	B4 %	C4 %	D4 mm	Clamp4	E4 %
Open5	B5 %	C5 %	D5 mm	Clamp5	E5 %
H.P.OPEN END			D6 mm	Clamping Aux G6 mm	
Syn.Eject			D7 mm	Clamping Force 0 ton 0 p	
hydraulic					
Low Press			F6 ton	Clamping Force F7 ton	

0000.0 mm 0000.0 mm 0000.0 mm SSS Kg/cm²

Press  to enter mould opening setting screen (05).


Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.

Adjustment of speed, pressure and position of mould opening and display of relevant parameters can be achieved in this screen.

Of which,

- "B1": Slow mould open speed setting
- "C1": Slow mould open pressure setting
- "D1": Slow mould open end position setting
- "B2": Stage 2 mould open speed setting
- "C2": Stage 2 mould open pressure setting
- "D2": Stage 2 mould open end position setting

- "B3 ": Stage 3 mould open speed setting
 "C3": Stage 3 mould open pressure setting
 "D3": Stage 3 mould open end position setting
 "B4": Fast mould open speed setting
 "C4": Fast mould open pressure setting
 "D4": Fast mould open end position setting
 "B5": Break speed setting
 "C5": Break pressure setting
 "D5": Break end position setting
 "D6": High pressure mould open end position setting
 "D7": Mould open synchronized ejector setting






5.2.4 Mould Clamping Setting

Mould Clamping Setting Screen (06)

Mould Open Close Setting		Mold Name:		No.	1	2008-1-17 15:28
MANUAL						
Maximum Mould Stroke		505.0mm				
Maximum Press		175bar		LOW PR.DETEC		0 s
Open1	Sp. B1 %	Pr. C1 %	Pos. D1 p	Clamp1	Sp. E1 %	Pr. F1 %
Open2	B2 %	C2 %	D2 mm	Clamp2	E2 %	F2 %
Open3	B3 %	C3 %	D3 mm	Clamp3	E3 %	F3 %
Open4	B4 %	C4 %	D4 mm	Clamp4	E4 %	F4 %
Open5	B5 %	C5 %	D5 mm	Clamp5	E5 %	F5 %
H.P.OPEN END			D6 mm	Clamping Aux		
Syn.Eject			D7 mm	Clamping Force		
				0 ton 0 p		
hydraulic						
Low Press				F6 ton		
Clamping Force				F7 ton		

0000.0 mm 0000.0 mm 0000.0 mm SSS Kg/cm²

Press  to enter the mould clamping setting screen (06).


Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.

Adjustment of speed, pressure and position of mould clamping, setting of clamping force and system pressure for mould opening and clamping and display of relevant parameters can be achieved in this screen.

Of which,

- "E1": Mould clamp speed setting
- "F1": Mould clamp pressure setting
- "G1": Mould clamp end position setting
- "E2": Stage 2 mould clamp speed setting
- "F2": Stage 2 mould clamp pressure setting
- "G2": Stage 2 mould clamp end position setting
- "E3": Stage 3 mould clamp speed setting
- "F3": Stage 3 mould clamp pressure setting
- "G3": Stage 3 mould clamp end position setting
- "E4": Low pressure mould clamp speed setting
- "F4": Low pressure mould clamp pressure setting

- "G4": Low pressure mould clamp end position setting
"E5": High pressure mould clamp speed setting
"F5": High pressure mould clamp pressure setting
"G5": High pressure mould clamp end position setting
"F6": Hydraulic mould clamp low pressure setting
"F7": Hydraulic mould clamp clamping force setting
"G6": Auxiliary mould clamp setting



5.2.5 Injection Setting

Injection Setting Screen (07)

Injection Setting		Mold Name:	No.	1	2008-1-17 16:28																																																																																								
MANUAL																																																																																													
Max. Stroke	560.0 mm	FILLING	0.00s	Cushion	End																																																																																								
INJECT TIME	A s	Hold Change	Timer	Inject Press	B bar																																																																																								
<table border="1"> <thead> <tr> <th></th> <th>Sp.</th> <th>Pr.</th> <th>Time</th> <th></th> <th>Sp.</th> <th>Pr.</th> <th>Pos.</th> </tr> </thead> <tbody> <tr> <td>Hold 1</td> <td>H1 %</td> <td>I1 %</td> <td>J1 s</td> <td>Inject1</td> <td>C1 %</td> <td>D1 %</td> <td>E1 mm</td> </tr> <tr> <td>Hold 2</td> <td>H2 %</td> <td>I2 %</td> <td>J2 s</td> <td>Inject2</td> <td>C2 %</td> <td>D2 %</td> <td>E2 mm</td> </tr> <tr> <td>Hold 3</td> <td>H3 %</td> <td>I3 %</td> <td>J3 s</td> <td>Inject3</td> <td>C3 %</td> <td>D3 %</td> <td>E3 mm</td> </tr> <tr> <td>Hold 4</td> <td>H4 %</td> <td>I4 %</td> <td>J4 s</td> <td>Inject4</td> <td>C4 %</td> <td>D4 %</td> <td>E4 mm</td> </tr> <tr> <td>Hold 5</td> <td>H5 %</td> <td>I5 %</td> <td>J5 s</td> <td>Inject5</td> <td>C5 %</td> <td>D5 %</td> <td>E5 mm</td> </tr> <tr> <td>Hold 6</td> <td>H6 %</td> <td>I6 %</td> <td>J6 s</td> <td>Inject6</td> <td>C6 %</td> <td>D6 %</td> <td>E6 mm</td> </tr> <tr> <td>Hold 7</td> <td>H7 %</td> <td>I7 %</td> <td>J7 s</td> <td>Inject7</td> <td>C7 %</td> <td>D7 %</td> <td>E7 mm</td> </tr> <tr> <td>Hold 8</td> <td>H8 %</td> <td>I8 %</td> <td>J8 s</td> <td>Inject8</td> <td>C8 %</td> <td>D8 %</td> <td>E8 mm</td> </tr> <tr> <td>Hold 9</td> <td>H9 %</td> <td>I9 %</td> <td>J9 s</td> <td>Inject9</td> <td>C9 %</td> <td>D9 %</td> <td>E9 mm</td> </tr> <tr> <td>Hold 10</td> <td>H10 %</td> <td>I10 %</td> <td>J10 s</td> <td>Inject10</td> <td>C10 %</td> <td>D10 %</td> <td>E10 mm</td> </tr> </tbody> </table>							Sp.	Pr.	Time		Sp.	Pr.	Pos.	Hold 1	H1 %	I1 %	J1 s	Inject1	C1 %	D1 %	E1 mm	Hold 2	H2 %	I2 %	J2 s	Inject2	C2 %	D2 %	E2 mm	Hold 3	H3 %	I3 %	J3 s	Inject3	C3 %	D3 %	E3 mm	Hold 4	H4 %	I4 %	J4 s	Inject4	C4 %	D4 %	E4 mm	Hold 5	H5 %	I5 %	J5 s	Inject5	C5 %	D5 %	E5 mm	Hold 6	H6 %	I6 %	J6 s	Inject6	C6 %	D6 %	E6 mm	Hold 7	H7 %	I7 %	J7 s	Inject7	C7 %	D7 %	E7 mm	Hold 8	H8 %	I8 %	J8 s	Inject8	C8 %	D8 %	E8 mm	Hold 9	H9 %	I9 %	J9 s	Inject9	C9 %	D9 %	E9 mm	Hold 10	H10 %	I10 %	J10 s	Inject10	C10 %	D10 %	E10 mm
	Sp.	Pr.	Time		Sp.	Pr.	Pos.																																																																																						
Hold 1	H1 %	I1 %	J1 s	Inject1	C1 %	D1 %	E1 mm																																																																																						
Hold 2	H2 %	I2 %	J2 s	Inject2	C2 %	D2 %	E2 mm																																																																																						
Hold 3	H3 %	I3 %	J3 s	Inject3	C3 %	D3 %	E3 mm																																																																																						
Hold 4	H4 %	I4 %	J4 s	Inject4	C4 %	D4 %	E4 mm																																																																																						
Hold 5	H5 %	I5 %	J5 s	Inject5	C5 %	D5 %	E5 mm																																																																																						
Hold 6	H6 %	I6 %	J6 s	Inject6	C6 %	D6 %	E6 mm																																																																																						
Hold 7	H7 %	I7 %	J7 s	Inject7	C7 %	D7 %	E7 mm																																																																																						
Hold 8	H8 %	I8 %	J8 s	Inject8	C8 %	D8 %	E8 mm																																																																																						
Hold 9	H9 %	I9 %	J9 s	Inject9	C9 %	D9 %	E9 mm																																																																																						
Hold 10	H10 %	I10 %	J10 s	Inject10	C10 %	D10 %	E10 mm																																																																																						
INJ.VA.SW	Position	H.P.CH.POS. F mm DATA POS. G mm																																																																																											
0000.0 mm PPPP P mm 0000.0 mm SSS Kg/cm ²																																																																																													


Press to enter the injection setting screen (07).

Use to select the parameters to be set, input the numerical value and press then the setting is complete.

Selection of pressure holding change mode (position, time and pressure), setting of injection time and pressure and proportion of each stage, setting of the position of pressure holding change and material overflow and display of relevant parameters can be achieved in this screen.

Of which,

- "A": Injection time setting
- "B": Injection pressure setting
- "C": Stage 1~10 injection speed setting
- "D": Stage 1~10 injection pressure setting
- "E": Stage 1~10 injection end position setting



Tips: The low start speed of injection can prevent the crystalloid plastic fused mass from entering the nozzle, making it leave the sprue and inject into the injection unit cylinders.

If the injection speed is too low, the shear heat will be insufficient and the crystallization in the runner will increase. This must be compensated by increasing the sprue temperature.

The sprue temperature can be decreased by increasing the injection speed. If the injection speed increases the shear heat in the machine and heat channel, the formation of acetaldehyde will speed up.

Note: A too high injection speed will shorten the ventilation time, so that increase the air resistance in the mould cavity. The following consequences will occur:

Injection is not stable with remarkable shrinks;

Eddy flow at the mould parting line;

Shear heat in the nozzle and sprue will increase and the temperature in the surface of ventilation and product will increase;

Deposited materials will increase due to the increase of gas generated;

Formation of acetaldehyde will increase.

5.2.6 Pressure Holding Setting

Pressure Holding Setting Screen (08)

Injection Setting		Mold Name:		No.	2008-1-17 16:28	
MANUAL						
Max. Stroke	560.0 mm	FILLING	0.00s	Cushion	End	0.0mm
INJECT TIME	A s	Hold Change	Timer	Inject Press	B	bar
Sp.	Pr.	Time	Sp.	Pr.	Pos.	
Hold 1	H1 %	I1 %	J1 s	Inject1	C1 %	D1 % E1 mm
Hold 2	H2 %	I2 %	J2 s	Inject2	C2 %	D2 % E2 mm
Hold 3	H3 %	I3 %	J3 s	Inject3	C3 %	D3 % E3 mm
Hold 4	H4 %	I4 %	J4 s	Inject4	C4 %	D4 % E4 mm
Hold 5	H5 %	I5 %	J5 s	Inject5	C5 %	D5 % E5 mm
Hold 6	H6 %	I6 %	J6 s	Inject6	C6 %	D6 % E6 mm
Hold 7	H7 %	I7 %	J7 s	Inject7	C7 %	D7 % E7 mm
Hold 8	H8 %	I8 %	J8 s	Inject8	C8 %	D8 % E8 mm
Hold 9	H9 %	I9 %	J9 s	Inject9	C9 %	D9 % E9 mm
Hold 10	H10 %	I10 %	J10 s	Inject10	C10 %	D10 % E10 mm
INJ.VA.SW	Position		H.P.CH.POS.	F mm		
			DATA POS.	G mm		
0000.0 mm PPPP P mm 0000.0 mm SSS Kg/cm ²						

Press to enter the pressure holding setting screen (08).

Use to select the parameters to be set, input the numerical value and press then the setting is complete.

To choose the mode, use to find the parameters to be selected, and use or to select.


Setting of the speed, pressure and position of pressure holding, selection of needle valve switch mode (position and time) and pressure holding change mode (time, pressure and position) and display of relevant parameters can be achieved in this screen.

Of which,

"H": Stage 1~10 pressure holding speed setting

"I": Stage 1~10 pressure holding pressure setting


"J": Stage 1~10 pressure holding time setting





5.2.7 Sequential Injection Control (Heat Channel Needle Valve Control) Setting

Sequential Injection Control Setting Screen (09)

Sequential Injection		Mold Name:		No. : 1		2008-1-18 9:14	
MANUAL							
SEQ.INJECT. E		SWITCHING F					
INJ.ON	Pos.	TIME	INJ.OFF	Pos.	Time		
Inject1	A1 mm	B1 s	Inject1	C1 mm	D1 s		
Inject2	A2 mm	B2 s	Inject2	C2 mm	D2 s		
Inject3	A3 mm	B3 s	Inject3	C3 mm	D3 s		
Inject4	A4 mm	B4 s	Inject4	C4 mm	D4 s		
Inject5	A5 mm	B5 s	Inject5	C5 mm	D5 s		
Inject6	A6 mm	B6 s	Inject6	C6 mm	D6 s		
Inject7	A7 mm	B7 s	Inject7	C7 mm	D7 s		
Inject8	A8 mm	B8 s	Inject8	C8 mm	D8 s		
Inject9	A9 mm	B9 s	Inject9	C9 mm	D9 s		
Inject10	A10 mm	B10 s	Inject10	C10 mm	D10 s		
0000.0 mm		PPPP F mm		0000.0 mm		SSS Kg/cm ²	

Press  two times to enter the sequential injection control setting screen (09).

Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.


This interface is used to control the injection sequence of each mould cavity (position and time control). (Optional function)



5.2.8 Automatic Purge Setting




Automatic Purge Setting Screen (10)

Auto Purge Setting		Mold Name: No. 1		2008-1-18 9:35	
MANUAL					
Gas	OFF				
POS.	A mm				
PURGE			B t		
Time					
Plast	Sp.	Pr.	Bp.	Pos.	
	B1 %	C1 %	E %	D1 s	
Inject	B2 %	C2 %		D2 s	
Decomp	B3 %	C3 %		D3 mm	

0000.0 mm
PPPP P mm
0000.0 mm
SSS Kg/cm²

Press  three times to enter the automatic purge setting screen (10).

Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.

To choose the mode, use  to find the parameters to be selected, and use  or  to select.

The function of automatic purge is used when changing plastics and offers the setting of relevant parameters during the purge. The purge times is the number that the plastics being injected from the barrel. (Optional function)

5.2.9 Plasticization/Decompression Setting

Plasticization/Decompression Setting Screen (11)

Plast/Decomp Setting		Mold Name		No	1	2008-1-18 9:47	
MANUAL							
MAX. Stroke	240 mm		PLAST	0.00s		Screw End	0.0mm
Sp.	Pr.	Bp.	Pos.				
PLAST1	A1 %	B1 bar	C1 bar	D1 mm	PLAST DLY. E s		
PLAST2	A2 %	B2 bar	C2 bar	D2 mm			
PLAST3	A3 %	B3 bar	C3 bar	D3 mm			
PLAST4	A4 %	B4 bar	C4 bar	D4 mm			
PLAST5	A5 %	B5 bar	C5 bar	D5 mm			
PLAST6	A6 %	B6 bar	C6 bar	D6 mm			
PLAST7	A7 %	B7 bar	C7 bar	D7 mm			
PLAST8	A8 %	B8 bar	C8 bar	D8 mm			
PLAST9	A9 %	B9 bar	C9 bar	D9 mm			
PLAST10	A10 %	B10 bar	C10 bar	D10 mm			
Decomp	F1 %	F2 bar	F3 mm	MD BEF		OFF	
0000.0 mm P P P P P mm 0000.0 mm SSS Kg/cm ²							

Press to enter the plasticization/decompression setting screen (11).

Use to select the parameters to be set, input the numerical value and press , then the setting is complete.

This interface can be used to set the speed, pressure, back pressure and position of plasticizing, to control the speed, pressure and position of decompression, to set the time delay of plasticizing and to inspect relevant parameters.

5.2.10 Ejector Setting

Ejector Setting Screen (12)

Ejector Setting		Mold Name: No. 1		2008-1-18 10:05																									
MANUAL																													
Max. Stroke	125.0 mm	Eject Mode	Not Use	Eject In Aux	C mm																								
EJECT PAUSE	A s	EJECT No.	B t	VIB EJT No.	D t																								
<table border="1"> <thead> <tr> <th></th> <th>Sp.</th> <th>Pr.</th> <th>Pos.</th> </tr> </thead> <tbody> <tr> <td>Eject Out 1</td> <td>E1 %</td> <td>F1 %</td> <td>G1 mm</td> </tr> <tr> <td>Eject Out 2</td> <td>E2 %</td> <td>F2 %</td> <td>G2 mm</td> </tr> </tbody> </table>				Sp.	Pr.	Pos.	Eject Out 1	E1 %	F1 %	G1 mm	Eject Out 2	E2 %	F2 %	G2 mm	<table border="1"> <thead> <tr> <th></th> <th>Sp.</th> <th>Pr.</th> <th>Pos.</th> </tr> </thead> <tbody> <tr> <td>Eject In 1</td> <td>H1 %</td> <td>I1 %</td> <td>J1 mm</td> </tr> <tr> <td>Eject In 2</td> <td>H2 %</td> <td>I2 %</td> <td>J2 mm</td> </tr> </tbody> </table>				Sp.	Pr.	Pos.	Eject In 1	H1 %	I1 %	J1 mm	Eject In 2	H2 %	I2 %	J2 mm
	Sp.	Pr.	Pos.																										
Eject Out 1	E1 %	F1 %	G1 mm																										
Eject Out 2	E2 %	F2 %	G2 mm																										
	Sp.	Pr.	Pos.																										
Eject In 1	H1 %	I1 %	J1 mm																										
Eject In 2	H2 %	I2 %	J2 mm																										
<table border="1"> <tbody> <tr> <td>Air1</td> <td>OFF</td> </tr> <tr> <td>Open End</td> <td></td> </tr> <tr> <td>AIR 1 DELAY</td> <td>K1 s</td> </tr> <tr> <td>AIR 1 TIMER</td> <td>K2 s</td> </tr> </tbody> </table>			Air1	OFF	Open End		AIR 1 DELAY	K1 s	AIR 1 TIMER	K2 s	<table border="1"> <tbody> <tr> <td>Air2</td> <td>OFF</td> </tr> <tr> <td>Air2 Start Position</td> <td>L1 mm</td> </tr> <tr> <td>AIR2 DELAY</td> <td>L2 s</td> </tr> <tr> <td>AIR2 TIMER</td> <td>L3 s</td> </tr> </tbody> </table>			Air2	OFF	Air2 Start Position	L1 mm	AIR2 DELAY	L2 s	AIR2 TIMER	L3 s								
Air1	OFF																												
Open End																													
AIR 1 DELAY	K1 s																												
AIR 1 TIMER	K2 s																												
Air2	OFF																												
Air2 Start Position	L1 mm																												
AIR2 DELAY	L2 s																												
AIR2 TIMER	L3 s																												
<table border="1"> <tbody> <tr> <td>Air3</td> <td>OFF</td> </tr> <tr> <td>Air3 Start Position</td> <td>M1 mm</td> </tr> <tr> <td>AIR3 DELAY</td> <td>M2 s</td> </tr> <tr> <td>AIR3 BLOW</td> <td>M3 s</td> </tr> </tbody> </table>			Air3	OFF	Air3 Start Position	M1 mm	AIR3 DELAY	M2 s	AIR3 BLOW	M3 s																			
Air3	OFF																												
Air3 Start Position	M1 mm																												
AIR3 DELAY	M2 s																												
AIR3 BLOW	M3 s																												
<div> 0000.0 mm P P P P mm 0000.0 mm SSS Kg/cm² </div>																													


Press to enter the ejector setting screen (12).



Use to select the parameters to be set, input the numerical value and press , then the setting is complete.




To choose the mode, use to find the parameters to be selected, and use or to select.

The interface is used to set the parameters of speed, pressure and position in each stage of ejector and other advanced parameters, including 3 kinds of ejector modes (Not Use, Stop and Multi), auxiliary ejector, ejector pause, eject number and vibration ejector.

Blowing Setting Screen (13)

Press  to enter the blowing setting screen (13).

Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.


To choose the mode, use  to find the parameters to be selected, and use  or  to select.



This interface is used to completely control 3 groups of blowing device (including the start of blowing in groups, starting position, time delay of action and the duration of action).

5.2.12 Carriage Setting

Carriage Setting Screen (14)

Carriage Lubrication		Mold Name:		No.	2008-1-18 10:34	
MANUAL						
Carr Fast	Sp. A1 %	Pr. A2 %	Time A3 s	Carr Back	Sp. C1 %	Pr. C2 %
Carr Slow	B1 %	B2 %			C3 s	
<div> LUB. CYCLE D1 t ***** </div> <div> LUBE. TIME D2 s </div> <div> LBU. ALARM D3 s </div>						
<div> 0000.0 mm 0000.0 mm 0000.0 mm SSS Kg/cm² </div>						

Press  to enter the carriage setting screen (14).

Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.

This interface is used to control the advance or retraction of the carriage, using the parameters of speed, pressure and time to set (for example, carriage fast forward: advance for A3 seconds with the speed of A1% and the pressure of A2%, then advance with the parameters of carriage slow forward).


5.2.13 Core Pulling Setting



Core Pulling 1 Setting Screen (15)




Core Setting		Mold Name:		No. : 1		2008-1-18 10:53	
MANUAL							
Core A Setting		Core In/Out One Cycle		Timer			
Core In mode		Not Use		Core Out Mode		Not Use	
Sp.	Pr.	Time		Sp.	Pr.	Time	
Core In	A1 %	A2 %	A3 s	Core Out	A4 %	A5 %	A6 s
Core B Setting		Coer In/Out One Cycle		Limit			
Core In mode		Clamp To		Core Out Mode		Open To	
Sp.	Pr.	Time		Sp.	Pr.	Time	
Core In	B1 %	B2 %	B3 s	Core Out	B4 %	B5 %	B6 s
Core C Setting		Coer In/Out One Cycle		Limit			
Core In mode		After		Core Out Mode		After	
Sp.	Pr.	Count	Time	Sp.	Pr.	Count	Time
Core In	C1 %	C2 %	C3 t C4 s	Core Out	C5 %	C6 %	C7 t C8 s
0000.0 mm PPPP P mm 0000.0 mm SSS Kg/cm ²							

Core Pulling 2 Setting Screen (16)

Core Setting		Mold Name:		No. : 1		2008-1-18 11:03	
MANUAL							
Core D Setting		Core In/Out One Cycle		Timer			
Core In mode		Not Use		Core Out Mode		Not Use	
Sp.	Pr.	Time		Sp.	Pr.	Time	
Core In	A1 %	A2 %	A3 s	Core Out	A4 %	A5 %	A6 s
Core E Setting		Coer In/Out One Cycle		Limit			
Core In mode		Clamp To		Core Out Mode		Open To	
Sp.	Pr.	Time		Sp.	Pr.	Time	
Core In	B1 %	B2 %	B3 s	Core Out	B4 %	B5 %	B6 s
Core F Setting		Coer In/Out One Cycle		Limit			
Core In mode		Before		Core Out Mode		Before	
Sp.	Pr.	Time		Sp.	Pr.	Time	
Core In	C1 %	C2 %	C3 s	Core Out	C4 %	C5 %	C6 s
0000.0 mm PPPP P mm 0000.0 mm SSS Kg/cm ²							

Press  one time or two times, then the core pulling 1 setting screen (15) or core pulling 2 setting screen (16) will appear.

Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.

To choose the mode, use  to find the parameters to be selected, and use  or  to select.

Core is the action of pulling and inserting cores, that is, during mould clamping, use the oil cylinder to insert the core into the mould for injection; while during mould opening, pull back the core to the original position. This function mostly applies to moulds whose finished products are hollow.

Unscrewing is the revolving positioning control on the finished products with unscrewing by the oil hydraulic motor.

Please check if the machine has relevant configurations before using the functions above.

Setting of Core/Unscrewing: Computer can offer at most 6 groups of Core/Unscrewing control, subject to the configuration of the machine. Each Core/Unscrewing can individually set the pressure, speed and action time according to requirements.


Note: In the automatic mode, the injection and core are approaching at the same time in case that the core will contract due to injection, so the Core and Unscrewing cannot be used simultaneously. When using the function of unscrewing, the mode of Core In/Out One Cycle shall be selected as Timer.



5.2.14 Timer Setting

Timer Setting Screen (17)

Timer Setting		Mold Name		No.	1	2008-1-18 11:55	
MANUAL							
PLAST DLY.	A1	0.0	CYCLE No.	B1	0		
COOLING	A2	0.0	REJECT No.	B2	0		
RECYCLE	A3	0.0	RPRODUCT TIME	B3	0		
MELT BEF PLA	A4	0.0	GREASE CYCLE	B4	0		
CYCLE TIMER	A5	0.0	CYCLE MONIT	B5	0		
EJE OUT DLY	A6	0.0	FORCE BWD	B6	0		
LOW PR DETEC	A7	0.0	FORCE FWD	B7	0		
HP CHARGE DL	A8	0.0	AUX11	B8	0		
HP END DELAY	A9	0.0	UNSCREW IN C	B9	0		
CLAMP END DL	A10	0.0	UNSCREW OT C	B10	0		
VIB EJECT	A11	0.0					
CARR BWD DL	A12	0.0					
CARR END DL	A13	0.0					
PRUGE BUFFER	A14	0.0					
DR OPEN SLOW	A15	0.0					
DOOR OPEN	A16	0.0					

0000.0 mm P P P P mm 0000.0 mm SSS Kg/cm²

Press  one time to enter the timer setting screen (17).

Use  to select the parameters be set, input the numerical value and press , then the setting is complete.


This interface is used to set the parameters of relevant timers inside the controller (including the following time relay: plasticizing delay, cooling time, recycle, decompression before plasticizing, cycle alarm, eject out delay, low pressure clamping detection, high pressure charge delay, high pressure end delay, clamping end delay, vibration ejection, carriage backward delay, carriage end delay, purge buffer, slow door open and door open time).



5.2.15 Counter Setting

Counter Setting Screen (18)

Timer Setting		Mold Name		No.	1	2008-1-18 11:55	
MANUAL							
PLAST DLY.	A1	0.0	CYCLE No.	B1	0		
COOLING	A2	0.0	REJECT No.	B2	0		
RECYCLE	A3	0.0	RPRODUCT TIME	B3	0		
MELT BEF PLA	A4	0.0	GREASE CYCLE	B4	0		
CYCLE TIMER	A5	0.0	CYCLE MONIT	B5	0		
EJE OUT DLY	A6	0.0	FORCE BWD	B6	0		
LOW PR.DETEC	A7	0.0	FORCE FWD	B7	0		
HP CHARGE DL	A8	0.0	AUX11	B8	0		
HP END DELAY	A9	0.0	UNSCREW IN C	B9	0		
CLAMP END DL	A10	0.0	UNSCREW OT C	B10	0		
VIB EJECT	A11	0.0					
CARR BWD DL	A12	0.0					
CARR END DL	A13	0.0					
PRUGE BUFFER	A14	0.0					
DR OPEN SLOW	A15	0.0					
DOOR OPEN	A16	0.0					

0000.0 mm P P P P mm 0000.0 mm SSS Kg/cm²


Press , then the counter setting screen (18) will appear.



Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.

This interface can be used to set the parameters of relevant counters inside the controller (including the following counter relay: cycle number, rejected part number, production time, grease cycle, cycle monitor, force backward, force forward, auxiliary 11, unscrew in C count and unscrew out C count).

5.2.16 Temperature Deviation Alarm Setting

Temperature Deviation Alarm Setting Screen (19)

Press , then the temperature deviation alarm setting screen (19) will appear.

Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.

This interface is used to control the temperature of each stage of the barrel. The “A” values are the set temperature of each stage, generally working in combination with parameter “B”, “C” (if A=200, B=10, C=10, thus the temperature is controlled between “A - C” and “A + B”, that is 190°C~210°C).

Alarm will ring if the temperature exceeds the range: “AL03: Barrel Temperature Not Reach” or “AL43: Barrel Temperature Too High”.





Preheat Function: control the current temperature of each stage of barrel as $A \times D\%$.

The parameters “E” and “F” are used to achieve the automatic operation, which is convenient for the customization of production schedule.





The blue digit on the barrel is the actual temperature of current barrel.

5.2.17 Heat Channel Setting

Heat Channel Setting Screen (20)


Hot Runner HeaterControl		Mold Name: No. : 1		2008-1-18 14:22					
MANUAL									
T1	T2	T3	T4	T5	T6	T7	T8	T9	T10
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
T11	T12	T13	T14	T15	T16	T17	T18	T19T	T20
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Data Copy A11				<input type="text"/>					
 0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm ²									



Heat Channel Setting Screen (21)

Hot Runner HeaterControl		Mold Name: No. : 1		2008-1-18 14:22					
MANUAL									
T21	T22	T23	T24	T25	T26	T27	T28	T29	T30
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
T31	T32	T33	T34	T35	T36	T37	T38	T39	T40
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Data Copy A11				<input type="text"/>					
 0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm ²									

Heat Channel Setting Screen (22)

Hot Runner Heater Control		Mold Name: No. 1		2008-1-18 14:22					
T41	T42	T43	T44	T45	T46	T47	T48	T49	T50
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
T51	T52	T53	T54	T55	T56	T57	T58	T59	T60
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Data Copy A11 <input type="text"/>									
<div> 0000.0 mm P P P P mm 0000.0 mm SSS Kg/cm³ </div>									

Press  2, 3 or 4 times, then the heat channel setting screen (20), (21) or (22) will appear separately.

Use  to select the parameters to be set, input the numerical value and press , then the setting is complete.

This interface can realize the independent control of the temperature of each mould heat channel, making the temperature control more flexible and accurate (optional function).

5.2.18 Function Setting

Function Setting Screen (23)

Function Setting		Mold Name:	No.	1	2008-1-18 15:51
MANUAL					
Boost	A1	Robot ON	B1	DR OPEN TIME	C1
Air	A2	NOZ BLK	B2	DR AUTO TEST	C2
Acc Inject	A3	NozLeak Alm	B3	Aux66	C3
MD BEF	A4	No Mat Alm	B4	Aux67	C4
Boost Inject	A5	Auto Color	B5	Aux68	C5
Boost Plast	A6	SPECIAL EJT	B6	Aux69	C6
HOLD CORE IN	A7	EJECT PLATE	B7	Aux70	C7
Hyd.Nozz.ON	A8	SPECIAL CORE	B8	Aux71	C8
Photo Eye ON	A9	AUTO PURGE	B9	Aux72	C9
Auto Stop	D				
Syn Action	E				

0000.0mm P P P P P mm 0000.0mm SSS Kg/cm²

Press then the function setting screen (23) will appear.

Use to move the cursor to the function to be set, press to select "ON"; press to select "OFF", then the setting is complete.

- 1) Auto Stop: use or to select the following four modes, which are used with forming numbers, production batch setting and fault stop.
 - (i) Not Use
 - (ii) Pump
 - (iii) Heater
 - (iv) Pump&Heater
- 2) Syn Action:
 - (i) Eject: When choosing Eject, the mould opening and ejection can be processed at the same time, and the position of mould opening when the ejection is started can be set.
 - (ii) Plast: When choosing Plast, the mould opening and ejection can be processed while plasticizing.
 - (iii) Core: When choosing Core, the action of core inserting and pulling can be processed while mould opening and clamping.
 - (iv) Not Use

- 3) Acc Inject: When choosing "ON", the nitrogen injection device can be used (User has to order this device separately).
- 4) NozLeak Alarm: When choosing "ON", alarm will ring if the nozzle leaks (optional device).
- 5) No Mat Alarm: When choosing "ON", alarm will ring if there is no material in the hopper; when choosing "OFF", no alarm will be given even if the plasticizing is not completed when the cooling time ends.
- 6) The meanings of other functions can be understood literally, so no further descriptions will be given hereby.

5.2.19 Mould Data Selection

Mould Data Selection Screen (24)

Mould Select		Mold Name:	No.	1	2008-1-18 16:14
MANUAL					
001:	007:	0013:			
002:	008:	0014:			
003:	009:	0015:			
004:	0010:	0016:			
005:	0011:	0017:			
006:	0012:	0018:			
Mould No. <input type="text" value="A1"/> <input type="text" value="B1"/>					
Mould Copy <input type="text" value="A2"/> <input type="text" value="B2"/>					
Mould Sel <input type="text" value="A3"/>					
<div> 0000.0 mm P P P P mm 0000.0 mm SSS Kg/cm² </div>					

Press and the mould data selection screen (24) will appear.

The procedure of mould data operation:

- 1) Move the cursor to the position of mould number A1, input the number and press , thus complete the setting of mould number.
- 2) Use to move the cursor to the position of B1, input the letters or digits use to input the next letter. Then press to complete the setting of mould data remark.
- 3) If changing the mould number 01 to 02 is required, move the cursor to the position of mould selection A3, input 02 and press . For confirmation, press ; or else press .

150 groups of mould data memory are available, of which, mould data No. 1 to No.99 are standard data module, and No. 101 to No.150 are easy operation module (some of which can only be altered by mould data 100). Failure to alter the data means no duplication can be realized, so do not make free with the mould data 100.

5.2.20 Statistic Value

Quality Statistics Screen (25)

Statistic		Mold Name		No.	2008-1-18 16:49	
MANUAL						
Clear SD: OFF						
	Target	Toler	Curr.	Prev		
Cycle No.			0	0	0	
Open Time	A1	+ B1	0.00	0.00	0.00	0.00 0.00 0.00
Clamp Time	A2	+ B2	0.00	0.00	0.00	0.00 0.00 0.00
Inject Time	A3	+ B3	0.00	0.00	0.00	0.00 0.00 0.00
Plast Time	A4	+ B4	0.00	0.00	0.00	0.00 0.00 0.00
Cycle Time	A5	+ B5	0.0	0.0	0.0	0.0 0.0 0.0
H.P.CH POS	A6	+ B6	0.0	0.0	0.0	0.0 0.0 0.0
Inject End	A7	+ B7	0.0	0.0	0.0	0.0 0.0 0.0
Plast End	A8	+ B8	*****	*****	*****	***** 0.0 0.0
Open Pos	A9	+ B9	0.0	0.0	0.0	0.0 0.0 0.0
MAX INJ SP.	A10	+ B10	0.0	0.0	0.0	0.0 0.0 0.0
MAX RPM	A11	+ B11	0	0	0	0 0 0
QUALITY			OK	OK	OK	
Product Time 0.0 h Product ***** DEFECT 0 (0.0 %)						
000mm P P P P mm 0000.0 mm SSS Kg/cm ²						

Press to enter the quality statistics screen (25).

Use to select the parameters to be set, input the numerical value and press , then the setting is complete.

The interface is mainly used to display the statistics of the products quality. In which, product qualification parameter may be set, i.e. the tolerance.

5.2.21 Timer Monitor

Timer Monitor Screen (26)

Timer Monitor		Mold Name		No.	1	2008-1-24 15:29
MANUAL						
		Set.	Act.		Set.	Act.
TM00	CYCLE TIME		0.00	TM17	HOLD3 TIME	***. 0.0
TM01	CLAMP TIME		0.0	TM18	HOLD4 TIME	***. 0.0
TM02	CARR. FWD.		0.0	TM19	HOLD5 TIME	***. 0.0
TM03	FILLING		0.0	TM20	PURGE PLAST	***. 0.0
TM04	HOLD TIME		0.0	TM21	EJECT PAUSE	***. 0.0
TM05	PLAST DLY.	***. *	0.0	TM22	CORE A IN	***. 0.0
TM06	COOLING	***. *	0.0	TM23	CORE A OUT	***. 0.0
TM07	BEFORE DECOM		0.0	TM24	CORE B IN	***. 0.0
TM08	PLAST		0.0	TM25	CORE B OUT	***. 0.00
TM09	AFTER DECOMP		0.0	TM26	CORE C IN	***. 0.00
TM10	CARR. BWD		0.0	TM27	CORE C OUT	***. 0.00
TM11	MD OPEN		0.0	TM28	CORE D IN	***. 0.00
TM12	EJECT TIME		0.0	TM29	CORE D OUT	***. 0.00
TM13	RECYCLE	***. *	0.0	TM30	LUBE. TIME	***. 0.0
TM14	INJECT TIME	***. *	0.0	TM31	LUB. ALARM	***. 0.0
TM15	HOLD1 TIME	***. *	0.0	TM32	CARR. FAST	***. 0.0
TM16	HOLD2 TIME	***. *	0.0	TM33	CARR. BACK	***. 0.0

0000.0 mm
 P P P P 1 mm
 0000.0 mm
 SSS Kg/cm²


Timer Monitor Screen (27)

Timer Monitor		Mold Name		No.	1	2008-1-18 17:13
MANUAL						
		Set.	Act.		Set.	Act.
TM34	MELT BEF PLA	***. *	0.00	TM51	AIR 2 TIMER	***. 0.0
TM35	CYCLE TIMER	***. *	0.0	TM52	AIR 3 DELAY	***. 0.0
TM36	EJE OUT DLY	***. *	0.0	TM53	AIR 3 TIMER	***. 0.0
TM37	LOW PR. DETEC	***. *	0.0	TM54	FORCE FWD	***. 0.0
TM38	HP CHARGE DL	***. *	0.0	TM55	FORCE BWD	***. 0.0
TM39	HP END DELAY	***. *	0.0	TM56	AIR 1 DELAY	***. 0.0
TM40	CLAMP END DL	***. *	0.0	TM57	AIR 2 DELAY	***. 0.0
TM41	VIB EJECT	***. *	0.0	TM58	CORE F IN	***. 0.0
TM42	CARR BWD DL	***. *	0.0	TM59	CORE F OUT	***. 0.00
TM43	CARR END DL	***. *	0.0	TM60	MOTOR START	***. 0.00
TM44	PURGE BUFFER	***. *	0.0	TM61	ORIGIN RESET	***. 0.00
TM45	DR. OPEN SLOW	***. *	0.0	TM62	MD ADJ MON.	***. 0.00
TM46	DOOR OPEN	***. *	0.0	TM63	ALARM ON	***. 0.00
TM47	MD ADJ. DELAY	***. *	0.0	TM64	ALARM OFF	***. 0.0
TM48	CLP INTERVAL	***. *	0.0	TM65	OUTPUT MON.	***. 0.0
TM49	FAST OPEN DL	***. *	0.0	TM66	TM066	***. 0.0
TM50	AIR 1 TIMER	***. *	0.0	TM67	GREASE TIMER	***. 0.0

0000.0 mm
 P P P P 1 mm
 0000.0 mm
 SSS Kg/cm²


Timer Monitor Screen (28)

Timer Monitor		Mold Name:		No.		1		2008-1-18 17:20	
MANUAL									
		Set.	Act.			Set.	Act.		
TM68	EJE.INTERVAL	***.	0.0	TM85	CORE E IN	***.	0.0		
TM69	COLD START	***.	0.0	TM86	CORE E OUT	***.	0.0		
TM70	NOZZ.CLOSE	***.	0.0	TM87	STEM 1 RELAY	***.	0.0		
TM71	ACC DELAY	***.	0.00	TM88	STEM 1 OPEN	***.	0.0		
TM72	LOW PRE DLY	***.	0.00	TM89	STEM 2 RELAY	***.	0.0		
TM73	ACTION DLY	***.	0.00	TM90	STEM 2 OPEN	***.	0.0		
TM74	DOOR MONI.	***.	0.0	TM91	STEM 3 RELAY	***.	0.0		
TM75	SPEC.LOW PRE	***.	0.0	TM92	STEM 3 OPEN	***.	0.0		
TM76	MD OPEN BP	***.	0.0	TM93	STEM 4 RELAY	***.	0.0		
TM77	NOZZ.OPEN	***.	0.0	TM94	STEM 4 OPEN	***.	0.0		
TM78	INJ.CUSHION	***.	0.0	TM95	STEM 5 RELAY	***.	0.0		
TM79	PLA. CUSHION	***.	0.0	TM96	STEM 5 OPEN	***.	0.0		
TM80	HOLD6 TIME	***.	0.0	TM97	TM97	***.	0.0		
TM81	HOLD7 TIME	***.	0.0	TM98	CHARGE MON.	***.	0.0		
TM82	HOLD8 TIME	***.	0.0	TM99	HP. RELEASE	***.	0.0		
TM83	HOLD9 TIME	***.	0.0						
TM84	HOLD10 TIME	***.	0.0						




0000.0

mm




PPPP

mm



0000.0

mm



SSS

Kg/cm²



0000.0 mm



PPPP P mm



0000.0 mm


SSS Kg/cm²


Press once to enter the time monitor screen (26).

In this interface, the setting and operation status of timers can be monitored, in case of monitoring other timers, simultaneously press + (or) keys, and switch among the interface(26) to interface(28).

This interface is mainly used for inspection of relevant time relay setting and working status of the system.

5.2.22 Counter Monitor

Counter Monitor Screen (29)

Counter Monitor

Mold Name:

No.


:


1


2008-1-18 17:56


MANUAL

		Set.	Act.			Set.	Act.
CT00	CYCLE No.	*****	0	CT10	FORCE FWD	*****	*****
CT01	REJECT No.	*****	0	CT11	AUX11	*****	*****
CT02	PRODUCT TIME	*****	0.0	CT12	UNSCREW IN C	*****	*****
CT03	PURGE	*****	*****	CT13	UNSCREW OT C	*****	*****
CT04	EJECT No.	*****	*****	CT14	AUX14	*****	*****
CT05	VIB.EJT.No.	*****	*****	CT15	AUX15	*****	*****
CT06	LUB. CYCLE	*****	*****	CT16	AUX16	*****	*****
CT07	GREASE CYCLE	*****	*****	CT17	AUX17	*****	*****
CT08	CYCLE MONIT	*****	*****	CT18	AUX18	*****	*****
CT09	FORCE BWD	*****	*****	CT19	AUX19	*****	*****

 0000.0 mm

 P P P P P mm

 0000.0 mm

 SSS Kg/cm²

0000.0 mm
 P P P P mm
 0000.0 mm
 SSS Kg/cm²

Press key twice to enter the counter monitor screen (29).

The interface is mainly used for monitoring the setting and working status of counters.

5.2.23 Input Monitor

Input Monitor Screen (30)

Input Monitor		Mold Name:	No.	1	2008-1-18 19:03
MANUAL					
EI00	FRONT DOOR	<input type="radio"/>	EI14	MD CLOSE ENA	<input type="radio"/>
EI01	REAR DOOR	<input type="radio"/>	EI15	EJECT PLATE	<input type="radio"/>
EI02	SAFETY DR LS	<input type="radio"/>	EI16	MD. ADJ. O/L	<input type="radio"/>
EI03	CARRIAGE LS	<input type="radio"/>	EI17	PUMP O/L	<input type="radio"/>
EI04	CORE B IN	<input type="radio"/>	EI18	ADJ 1 FWD LS	<input type="radio"/>
EI05	CORE B OUT	<input type="radio"/>	EI19	ADJ 1 BWD LS	<input type="radio"/>
EI06	UNSCR C CNT	<input type="radio"/>	EI20	MD ADJ COUNT	<input type="radio"/>
EI07	NOZZLE GUARD	<input type="radio"/>	EI21	LUB. LEVEL	<input type="radio"/>
EI08	CORE A IN	<input type="radio"/>	EI22	LUB. PRESS	<input type="radio"/>
EI09	CORE A OUT	<input type="radio"/>	EI23	CORE C IN	<input type="radio"/>
EI10	PHOTO EYE	<input type="radio"/>	EI24	CORE C OUT	<input type="radio"/>
EI11	ACC END	<input type="radio"/>	EI25	FILTER	<input type="radio"/>
EI12	MD AREA FREE	<input type="radio"/>	EI26	AUX/DR OPEN	<input type="radio"/>
EI13	EJE FWD ENA.	<input type="radio"/>	EI27	DOOR OPENED	<input type="radio"/>
EI28	DR CLS SLOW	<input type="radio"/>	EI29	CLAMP PRESET	<input type="radio"/>
EI30	EJECT PRESET	<input type="radio"/>	EI31	INJ. PRESET	<input type="radio"/>
EI32	MOTOR RUNED	<input type="radio"/>	EI33	SLV PUMP RUN	<input type="radio"/>
EI34	CORE D IN	<input type="radio"/>	EI35	CORE D OUT	<input type="radio"/>
EI36	CORE E IN LS	<input type="radio"/>	EI37	CORE E OUT L	<input type="radio"/>
EI38	DOOR CRASH	<input type="radio"/>	EI39	OIL LEVEL	<input type="radio"/>
EI40	AUX/DOOR CLS	<input type="radio"/>	EI41	REAR DOOR 2	<input type="radio"/>
EI42	EJE BWD ENA.	<input type="radio"/>	EI43	ROBOT EMSTOP	<input type="radio"/>
EI44	ROBOT EMG 2	<input type="radio"/>	EI45	ROBOT OFF	<input type="radio"/>
EI46	EN CORE A IN	<input type="radio"/>	EI47	EN CORE A OT	<input type="radio"/>
EI48	EN CORE B IN	<input type="radio"/>	EI49	EN CORE B OT	<input type="radio"/>
EI50	GREASE PR.	<input type="radio"/>	EI51	OPEN LIMIT	<input type="radio"/>
EI52	CLAMP LIMIT	<input type="radio"/>	EI53	FOOT PLATE	<input type="radio"/>
EI54	CORE F IN LS	<input type="radio"/>	EI55	CORE F OUT L	<input type="radio"/>

0000.0 mm

P P P P P mm

0000.0 mm

SSS Kg/cm²

Press three times to enter the input monitor screen (30).

Through inspection of the relevant inputs status, to confirm whether the input signals from the controller have been sent to the corresponding points on I/O board, and estimate the operating status of I/O board system or PCB failure.

5.2.24 Output Monitor

Output Monitor Screen (31)

Output Monitor		Mold Name:	No.	1	2008-1-18 19:19
MANUAL					
EO00	ADJ.1 FWD	<input type="radio"/>	EO14	CORE B IN	<input type="radio"/>
EO01	ADJ.1 BWD	<input type="radio"/>	EO15	CORE B OT	<input type="radio"/>
EO02	MD CLOSE	<input type="radio"/>	EO16	ACC CHARGE	<input type="radio"/>
EO03	CARRIAGE FWD	<input type="radio"/>	EO17	ACC INJECT	<input type="radio"/>
EO04	INJECTION	<input type="radio"/>	EO18	AIR 2	<input type="radio"/>
EO05	PLAST.	<input type="radio"/>	EO19	AIR 1	<input type="radio"/>
EO06	MELT DECOMPR	<input type="radio"/>	EO20	MOLD OPEN BP	<input type="radio"/>
EO07	CARRIAGE BWD	<input type="radio"/>	EO21	BOOST/LOW PR	<input type="radio"/>
EO08	MD. OPEN	<input type="radio"/>	EO22	LOW PR CLAMP	<input type="radio"/>
EO09	EJT. FWD	<input type="radio"/>	EO23	AUX/AIR 3	<input type="radio"/>
EO10	EJT. BWD	<input type="radio"/>	EO24	DOOR OPEN	<input type="radio"/>
EO11	BOOST	<input type="radio"/>	EO25	DOOR CLOSE	<input type="radio"/>
EO12	CORE A IN	<input type="radio"/>	EO26	FAST OPEN	<input type="radio"/>
EO13	CORE A OT	<input type="radio"/>	EO27	AUTO MODE	<input type="radio"/>
EO28	MD OPEN END	<input type="radio"/>	EO29	DR CLOSED	<input type="radio"/>
EO30	CORE C IN	<input type="radio"/>	EO31	CORE C OT	<input type="radio"/>
EO32	GAS INJECTION	<input type="radio"/>	EO33	DR SLOWDOWN	<input type="radio"/>
EO34	BRAKE RELEASE	<input type="radio"/>	EO35	CORE D IN	<input type="radio"/>
EO36	CORE D OT	<input type="radio"/>	EO37	CORE E IN	<input type="radio"/>
EO38	CORE E OT	<input type="radio"/>	EO39	SMALL PUMP	<input type="radio"/>
EO40	CARRIAGE IN	<input type="radio"/>	EO41	CARRIAGE OUT	<input type="radio"/>
EO42	MOLD OP/CL	<input type="radio"/>	EO43	AUX PUMP 1	<input type="radio"/>
EO44	AUX PUMP 2	<input type="radio"/>	EO45	CORE F IN	<input type="radio"/>
EO46	CORE F OT	<input type="radio"/>	EO47	COOL WATER	<input type="radio"/>
EO48	REJECT	<input type="radio"/>	EO49	MOLD CLOSED	<input type="radio"/>
EO50	EJT FWD END	<input type="radio"/>	EO51	EJT BWD END	<input type="radio"/>
EO52	CORE A FWDED	<input type="radio"/>	EO53	CORE A BWDED	<input type="radio"/>
EO54	CORE B FWDED	<input type="radio"/>	EO55	CORE B BWDED	<input type="radio"/>

0000.0 mm
 P P P P mm
 0000.0 mm
 SSS Kg/cm²


Output monitor Screen (32)




Output Monitor		Mold Name:	No.	1	2008-1-18 19:35
MANUAL					
EO56	HP RELEASE	<input type="radio"/>	EO70	PR. CHARGE	<input type="radio"/>
EO57	HP. CLAMP	<input type="radio"/>	EO71	STOPER ENA.	<input type="radio"/>
EO58	HP. OPEN	<input type="radio"/>	EO72	HP/STOPER	<input type="radio"/>
EO59	NUT CLOSE	<input type="radio"/>	EO73	PUMP 2	<input type="radio"/>
EO60	NUT OPEN	<input type="radio"/>	EO74	PUMP 3	<input type="radio"/>
EO61	HP. CHARGE	<input type="radio"/>	EO75	PUMP 4	<input type="radio"/>
EO62	TIE BAR FWD	<input type="radio"/>	EO76	PUMP 5	<input type="radio"/>
EO63	ADJ. 2 FWD	<input type="radio"/>	EO77	PUMP 6	<input type="radio"/>
EO64	ADJ. 2 BWD	<input type="radio"/>	EO78	AUX	<input type="radio"/>
EO65	ADJ. 3 FWD	<input type="radio"/>	EO79	AUX	<input type="radio"/>
EO66	ADJ. 3 BWD	<input type="radio"/>			
EO67	ADJ. 4 FWD	<input type="radio"/>			
EO68	ADJ. 4 BWD	<input type="radio"/>			
EO69	PLAST/DECOMP	<input type="radio"/>			

0000.0 mm
 P P P P mm
 0000.0 mm
 SSS Kg/cm²

Output monitor Screen (33)



Press  four times to enter the output monitor screen (31).

In this interface, the setting and operation status of outputs can be monitored, in case of monitoring other outputs status, simultaneously press  +  (or ) keys, and switch among the interface (31) to interface (33).

Through inspection of the relevant outputs status, to confirm whether the output signals from the controller have been sent to the corresponding points on I/O board, and estimate the operating status of I/O board system or PCB failure.

5.2.25 Relay Monitor

EI Relay Monitor Screen (34)

Relay Monitor	Mold Name	No. :	1	2008-1-18 20:17
MANUAL				
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9
EI000
EI020
EI040
EI060



EO Relay Monitor Screen (35)

Relay Monitor	Mold Name	No. :	1	2008-1-18 20:18
MANUAL				
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9
EO000
EO020
EO040
EO060



ER Relay Monitor Screen (36)

Relay Monitor	Mold Name	No. :	1	2008-1-18 20:20
MANUAL				
<div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> </div> <div> <div>ER000</div> <div>...</div> <div>...</div> </div>				
<div> <div>0000.0 mm</div> <div>PPPP P mm</div> <div>0000.0 mm</div> <div>SSS Kg/cm²</div> </div>				

KY Relay Monitor Screen (37)

Relay Monitor	Mold Name	No. :	1	2008-1-18 20:22
MANUAL				
<div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> </div> <div> <div>KY000</div> <div>...</div> <div>...</div> </div> <div> <div>KY020</div> <div>...</div> <div>...</div> </div> <div> <div>KY040</div> <div>...</div> <div>...</div> </div>				
<div> <div>0000.0 mm</div> <div>PPPP P mm</div> <div>0000.0 mm</div> <div>SSS Kg/cm²</div> </div>				




LS Relay Monitor Screen (38)

Relay Monitor	Mold Name:	No. :	1	2008-1-18 20:24																									
MANUAL																													
<table border="1"> <thead> <tr> <th></th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> </tr> </thead> <tbody> <tr> <td>LS000</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>LS020</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>LS040</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>LS060</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> </tbody> </table>						0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9	LS000	LS020	LS040	LS060
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9																									
LS000																									
LS020																									
LS040																									
LS060																									
<div> 0000.0 mm P P P P P mm 0000.0 mm SSS Kg/cm² </div>																													





SL Relay Monitor Screen (39)

Relay Monitor	Mold Name:	No. :	1	2008-1-18 20:27																																																		
MANUAL																																																						
<table border="1"> <thead> <tr> <th></th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> </tr> </thead> <tbody> <tr> <td>SL000</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>SL020</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>SL040</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>SL060</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>SL080</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>SL100</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>SL120</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>SL140</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>SL160</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> </tbody> </table>						0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9	SL000	SL020	SL040	SL060	SL080	SL100	SL120	SL140	SL160
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9																																																		
SL000																																																		
SL020																																																		
SL040																																																		
SL060																																																		
SL080																																																		
SL100																																																		
SL120																																																		
SL140																																																		
SL160																																																		
<div> 0000.0 mm P P P P P mm 0000.0 mm SSS Kg/cm² </div>																																																						





MF Relay Monitor Screen (40)

Relay Monitor	Mold Name:	No. :	1	2008-1-18 20:31																														
MANUAL																																		
<table border="0"> <thead> <tr> <th></th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> </tr> </thead> <tbody> <tr> <td>MF000</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>MF020</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>MF040</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>MF060</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>MF080</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> </tbody> </table>						0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9	MF000	MF020	MF040	MF060	MF080
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9																														
MF000																														
MF020																														
MF040																														
MF060																														
MF080																														
<div style="text-align: center;">  0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm² </div>																																		





LF Relay Monitor Screen (41)

Relay Monitor	Mold Name:	No. :	1	2008-1-18 20:34										
MANUAL														
<table border="0"> <thead> <tr> <th></th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> </tr> </thead> <tbody> <tr> <td>LF000</td> <td>.....</td> <td></td> <td></td> <td></td> </tr> </tbody> </table>						0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9	LF000			
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9										
LF000													
<div style="text-align: center;">  0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm² </div>														

WK Relay Monitor Screen (42)





Relay Monitor	Mold Name	No.	1	2008-1-18 20:37																																																							
MANUAL																																																											
<table border="1"> <thead> <tr> <th></th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> </tr> </thead> <tbody> <tr><td>WK000</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>WK020</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>WK040</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>WK060</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>WK080</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>WK100</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>WK120</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>WK140</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>WK160</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>WK180</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> </tbody> </table>						0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9	WK000	WK020	WK040	WK060	WK080	WK100	WK120	WK140	WK160	WK180
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9																																																							
WK000																																																							
WK020																																																							
WK040																																																							
WK060																																																							
WK080																																																							
WK100																																																							
WK120																																																							
WK140																																																							
WK160																																																							
WK180																																																							
 0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm ²																																																											

KP Relay Monitor Screen (43)

Relay Monitor	Mold Name	No.	1	2008-1-18 20:41																																																							
MANUAL																																																											
<table border="1"> <thead> <tr> <th></th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> </tr> </thead> <tbody> <tr><td>KP000</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>KP020</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>KP040</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>KP060</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>KP080</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>KP100</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>KP120</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>KP140</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>KP160</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> <tr><td>KP180</td><td>.....</td><td>.....</td><td>.....</td><td>.....</td></tr> </tbody> </table>						0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9	KP000	KP020	KP040	KP060	KP080	KP100	KP120	KP140	KP160	KP180
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9																																																							
KP000																																																							
KP020																																																							
KP040																																																							
KP060																																																							
KP080																																																							
KP100																																																							
KP120																																																							
KP140																																																							
KP160																																																							
KP180																																																							
 0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm ²																																																											




TM Relay Monitor Screen (44)

Relay Monitor	Mold Name	No.	1	2008-1-18 20:44
MANUAL				
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9
TM000
TM020
TM040
TM060
TM080





 0000.0 mm
  P P P P P mm
  0000.0 mm
  SSS Kg/cm²

CT Relay Monitor Screen (45)





Relay Monitor	Mold Name	No.	1	2008-1-18 20:46
MANUAL				
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9
CT000

 0000.0 mm
  P P P P P mm
  0000.0 mm
  SSS Kg/cm²




AL Relay Monitor Screen (46)

Relay Monitor	Mold Name:	No. :	1	2008-1-21 9:56																														
MANUAL																																		
<table border="1"> <thead> <tr> <th></th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> </tr> </thead> <tbody> <tr> <td>AL000</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>AL020</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>AL040</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>AL060</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>AL080</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> </tbody> </table>						0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9	AL000	AL020	AL040	AL060	AL080
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9																														
AL000																														
AL020																														
AL040																														
AL060																														
AL080																														
 0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm ²																																		





LA Relay Monitor Screen (47)

Relay Monitor	Mold Name:	No. :	1	2008-1-21 10:01																				
MANUAL																								
<table border="1"> <thead> <tr> <th></th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> <th>0 1 2 3 4</th> <th>5 6 7 8 9</th> </tr> </thead> <tbody> <tr> <td>LA000</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>LA020</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> <tr> <td>LA040</td> <td>.....</td> <td>.....</td> <td>.....</td> <td>.....</td> </tr> </tbody> </table>						0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9	LA000	LA020	LA040
	0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9																				
LA000																				
LA020																				
LA040																				
 0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm ²																								

MG Relay Monitor Screen (48)

Relay Monitor	Mold Name:	No. :	1	2008-1-21 10:04
MANUAL				
<div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> </div> <div> MG000 - - - - - MG020 - - - - - MG040 - - - - - </div>				
<div>  0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm² </div>				


MO Relay Monitor Screen (49)

Relay Monitor	Mold Name:	No. :	1	2008-1-21 10:07
MANUAL				
<div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> </div> <div> MO000 - - - - - </div>				
<div>  0000.0 mm  P P P P P mm  0000.0 mm  SSS Kg/cm² </div>				

SC Relay Monitor Screen (50)

Relay Monitor	Mold Name:	No. :	1	2008-1-21 10:10
MANUAL				





0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9
SC000

	0000.0 mm		PPPP P mm		0000.0 mm		SSS Kg/cm ²
---	-----------	---	-----------	---	-----------	---	------------------------

EJ Relay Monitor Screen (51)

Relay Monitor	Mold Name:	No. :	1	2008-1-21 10:13
MANUAL				

0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9
EJ000

	0000.0 mm		PPPP P mm		0000.0 mm		SSS Kg/cm ²
---	-----------	---	-----------	---	-----------	---	------------------------

OT Relay Monitor Screen (52)

Relay Monitor	Mold Name:	No. :	1	2008-1-21 10:15
MANUAL				
<div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> </div> <div> <div>OT000</div> <div>OT020</div> </div> <div> <div>.....</div> <div>.....</div> <div>.....</div> <div>.....</div> </div>				
<div> <div>0000.0 mm</div> <div>PPPP P mm</div> <div>0000.0 mm</div> <div>SSS Kg/cm²</div> </div>				





S1 Relay Monitor Screen (53)

Relay Monitor	Mold Name:	No. :	1	2008-1-21 10:21
MANUAL				
<div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> <div>0 1 2 3 4</div> <div>5 6 7 8 9</div> </div> <div> <div>S1000</div> </div> <div> <div>.....</div> <div>...</div> </div>				
<div> <div>0000.0 mm</div> <div>PPPP P mm</div> <div>0000.0 mm</div> <div>SSS Kg/cm²</div> </div>				

PR Relay Monitor Screen (54)

Relay Monitor	Mold Name:	No. :	1	2008-1-21 10:26
MANUAL				





0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9
PR000

	0000.0 mm		PPPP P mm		0000.0 mm		SSS Kg/cm ²
---	-----------	---	-----------	---	-----------	---	------------------------


BP Relay Monitor Screen (55)


Relay Monitor	Mold Name:	No. :	1	2008-1-21 10:27
MANUAL				

0 1 2 3 4	5 6 7 8 9	0 1 2 3 4	5 6 7 8 9
BP000




	0000.0 mm		PPPP P mm		0000.0 mm		SSS Kg/cm ²
---	-----------	---	-----------	---	-----------	---	------------------------

S2 Relay Monitor Screen (56)



Press  five times to enter the relay monitor screen (34).

In this interface, internal relays status can be monitored, in case of monitoring other relays

status, press  +  (or ) keys to switch among relay monitor interfaces.



These interfaces are used to confirm whether the signal receiving and sending function of controller internal relays is in normal condition, in case of failure during the machine operating, troubleshooting can be found through these interfaces(in which, @ means operating, • means not operating).




5.2.26 Program Monitor


Program Monitor Screen (57)



Ladder Monitor		Mold Name:	No.	1	2008-1-21 10:42
MANUAL					
A	B	Search			
00000	LDI	EI000	*		
00001	AND	EI002	*		
00002	OUT	WK020	*		
00003	ANI	EI001	*		
00004	OUT	WK068	*		
00005	LDI	KY005	*		
00006	ANI	EI001	*		
00007	OR	ER001	*		
00008	ANI	LS040	*		
00009	ANI	KY006	@		
00010	AND	ER002	*		
00011	OR	AL069	*		
00012	ANI	KY000	*		

0000.0 mm 0000.0 mm 0000.0 mm SSS Kg/cm²

Press  six times, or press , it will show program monitor screen (57).

"A": Input position of internal relay types, press  or  key to switch internal relay types, then press  key to confirm.


"B": Input position of internal relay serial number, input the serial number, and then press  key to confirm.


"Search": While moving the cursor to this position, press  key once, one required relay that internal program used can be found immediately, press  key again, and a second relay that internal program used can be found, and the like.

This interface is mainly used for inspection of controller program, and understanding the operation principle of the machine. It is convenient for operation and maintenance.

5.2.27 Injection End Position


Injection End Position Screen (58)








Press  once to enter the injection end position screen (58). This interface displays the injection end positions and the average values of 50 products produced.

5.2.28 Injection Speed Curve

Injection Speed Curve Screen (59)





Press  twice to enter the injection speed curve screen (59).


Press  key to move the cursor and press  or  key to select ON or OFF, press  key, to complete the setting.

5.2.29 Injection Pressure Curve

Injection Pressure Curve Screen (60)



Press  three times to enter the injection pressure curve screen (60).


Press  key, at this time, the computer will adapt to the machine to perform automatic linear adjustment of pressure, and automatically show the linear values on the screen.

5.2.30 Help


Help Screen (61)




Help Screen (62)




Help Screen (63)






Help Screen (64)



Press  once to enter the help screen (61).

Press  or , to select help types.

Help interfaces from (61) ~ (64), help types include Function Introduction, Data Introduction, Alarm and Maintenance.

Press  key, move the cursor from the main catalogue to the sub-catalogue, then press  or  key, to check the detailed description of help content.

Function Introduction:

Automatic stop selection—Select four mode, machine stop automatically when cycle count is over.

Switching from filling to hold—Switch by injection timer; Switch by injection position V; Switch by pressure setting.

Hydraulic nozzle—Turn ON for hydraulic nozzle (option).

Holding pressure alarm—Alarm comes when holding pressure is over (option).

Synchronise movement—Ejecting during open; Plasticization during open; Core pulling during mold movement.

Other function—Meaning can be understood by wordings.

Data Introduction:

Filling time—Timing from injection stage I to V.

Injection end point—Display of injection end point.

Injection time—Setting of injection time.

Plasticization end point—Setting of plasticization end point.

Injection stage I—Setting of injection stage I.

Holding pressure stage I—Setting of holding pressure stage I.

Plasticization time—Display of plasticization time.

Plasticization delay—Setting of plasticization delay time.

Low temperature alarm—Low temperature alarm function.

Plasticization stage I—Setting of plasticization stage I.

Plasticization stage II—Setting of plasticization stage II.

Melt Decompression—Setting of Melt Decompression.

Fast speed clamp—Setting of fast speed clamp.

Low pressure clamp—Setting of low pressure clamp.

High pressure clamp—Setting of high pressure clamp.

Display of clamping force—Display of clamping force.

Boost clamp—Boost the speed of clamping.

Low pressure clamp protection—Low pressure clamping for mold protection.

High pressure clamp—Ensure enough clamping pressure.

Alarm:

AL03: Barrel Temperature Not Reach—Actual barrel temperature is lower than the minus deviation of setting temperature.

AL04: Lubrication Oil Level Too Low—The oil level of lubrication oil is too low.

AL06: Pump O/L Alm—Check the overload of oil pump motor.

AL07: Md Adj O/L Alm—Check the overload of mould-adjust motor.

AL08: Rear Door Alm—Close the rear safety door and check the limit switch.

AL09: Front Door Alm—Close the front safety door and check the limit switch.

AL10: Md Adj-Limit Alm—The mold thickness is less than the minimum thickness or check safety limit switch for mold-adjusting.

AL11: Md Adj-Limit Alm—The mold thickness exceeds the maximum thickness or check the safety limit switch for mold-adjusting.

- AL19: Nozz Fwd LS Alm — The limit switch for carriage forward has not been triggered during automatic operation.
- AL20: Nozz Guard Open — The purge guard fails to be closed during injection.
- AL21: Nozz Block Alm — The nozzle is blocked by foreign matters. Check the injection position setting or nozzle.
- AL22: Short Shot or Over Shot — Injection end position has gone beyond the tolerance setting. Adjust the tolerance setting or check ring.
- AL23: No Material Alm — During automatic operation, plasticization time exceeds cooling time setting. Check for hopper blocking.
- AL24: Cyc Completed Alm — The actual cycle counter has reached the production counter setting under automatic operation.
- AL25: Cyc Time Long Al — The production cycle time exceeds the alarm setting of the cyclic time.
- AL26: Md Protect Alm — There are plastics in mold or the high-press clamp position and low-press time setting are not correct.
- AL29: Photo Cut Alm — When photo cell is used for recycle, please clean off the products or foreign matters on the slide way.
- AL48: Oil Filter Clog — Check and clean oil filter.
- AL30: Oil Temp Low Alm — The actual temp of the hydraulic oil is lower than the setting for the minus allowed deviation.
- AL31: Oil Temp High Alm — The actual temp of the hydraulic oil is higher than the setting for the plus allowed deviation.
- AL32: Core LS Alm — During automatic operation the core-pulling time exceeds the setting of the limit alarm time of the core.
- AL33: Eje LS Alm — During automatic operation the ejection time exceeds the setting of the limit alarm time of the ejector.
- AL49: Robot Alarm — Check robot device.
- AL35: Acc Charge Alm — When ACC injection is ON, charging time exceeds cooling time. Please check the charging pressure switch.
- AL61: Oil Level Too Low — Check oil volume.
- AL36: Md Adj Sensor Alm — During mold-adjustment the mold adjustment sensor is found to be faulty. Please check the mold-adjustment.
- AL38: Barrel Preheat — Preheat function turn ON.
- AL39: Check Unscrew Counting Sensor — During automatic operation, the unscrewing time exceeds the setting of the limit alarm time.
- AL05: Low Lub Press — Lubrication pressure too low. Oil pipe break or oil pump damage.
- AL50: Pump Motor Not Start — Check whether each phase voltage and 10A fuse are normal and AC 3A switch has tripped.

Maintenance:

- Daily: Emergency stop switch — Confirm the cut-off of pump and power.
- Central lubrication — Check lubrication status, any block or leakage in the circuit.
- Cleaning — Keep clean.
- Heating barrel — Check heater and thermocouple.
- Safety door — Check door safety under manual and semi-auto mode.
- Oil pressure&tempera — Check oil pressure and temperature. Temperature should below 50 degree.
- Weekly: Lubrication oil — lubricate all moving parts.
- Check all switch&con — Check the control cabinet.

Check hydraulic circ— If leakage, tighten the joints or replace oil seal.

Annually: Check hydraulic oil— Check hydraulic oil quality.

Check cable— Check the hardening of cables due to oil.

Check nozzle— Check wear of nozzle, centre with the fix platen.

Check mold platen— Check the parallel of fixed platen, moving platen and rear platen.

Check hydraulic motor— Check the noise of coupling. Apply grease or replace bearing.

5.2.31 System Time and Language Setting

System Time and Language Setting Screen (65)

Firstly, press + keys, then press + (or) to turn over the page, enter the system time and language setting screen (65).

Press to move the cursor to the items to be set, input corresponding value, then press key, to complete the setting (in which, date format: yyyy/mm/dd, time format: hh:mm).

To change system language, press or key, switch among English, Chinese and the third language.

5.2.32 Action Stroke Stage Number Selection

Action Stroke Stage Number Selection Screen (66)

Mold Name		No. :	1	2008-1-22 10:56
MANUAL				
Open Number	A1			
Clamp Number	A2			
Inject Number	A3			
Hold Number	A4			
Plast Number	A5			
0000.0 mm P P P P P mm 0000.0 mm SSS Kg/cm ²				

Firstly, press + keys, then press + (or) to turn over the page, enter the action stroke stage number selection screen (66). Press to move the cursor to the position required for alteration.

To change the stage number, it is only required to input the value directly, then press to complete the setting.

In which: "A1"~"A5" are respective the stage numbers setting value of mould opening, mould clamping, injection, pressure holding and plasticizing.

5.2.33 Ramp Setting

Ramp Setting Screen (67)

Ramp Setting		Mold Name:		No. : 1		2008-1-22 11:05	
MANUAL							
S11	A1	PR1	B1	BP1	C1	S21	D1
S12	A2	PR2	B2	BP2	C2	S22	D2
S13	A3	PR3	B3	BP3	C3	S23	D3
S14	A4	PR4	B4	BP4	C4	S24	D4
S15	A5	PR5	B5	BP5	C5	S25	D5

	0000.0 mm		PPPP P mm		0000.0 mm		SSS Kg/cm ²
--	-----------	--	-----------	--	-----------	--	------------------------

Press + to enter the ramp setting screen (67).

Press to choose slope, and input corresponding slope, then press to complete the setting.

In which: "S", "PR", "BP" are respective abbreviation of Speed, Press and Back Press.

S11: Speed slope of fast mould clamping and low pressure mould clamping;

S12: Speed slope of mould opening;

S13: Speed slope of injection and plasticizing;

S14: Speed slope of melt decompression;

S15: Speed slope of mould clamping while adjusting mould clamping force;

PR1: Pressure slope of fast mould clamping;

PR2: Pressure slope of mould opening;

PR3: Pressure slope of injection and plasticizing;

PR4: Pressure slope of melt decompression;

PR5: Pressure slope of mould clamping while adjusting mould clamping force.

5.2.34 Speed 1 Output Setting

Speed 1 Output Setting Screen (68)

Speed1 Output Setting		Mold Name		No.	1	2008-1-22 11:21	
0rpm ## bar							
0Volt	A						
B1 %	C1	B7 %	C7	B13 %	C13	B19 %	C19
B2 %	C2	B8 %	C8	B14 %	C14	B20 %	C20
B3 %	C3	B9 %	C9	B15 %	C15	B21 %	C21
B4 %	C4	B10 %	C10	B16 %	C16	B22 %	C22
B5 %	C5	B11 %	C11	B17 %	C17	B23 %	C23
B6 %	C6	B12 %	C12	B18 %	C18	B24 %	C24
SL049	D1 %	SL140	D9 %	SL148	D17 %	SL156	D25 %
SL050	D2 %	SL141	D10 %	SL149	D18 %	SL157	D26 %
SL051	D3 %	SL142	D11 %	SL150	D19 %	SL158	D27 %
SL052	D4 %	SL143	D12 %	SL151	D20 %	SL159	D28 %
SL053	D5 %	SL144	D13 %	SL152	D21 %	SL160	D29 %
SL054	D6 %	SL145	D14 %	SL153	D22 %	SL161	D30 %
SL055	D7 %	SL146	D15 %	SL154	D23 %	SL162	D31 %
SL056	D8 %	SL147	D16 %	SL155	D24 %	SL163	D32 %



Press + to enter the speed 1 output setting screen (68).



Press to choose the speed, and input corresponding speed, then press key, to complete the setting.

Note: As the speed percentage increasing, the corresponding analog value of speed output will also increase, decreasing is not allowed, otherwise, the output speed signal will be in disturbance, which causes the machine instable.

5.2.35 Pressure Output Setting

Pressure Output Setting Screen (69)

Press  +  three times to enter the pressure output setting screen (69).

Press  to choose pressure, and input the corresponding pressure, then press , to complete the setting.

In which, four groups and two rows respective are: pressure percentage and pressure output analog value.



Note: As the pressure percentage increasing, the corresponding analog value of pressure output will also increase, decreasing is not allowed, otherwise, the output pressure signal will be in disturbance, which causes the machine instable.



5.2.36 Back Pressure Output Setting

Back Pressure Output Setting Screen (70)

Bak Pr Output Setting		Mold Name		No.		2008-1-22 11:38	
0rpm 250 bar							
0Volt	A						
B1 %	C1	B7 %	C7	B13 %	C13	B19 %	C19
B2 %	C2	B8 %	C8	B14 %	C14	B20 %	C20
B3 %	C3	B9 %	C9	B15 %	C15	B21 %	C21
B4 %	C4	B10 %	C10	B16 %	C16	B22 %	C22
B5 %	C5	B11 %	C11	B17 %	C17	B23 %	C23
B6 %	C6	B12 %	C12	B18 %	C18	B24 %	C24

0000.0 mm
PPPP P mm
0000.0 mm
SSS Kg/cm²

Press  +  four times to enter the back pressure output setting screen (70).



Press  to choose back pressure, and input the corresponding value, then press , to complete the setting.



In which, four groups and two rows respective are: pressure percentage and pressure output analog value.

Note: As the back pressure percentage increasing, the corresponding analog value of back pressure output will also increase, decreasing is not allowed, otherwise, the output back pressure signal will be in disturbance, which causes the machine instable.

5.2.37 Speed 2 output setting

Speed 2 output setting (71)

Press  +  five times to enter the speed 2 output setting screen (71).

Press  to choose speed, and input the corresponding speed, then press , to complete the setting.

In which, four groups and two rows respective are: speed percentage and speed output analog value.

Note: As the speed percentage increasing, the corresponding analog value of speed output will also increase, decreasing is not allowed, otherwise, the output speed signal will be in disturbance, which causes the machine instable.



Initial Setting Screen (72)

Initial Setting Screen (73)

Initial Setting		Mold Name:	No.	Date	
M-SSU-MI					2008-1-22 13:39
Oil Press	0bar	A1	175bar	B1	
Clamp Force	0ton	A2	5000ton	B2	

	Sys	Mold	Inj
Act	4095	4095	4095
Bar	2797	9998	2797

0000.0 mm
 PPPP F mm
 0000.0 mm
 SSS Kg/cm²

Press  to select the item to be set, input the corresponding value, and press  to complete the setting.

In this screen:

- "A1": Lower limit setting of oil pressure
- "A2": Upper limit setting of oil pressure
- "B1": Lower limit setting of mould clamping force
- "B2": Upper limit setting of mould clamping force

This screen is used for the setting of system origins, oil pressure and mould clamping force related parameters. Since these settings are related to the stability of the whole machine, they have been set by the manufacturer prior to delivery, and do not need modification if there is no special requirement. If necessary, please contact the customer service department for assistance.

5.2.39 Auxiliary Speed and Pressure Setting

Auxiliary Speed and Pressure Setting Screen (74)

Speed/Press Setting		Mold Name	No.	1	2008-1-22 13:58
MANUAL					
	Speed	Press			
0T012	A1	B1			
0T013	A2	B2			
0T014	A3	B3			
0T015	A4	B4			
0T016	A5	B5			
0T017	A6	B6			
0T018	A7	B7			
0T019	A8	B8			



0000.0 mm
 P P P P P
 0000.0 mm
 SSS Kg/cm²

Auxiliary Speed and Pressure Setting Screen (75)

Speed/Press Setting		Mold Name	No.	1	2008-1-22 14:02
MANUAL					
	Speed	Press			
0T20	A1	B1			
0T21	A2	B2			
0T22	A3	B3			
0T23	A4	B4			
0T24	A5	B5			
Clamp Force	C1	C2			
H.P. Clamp Pr		D			
Open Aux2	E				

0000.0 mm
 P P P P P mm
 0000.0 mm
 SSS Kg/cm²

Press + 8 and 9 times to enter the auxiliary speed and pressure setting screen (74) and (75).

Press  to select the item to be set, input the corresponding value, and press  to complete the setting.

"A": Auxiliary Speed;

"B": Auxiliary pressure;

"C1": Mould clamping force speed setting while automatic mould adjusting;

"C2": Mould clamping force pressure setting while automatic mould adjusting;

"D": Pressure setting for high-pressure mould clamping;

"E": Auxiliary position setting for mould opening;

OT012: Speed and pressure settings for mould clamping, injection and ejector decoder origins resetting;

OT016: Speed and pressure settings for special low pressure mould clamping.

Other settings are not used yet.

5.2.40 Timer Setting

Timer Setting Screen (76)

Timer Setting		Mold Name	No.	1	2008-1-22 14:28
RECALL					
MOTOR START	A1	NOZZ CLOSE	B1		
ORIGIN RESET	A2	ACC DELAY	B2		
MD ADJ MON.	A3	LOW PRE DLY	B3		
ALARM ON	A4	ACTION DLY	B4		
ALARM OFF	A5	DOOR MONI	B5		
OUTPUT MON.	A6	SPEC LOW PRE	B6		
TM066	A7	MD OPEN BP	B7		
GREASE TIMER	A8	NOZZ OPEN	B8		
EJE INTERVAL	A9	INJ CUSHION	B9		
COLD START	A10	PLA CUSHION	B10		

0000.0 mm
 FPPP P mm
 0000.0 mm
 SSS Kg/cm²

Press + 10 times to enter the timer setting screen (76).

Press to select the item to be set, input the corresponding value, and press to complete the setting.

In this screen:

- "A1": Setting of motor start time
- "A2": Setting of origin reset time
- "A3": Setting of mould adjustment monitor time
- "A4": Setting of alarm duration time
- "A5": Setting of alarm pause time
- "A6": Setting of action monitor time
- "A7": Auxiliary 66
- "A8": Setting of grease lubrication time
- "A9": Setting of ejector interval time
- "A10": Setting of cold start proof time
- "B1": Setting of nozzle closing time
- "B2": Setting of nitrogen ending time
- "B3": Setting of low pressure delay time
- "B4": Setting of action delay time
- "B5": Setting of safety door monitor time
- "B6": Setting of special low pressure time
- "B7": Setting of mould opening back pressure time
- "B8": Setting of nozzle open time

"B9": Setting of injection cushion time

"B10": Setting of plasticizing cushion time

5.2.41 Counter Setting

Counter Setting Screen (77)

Counter Setting		Mold Name: No. 1		2008-1-22 14:42	
RECALL					
CYCLE NO.	A1	FORCE FWD	B1		
REJECT NO.	A2	AUX11	B2		
PRODUCT TIME	A3	UNSCREW IN C	B3		
PURGE	A4	UNSCREW OT C	B4		
EJECT NO.	A5	AUX14	B5		
VIB EJT NO.	A6	AUX15	B6		
LUB CYCLE	A7	AUX16	B7		
GREASE CYCLE	A8	AUX17	B8		
CYCLE MONIT	A9	AUX18	B9		
FORCE BWD	A10	AUX19	B10		

Press + 11 times to enter the counter setting screen (77).

Press to select the item to be set, input the corresponding value, and press to complete the setting.

In this screen:

- "A1": Setting of cycle number
- "A2": Setting of rejected parts number
- "A3": Setting of production time
- "A4": Setting of purge number
- "A5": Setting of ejection number
- "A6": Setting of vibration ejection number
- "A7": Setting of lubrication cycle counting
- "A8": Setting of grease cycle counting
- "A9": Setting of cycle monitor counting
- "A10": Setting of force backward counting
- "B1": Setting of force forward counting
- "B2": Auxiliary 11
- "B3": Setting of unscrew in C counting
- "B4": Setting of unscrew out C counting
- "B5": Auxiliary 14
- "B6": Auxiliary15
- "B7": Auxiliary 16



"B8": Auxiliary 17

"B9": Auxiliary 18

"B10": Auxiliary 19

5.2.42 Factory Setting

Factory Setting Screen (78)

Factory Setting		Mold Name:	No.	:	1	2008-1-22 14:59
MANUAL						
Model :	A1					
Serial No. :	A2					
Date :	A3					
<div> </div>						

Factory Setting Screen (79)

Factory Setting		Mold Name:	No.	:	1	2008-1-22 15:02
MANUAL						
Max. Inj. Speed	A1					
Start Wait	A2					
Stage CL Adj. Wait	A3					
CL Adj. Wait	A4					
<div> </div>						

Press + 12 and 13 times to enter the factory setting screen (78) and (79).

Press to select the item to be set, input the corresponding value, and press to complete the setting.

These screens are used for modifying the original information of the system (like machine model, serial number, date of delivery etc).

Since the settings in screen (79) are related to the stability of the whole machine, they have been set by the manufacturer prior to delivery, and do not need modification if there is no special requirement. If necessary, please contact the customer service department for assistance.

In the screen (78):

- "A1": Setting of machine model
- "A2": Setting of machine serial number
- "A3": Setting of date of delivery

In the screen (79):

- "A1": Setting of maximum injection speed
- "A2": Setting of start delay
- "A3": Setting of each stage closed loop adjustment delay
- "A4": Setting of closed loop adjustment delay

5.2.43 Maintenance Setting

Maintenance Setting Screen (80)

Mold Name		No.	1	2008-1-22 15:28
No.	Last Date			
1 :	Please check lubri	0000/00/00	A1	
2 :	please make sure d	0000/00/00	A2	
3 :	Lubrication level	0000/00/00	A3	
4 :	Low lubrication pr	0000/00/00	A4	
5 :	Check oil pressure	0000/00/00	A5	
6 :	Lubricate all moni	0000/00/00	A6	
7 :	Check oil leakage	0000/00/00	A7	
8 :	Check limit switch	0000/00/00	A8	
9 :	Clean cooler	0000/00/00	A9	

Maintenance Setting Screen (81)

Mold Name		No.	3	2008-1-22 15:35
No.	Last Date			
10 :	Check oil quality	0000/00/00	A1	
11 :	Apply grease on bu	0000/00/00	A2	
12 :	Change hydraulic o	0000/00/00	A3	
13 :	Check cable status	0000/00/00	A4	
14 :	Check centre of no	0000/00/00	A5	
15 :	Check parallel of	0000/00/00	A6	
16 :		0000/00/00	A7	
17 :		0000/00/00	A8	
18 :		0000/00/00	A9	

Press + 15, 16 times to enter the maintenance setting screen (80) and (81).

Press to move the cursor to “Last Date” position, and press key, a “?”

appears after the “Last Date”, then press key to confirm and initialize the “Last Date” to the current date of the system, then the maintenance reminding time will be counted from current time of the system.

Set the time interval for machine maintenance reminder so that the customer could maintain the machine regularly and obtain higher production efficiency.

The 2 columns stand for: The last reminding time of the maintenance content indicated;
The reminding time interval setting of the maintenance content indicated. If it sets as "0", there should be no maintenance reminder.

5.2.44 Alarm History

Alarm History Screen (82)

Alarm History

Mold Name




No. : 1



2008-1-22 15:59

MANUAL

SD: OFF

OCCUR		RECOVERY		CONTENTS
2008/01/01	15:00	2008/01/01	15:00	AL79: STEPPER ERROR
2008/01/01	15:00	2008/01/01	15:00	AL06: PUMP O/L ALM
2008/01/01	15:00	2008/01/01	15:00	AL79: STEPPER ERROR
2008/01/01	15:00	2008/01/01	15:00	AL06: PUMP O/L ALM
2008/01/01	15:00	2008/01/01	15:00	AL79: STEPPER ERROR
2008/01/01	15:00	2008/01/01	15:00	AL50: PUMP MOTOR NOT START
2008/01/01	15:00	2008/01/01	15:00	AL79: STEPPER ERROR
2008/01/01	15:00	2008/01/01	15:00	AL50: PUMP MOTOR NOT START
2008/01/01	15:00	2008/01/01	15:00	AL79: STEPPER ERROR
2008/01/01	15:00	2008/01/01	15:00	AL50: PUMP MOTOR NOT START
2008/01/01	15:00	2008/01/01	15:00	AL79: STEPPER ERROR
2008/01/01	15:00	2008/01/01	15:00	AL50: PUMP MOTOR NOT START
2008/01/01	15:00	2008/01/01	15:00	AL79: STEPPER ERROR
2008/01/01	15:00	2008/01/01	15:00	AL50: PUMP MOTOR NOT START
2008/01/01	15:00	2008/01/01	15:00	AL79: STEPPER ERROR
2008/01/01	15:00	2008/01/01	15:00	AL50: PUMP MOTOR NOT START


 0000.0mm  PPPP mm  0000.0 mm  SSS Kg/cm²



Press  to display the alarm history screen (82), and then press  to switch pages.

5.2.45 Network

Network Screen (83)

Network	Mold Name	No. :	1	2008-1-22 16:15
MANUAL				
Job Name	Progress		0/65000	
Name		Log Out	Mode	No Order
Job Card	Job Card			
Job No.	Job Name	Mold Name	Progress	
Mould		Save Mold	Find Mold	
Mold Name	Machine	Version	Date	Time
	0000.0 mm	PPFP P mm	0000.0 mm	SSS Kg/cm ²

Press  to enter the network screen (83) (which is only available when you have bought the iCHEN network system of Chen Hsong Group).

Press  to select the item to be set, input the corresponding value, and press  to complete the setting.



This function is utilized in industrial automation and automatic orders scheduling and production data logging (wire and wireless), and it guarantees the safety of the technical parameters and the extension of the production scale.



In this screen: Press  or  to select the following 13 modes,

- (1) Changed (2) Suspended (3) Out of Servi (4) Waiting Mold (5) Waiting Mate
- (6) Change Mater (7) Replace Mold (8) Test Mold (9) Fix Mold (10) Adjust Color
- (11) Production (12) No Order (13) Other3.

5.2.46 Change Password

Change Password Screen (84)

Press  and  keys for over 5 seconds to enter the change password screen (84)
(This password is used system operator and supervisor).

Press  to select the item to be set, input the corresponding value, and press  to complete the setting.

To facilitate the operation and management of the machine, every controller has an initial password when delivery. In this screen, it is suggested to change the class 1 and 2 passwords immediately for better use.

Of which:

"A1": The old password to be modified


"A2": The new password to be inputted



"A3": New password input confirmation

5.2.47 Manual Lubrication Setting

Manual Lubrication Setting Screen (85)

Carrage Lubrication		Mold Name:		No. :		2008-1-18 10:34	
MANUAL							
Carr Fast	Sp. A1 %	Pr. A2 %	Time A3 s	Carr Back	Sp. C1 %	Pr. C2 %	Time C3 s
Carr Slow	B1 %	B2 %					
LUB. CYCLE				D1 t	*****		
LUBE. TIME				D2 s			
LBU. ALARM				D3 s			
0000.0 mm		P P P P P mm		0000.0 mm		SSS Kg/cm ²	

Press  to enter the manual lubrication setting screen (85).

Press  key to select the parameters to be set, input the value and press  to complete the setting.

In this screen:

"D1": Setting of lubrication cycle.

"D2": Setting of lubrication time.

"D3": Setting of lubrication alarm time.

5.2.48 Mould Adjustment Setting

Mould Adjustment Setting Screen (86)

Thickness & Clamp Force		Mold Name:	No. :	1	2008-1-22 17:28
MANUAL					
Max. Thick A1 mm	Act Thick A2 mm	Min. Thick A3 mm			
Mould Thick A4 mm		A5			
Mold Adj-> A6	Sp. A8	Pr. A9	Auto Force A10	A12 p	
Mold Adj-< A7			Clamp Force A11		
0000.0 mm P P P P mm 0000.0 mm SSS Kg/cm ²					

Press to enter the mould adjustment setting screen (86).

Press key to select the parameters to be set, input the value and press to complete the setting.

Manual mould thickness adjustment procedure is as follows:


Press key, the mould moves forward and its capacity is reduced; press key, the mould moves backward and its capacity is increased; press again the key to stop it.


In this screen:



- "A1": Maximum mould thickness
- "A2": Actual mould thickness
- "A3": Minimum mould thickness
- "A4": Setting of mould thickness
- "A5": Mould adjustment mode selection (Auto, Manual)
- "A10": Switch for automatic mould clamping force regulation (ON、OFF)
- "A11": Setting of mould clamping force
- "A12": Mould adjustment position.

5.2.49 Machine Adjustment

Machine Adjustment Screen (87)



Press  to enter the machine adjustment screen (87).

Press  key to switch to A, input the value and press  to complete the setting.

This screen is mainly used for machine adjustment, all current actions speed of the machine will reduce the set percentage. (If the current speed is A, and the speed reduction rate is set as B%, then the current speed = A x B%).

VI. Advanced Computer Operation

6.1 Initial Position Reset Procedure

The power supply to the computer may be suddenly cut off during machine operation. When the computer is restarted, a warning message is shown on the screen reminding the operator to reset the initial position.


Before resetting the initial position, check the setting as following:

- (i) Settings of the origin speed and pressure
Speed = 50% Pressure = 99%
- (ii) Origin reset timer TIM20 = 4 sec
- (iii) Initial setting screen (72)
Mould preset position: B1=1p
Ejector preset position: C1=0.5mm
Injection preset position: D1=0.5mm

6.1.1 Clamping


If the power supply to the computer is suddenly cut off during mould clamping or mould opening, the warning message "Reset origin clamp until no alarm" is shown on the screen when the computer is switched on.


The method of resetting the initial position for mould clamping is as follows:


Press  key after an interval of 4 seconds on the setting of timer TIM20 and the toggles are straightened, and the clamping position is automatically changed into mould clamping preset position B1=1p. The warning message disappears and the origin resetting is complete.



In case of products in the mould, firstly the products must be ejected with the methods below:

- (i) Open the mould till the movable platen stops. At the mould clamping preset position in initial setting screen (72), set B1 to 9999p, which shall be greater than the setting value

of slow mould open end position D1 in the mould opening screen (05). Press 

to move the cursor back to the mould clamping preset position and press 


key. The question mark "?" appears on the screen, press  and the actual clamping position is automatically changed into clamping preset position 9999p and the warning message disappears.

- (ii) Press  until the signal "Open Ends" is shown on the screen.
- (iii) Press  to eject out the products.
- (iv) Move the cursor back to the clamping preset position and change B1 from 9999p to 1p.

6.1.2 Ejector

If the power supply to the computer is suddenly cut off during ejector movement, the warning message "Reset origin eject until no alarm" is shown on the screen, after the computer is switched on again.

The method of resetting the ejector initial position is as follows:


Press  key after an interval of 4 seconds on the setting of timer TIM20 and the ejector retracts to its end position and the alarm message disappears. Now the actual position of ejector is automatically changed into ejector preset position 0.5mm, and the origin setting is complete.

If the ejector hasn't retracted to its end position, carry out ejector origin preset again.

6.1.3 Injection

If the power supply to the computer is suddenly cut off during injection or plasticization, the warning message "Reset origin injection until no alarm" is shown on the screen after the computer is switched on again.

The method of resetting injection initial position is as follows:

Press  key after an interval of 4 seconds on the setting of timer TIM20 and the injection operation is carried out to its end position. Then the actual injection position is automatically changed to injection preset position setting 0.5mm and the warning message disappears and the initial position setting is complete.

If the injection hasn't been carried out to its final end position after 4 seconds, perform the injection initial position resetting once more.



6.2 Decoder Initial Position Setting


- (1) In the initial setting screen (72), there are mould clamping preset, mould clamping origin, injection preset, injection origin, ejector preset and ejector origin.
 - (i) The functions of preset are to change the current value of the encoder position and manually set the initial position.
 - (ii) The function of origin is to reset the encoder positions.

- (2) The operation method of preset:

(The method of changing the encoder's actual position)(Clamping)

Move the cursor to B1 position of the clamping preset, input the position setting value and

press . Move the cursor back to the B1 position of preset and press , the

question mark “?” is shown on the screen. Press  to complete the setting. Now the current clamping position is the same as the B1 position of the clamping preset.

(The operation method of injection preset and ejector preset is the same as that of clamping preset described above)

Preset – This is for manually setting the initial position.

During the machine operation, if the initial position changes, the initial position can be reset by means of manually setting the origin.

- (3) Method for manually setting the clamping initial position

Before manually resetting the clamping initial position, check the settings as follows::

- (i) The settings of speed and pressure for the origin


Speed=50% Pressure=99%

- (ii) Reset origin time: TIM20=4 sec

- (iii) Check clamping preset position B1=1p

Note: (i) There should be no product in the mould. In case there is, the product must be taken out first.

- (ii) If the mould is equipped with the core-pulling and core-rotating devices, check their positions and strokes and ensure that the core-pulling and rotating devices are in a safe position to avoid any damage.

Method: Press  key to move the toggle forward. After an interval of 4 seconds

has expired on the setting of TIM20, the toggle fully extends, and the actual clamping position is automatically changed into B1 position 1p of clamping preset. The manual setting of the initial position is complete.


If the toggle fails to extend fully, manual setting of the initial position shall be carried out again.

(4) Method for manually setting the injection initial position

Caution: The temperature of the barrel must reach the setting point.

Injection preset position D1=0.5mm.




Press  key to carry out injection till the end position. The actual position for injection is automatically changed into the D1 position 0.5mm of injection preset. The manual setting of the injection initial position is complete.

(5) Method for manually setting the ejector initial position

Caution: Opening position must be at the end position.

Ejector preset position C1=0.5mm.



Press  key and the ejector retreats to the end position. The actual position for the ejector is automatically changed to the C1 position 0.5mm of the ejector preset.

The function of origin is to reset the encoder position automatically. Origin position is the position of the proximity switch for resetting the origin sensor. The setting of the origin shall be performed on the basis of the position of that proximity switch.

(6) Method for setting of clamping origin position

Clamping origin position is the position of the clamping reset sensor. During the mould opening, when the reset sensor is actuated, the clamping position origin is reset automatically.

- (i) Adjust the mould thickness to ensure the mould parts mounted on the stationary platen and movable platen can not touch each other when the toggle is extended fully. If there is no mould on the platens, this step can be ignored.
- (ii) On the initial setting screen (72), input a greater figure (say, 2000p) in the position B2 of clamping origin.
- (iii) Change the high pressure mould clamp end position G5 to 0p in the mould clamping setting screen (06).
- (iv) Carry out clamping and opening operations 3 times in manual mode. Each time when clamping is carried out, the toggle must be fully extended. Each time when opening is performed, the reset sensor must be actuated.
- (v) After performing the mould clamping operation for 3 times, write down the actual position of the clamp (say, 1250p) when the toggle is fully extended.
- (vi) The new clamping origin position (the position where the reset sensor is actuated) $B2=2000p-1250p=750p$.
- (vii) Enter the new value 750p into the B2 position of clamping origin.
- (viii) Carry out 3 further clamping and opening operations. If each time the actual clamp end position is below 10p, the setting of clamping origin position (the position of the clamping reset sensor) is complete. If it is a two-digit number or above, repeat steps (v)-(viii).
- (ix) Enter 100p into the high pressure mould clamp end position G5 in the mould clamping setting screen (06).

(7) Method for setting the injection origin position

The injection origin position is the position of the injection reset sensor. During plasticization, when the reset sensor is actuated, the injection initial position will be reset automatically.

Caution: The temperature of the barrel must reach the set point.

- (i) Enter a comparatively large figure (say, 100mm) into the injection origin position D2 in the initial setting screen (72). This figure must be smaller than the setting of plasticization position.
- (ii) Carry out injection and plasticization operations 3 times in manual mode. Each time when injection is carried out, the stroke must be completed until the end position is reached, and only then plasticization can be started. During plasticization, the reset sensor must be actuated.
- (iii) After performing the injection operation for 3 times and when the injection stroke comes to its end position, record the actual position of injection (say, 68mm).
- (iv) The new injection origin position (the position where the reset sensor is actuated) $D2 = 100\text{mm} - 68\text{mm} = 32\text{mm}$.
- (v) Enter the new figure 32mm into the D2 position of injection origin.
- (vi) Carry out 3 further injection and plasticization operations. If the actual end position of the injection stroke is below 0.5mm, the setting of injection origin position (the position of injection reset sensor) is complete. If such end position is above 0.5mm, steps (iii)-(vi) shall be repeated.

(8) Method for setting the ejector origin position

The ejector origin position is the position of the ejector reset sensor. When the ejector backward is complete and the reset sensor is actuated, the initial position will be reset automatically.

Caution: The mould-opening stroke must reach its end position.

- (i) Enter a comparatively large figure (say, 15mm) into the ejector origin position C2 in the initial setting screen (72).
- (ii) Carry out ejector forward and backward operations 3 times in manual mode. Each time the ejector backward must be carried out to its end position and the ejector reset sensor must be actuated.
- (iii) After performing the ejector forward and backward operations 3 times and the ejector backward has been carried out to the end position, record the actual position of the ejector (say, 8.5mm).
- (iv) The new ejector origin position (the position where the reset sensor is actuated) $C2 = 15\text{mm} - 8.5\text{mm} = 6.5\text{mm}$.
- (v) Enter the new figure 6.5mm into the C2 of ejector origin position.
- (vi) Carry out 3 further ejector forward and backward operations. If each time the ejector backward end position is below 1mm, the setting of ejector origin position (the position of ejector reset sensor) is complete. If such end position is above 1mm, steps (iii)-(vi) shall be repeated.

Caution: The settings on this screen have been tested before delivery. Do not change them willfully so as to avoid impairing machine stability.

6.3 Alarm and Treatment

Description of Computer Alarm Message

No.	Message	Description
AL000	Alarm 1	System alarm 1
AL001	Alarm 2	System alarm 2
AL002	Big Cylinder Not Located	
AL003	Barrel Temperature Not Reach	Actual barrel temperature is lower than the minus deviation of setting temperature.
AL004	Lubrication Oil Level Too Low	The oil level of lubrication oil is too low.
AL005	Low Lub Press	Lubrication pressure too low. Oil pipe break or oil pump damage.
AL006	Pump O/L Alm	Check the overload of oil pump motor.
AL007	Md Adj O/L Alm	Check the overload of mould-adjust motor.
AL008	Rear Door Alm	Close the rear safety door and check the limit switch.
AL009	Front Door Alm	Close the front safety door and check the limit switch.
AL010	Md Adj-Limit Alm	The mold thickness is less than the minimum thickness or check safety limit switch for mold-adjusting.
AL011	Md Adj+Limit Alm	The mold thickness exceeds the maximum thickness or check the safety limit switch for mold-adjusting.
AL012	Safety Door limit Error	
AL013	Safety Door Latch Error	
AL014	Grease Pressure Not Enough	
AL015	Cooling Water Not Open	
AL016	Aux	Not Used
AL017	Aux	Not Used
AL018	Aux	Not Used
AL019	Nozz Fwd LS Alm	The limit switch for carriage forward has not been triggered during automatic operation.
AL020	Nozz Guard Open	The purge guard fails to be closed during injection.
AL021	Nozz Block Alm	The nozzle is blocked by foreign matters. Check the injection position setting or nozzle.
AL022	Short Shot or Over Shot	Injection end position has gone beyond the tolerance setting. Adjust the tolerance setting or check ring.

AL023	No Material Alm	During automatic operation, plasticization time exceeds cooling time setting. Check for hopper blocking.
AL024	Cyc Completed Alm	The actual cycle counter has reached the production counter setting under automatic operation.
AL025	Cyc Time Long Al	The production cycle time exceeds the alarm setting of the cyclic time.
AL026	Md Protect Alm	There are plastics in mold or the high-press clamp position and low-press time setting are not correct.
AL027	Please Check Robot Fixture	
AL028	Take Out Failure	Photo eye is on, but no product is detected.
AL029	Photo Cut Alm	When photo cell is used for recycle, please clean off the products or foreign matters on the slide way.
AL030	Oil Temp Low Alm	The actual temp of the hydraulic oil is lower than the setting for the minus allowed deviation.
AL031	Oil Temp High Alm	The actual temp of the hydraulic oil is higher than the setting for the plus allowed deviation.
AL032	Core LS Alm	During automatic operation the core-pulling time exceeds the setting of the limit alarm time of the core.
AL033	Eje LS Alm	During automatic operation the ejection time exceeds the setting of the limit alarm time of the ejector.
AL034	Check Safety Valve For Door	
AL035	Acc Charge Alm	When ACC injection is ON, charging time exceeds cooling time. Please check the charging pressure switch.
AL036	Md Adj Sensor Alm	During mold-adjustment the mold adjustment sensor is found to be faulty. Please check the mold-adjustment.
AL037	Air Pressure For Robot Too Low	
AL038	Barrel Preheat	Preheat function turn ON.
AL039	Check Unscrew Counting Sensor	During automatic operation, the unscrewing time exceeds the setting of the limit alarm time.
AL040	Auto Md Thick Adj In Progress	
AL041	Auto Md Clp Force Adj In Progress	Appear when using automatic mould clamping force adjustment.
AL042	Auto Md Clp Force Complete	Appear when the automatic mould clamping force adjustment complete.

AL043	Barrel Temperature Too High	Actual barrel temperature is higher than the plus deviation of setting temperature.
AL044	Aux	Not Used
AL045	Door Limit Switch Error	Door limit switch has no signals in the setting time.
AL046	Mold Open/Close Error	During automatic operation the clamping/opening time exceeds the limit alarm time.
AL047	Product Eject Out Error	
AL048	Oil Filter Clog	Check and clean oil filter.
AL049	Robot Alarm	Check robot device.
AL050	Pump Motor Not Start	Check whether each phase voltage and 10A fuse are normal and AC 3A switch has tripped.
AL051	Mold Adjust Too Long	
AL052	Aux	Not Used
AL053	Aux	Not Used
AL054	Oil Screen Clog	Oil screen clogged while using high pressure oil filter.
AL055	Auto Mold Change	
AL056	Nut Closing Not Align	
AL057	Check Gate In/Out Limit	
AL058	Open Pressure Release Trouble	
AL059	Big Cylinder Over Travel	
AL060	Aux	Not Used
AL061	Oil Level Too Low	Check oil volume.
AL062	Mold Adjust Gear Trouble	
AL063	Mold Fitting Position Check	
AL064	Hydraulic Clamp Trouble	
AL065	Clamp Force Not Enough	
AL066	Back Pressure Too High	
AL067	Material Change In Progress	
AL068	AMC Table LS Error	
AL069	Pressure Sensor Detect Error	
AL070	Plast RPM Sensor Detect Error	
AL071	Control Cabinet Door Not Close	
AL072	Change Battery	
AL073	Auto Md Thick Adj Complete	
AL074	Injection Setting Not Good	
AL075	Aux	Not Used
AL076	Table In Rotation	
AL077	Stopper Not Return	
AL078	Auto Mold Adjust Error	
AL079	Stepper Error	

AL080	Aux	Not Used
AL081	Ejector Plate Not Return	
AL082	Safety Valve Error	
AL083	Semi/Auto Mode	
AL084	Door Latch Error	
AL085	Air Pressure Not Enough	
AL086	Aux	Not Used
AL087	Aux	Not Used
AL088	Preform Not Drop	
AL089	Aux	Not Used
AL090	Robot Safety Check Error	
AL091	Robot Not Zero Return	
AL092	Servo Control Alarm	
AL093	Open End Position Error	
AL094	Mold Not Closed	
AL095	Plasticization Not End	
AL096	Clean Up Barrel	
AL097	Adjustment !	
AL098	Gate In Not End	
AL099	Barrel Temperature Too Low	
MG01	Clamp End	In manual mode, mould clamping complete display.
MG02	Open End	In manual mode, mould opening complete display.
MG03	Open Not End	While manual mould adjustment or ejector operation, mould opening stroke does not end display.
MG04	Eject Forward End	In manual mode, ejection complete display.
MG05	Eject Backward End	In manual mode, ejector retraction complete display.
MG06	Plast End	In manual mode, plasticization complete display.
MG07	Melt End	In manual mode, melt decompression complete display.
MG08	Lub In Process	
MG09	Power Off Then On Again	
MG10	Clamp In Process	
MG11	Preheat In Process	Barrel preheat function activated.
MG12	Plast Delay	After injection, perform plasticization when delay time has reached.
MG13	Md Adj In Process	
MG14	Turn On/Off twice	
MG15	Plast In Process	

6.4 Moulding Operation Instruction

6.4.1 Setting of Temperature Control

When the power is turned on, the temperature display appears. Refer to screen (03). When the symbol “▲” is shown in the picture, it means that the electric heater is switched on and the temperature control key light shines.

(1) Temperature Setting of Each Stage:







For the temperature setting of Stage 1, press , set the temperature at the position of T1 on the screen and a reverse cursor is produced. Enter the required


figure and press  to input the data into the computer. Now the cursor moves to the setting of the next stage. To stop the temperature setting, press any other function key to clear the cursor.

For the temperature setting of Stage 2, except for pressing  the other steps are the same as for the temperature setting of Stage 1.

For the temperature setting of Stage 3, except for pressing  the other steps are the same as for the temperature setting of Stage 1.

For the temperature setting of Stage 4, except for pressing  the other steps are the same as for the temperature setting of Stage 1.

For the temperature setting of Stage 5, except for pressing  the other steps are the same as for the temperature setting of Stage 1.

For the temperature setting of Stage 6, except for pressing  the other steps are the same as for the temperature setting of Stage 1.

Among all the temperature stages, the settings of Stage 5 and 6 are subject to the machine type and requirements of the customer. When the machine is equipped with the oil temperature control device, the control function will be realized via the temperature of Stage 6. The standard value is normally within the range of 35°C-40°C. TC7 relay output from the I/O board controls the opening and closing of the water gate to make the oil temperature consistent with requirements. Normally the setting of the high-temperature positive deviation of the temperature of Stage 6 is 15°C, and low-temperature negative deviation is 30°C. Thus when the setting of the standard oil temperature is 35°C, its allowable range will be 5°C-50°C. When the oil temperature goes beyond this range, an alarm will be given.

(2) Temperature Setting of the Nozzle

The temperature zone of the nozzle is a constant temperature controlled zone. It is used to achieve the constant temperature requirement of the nozzle. Its setting range is 00% to 99%. If the setting is 99%, 10-30 seconds may be set in the computer as the full-period heating time. If the setting is 20 seconds, it means 20 seconds is one cycle of the thermostatic control.

Example: Nozzle temperature setting: 60%; Constant temperature time: 20 seconds.

That is to say:

$20 \times 60\% = 12$ seconds The heater of the nozzle zone is in "ON" state

$20 - 12 = 8$ seconds The heater of the nozzle zone is in "OFF" state

- (3) When no temperature control is applied for a certain zone, the temperature of that zone will be set to 0.


6.4.2 Setting of the Temperature Deviation (Alarm)

For the temperature deviation alarm, there are high and low temperature settings. Refer to screen (19). When either of the deviation settings is exceeded, either the high-temperature or low-temperature alarm will be shown on the screen.

High temperature deviation setting value could be $+20^{\circ}\text{C} \sim +90^{\circ}\text{C}$

Low temperature deviation setting value could be $-20^{\circ}\text{C} \sim -90^{\circ}\text{C}$

6.4.3 Setting of the Temperature Preheat Function


For the setting of temperature preheat function, press  and refer to screen (19). Temperature preheat maintains the temperature settings of all zones at the set preheat temperature percentage.

Example: Setting: 20%; Temperature Setting 250°C

$$250^{\circ}\text{C} \times (100\% - 20\%) = 200^{\circ}\text{C}$$


If the temperature drops from the set point to 200°C , the corresponding zone will be in the temperature control state.

6.4.4 Selection of Fully Automatic, Semi-Automatic or Manual Operation

- (1) If manual operation is to be selected, press . When the power is switched on, the computer will be in manual operation state automatically without the requirement of pressing the key again. Then it is required to return to manual operation after operating in any other mode or when the screen is reset, the above key shall be pressed.




- (2) If semi-automatic operation is to be selected, press  and the machine will

operate in semi-automatic mode. Now, the front safety door may be opened and closed every cycle to confirm the operation of the next cycle. Please note that the power supply of the oil pump will be automatically cut off when the rear safety door is opened.

- (3) If fully-automatic operation is to be selected, press  and the machine will operate in fully-automatic mode. The operator may confirm the operation of the next cycle by selecting the cycle restart time, photo eye sensor or robot resetting.


Only one of the above three modes may be selected at a time. Before selection, the setting of moulding conditions shall be completed and all operating items of the cycle shall be confirmed. In case that the LED of any of the three keys is flashing, it means the data in the computer is locked and can not be changed. As for the locking and unlocking methods, consult the professional personnel of the client's plant in charge of data modification.

6.4.5 Setting of Position, Speed and Pressure Data

- (1) Select the correct screen keys for the required operation. When the key for the required operation is pressed, the corresponding screen is shown for setting or modification at once.
- (2) For the setting of the position data, either the optical encoder parameters (p) or the stroke settings (mm) may be used for this purpose. When the stroke is set, the corresponding optical encoder figures may be automatically obtained through conversion by the computer.
- (3) When the function screen is shown and no further changes are to be made by the operator, press  or  or  and the normal operation screen will automatically appear. In semi-automatic or fully-automatic operation, if none of the keys are pressed within 30 seconds, the monitor will return to the normal operation screen.

6.4.6 Setting of the Numerical Data for Moulding Conditions

When setting moulding conditions, it is necessary to enter the data of such items as the position, stroke, speed, pressure, timers and counters of the optical encoder. For digital input of this data, move the cursor to the position of the figures requiring change and enter the correct data. If the entered data is not correct, warnings as to the scope of the data to be entered will appear on the screen as well as new data prompts. Now the next data

change can be made only after pressing .

6.4.7 Adjustment of Proportional Numerical Control

Sophisticated proportional adjustment is applied to control the speed and pressure of operation of the machine. The use of percentage speed and pressure greatly facilitates recording and future readjustment.

Numerical control of the speed and pressure is achieved by the computer, which provides different current values to control the proportional pressure valve and proportional flow valve in the hydraulic circuit for different operations.

When the pressure ranges in $20\text{Kg/cm}^2 \sim 145\text{-}175\text{Kg/cm}^2$, the corresponding setting range of the working current of the proportional pressure valve is $200\text{mA} \sim 800\text{mA}$.

The setting of the working current of the proportional flow valve (speed valve) range is $200\text{mA} \sim 680\text{mA}$.

(1) Closed-loop Control

When closed-loop control system IC is used, the machine shall be equipped with system pressure transducer and proximity switches for checking the speed of the screw. In this mode, the computer may automatically linearize the speed and pressure of the machine and record the linearity data.

Linearization of the speed and pressure shall be carried out separately by the methods covered in screen (46) and (47). The computer will carry out the next operation only after such linearization has been completed.

(2) Open-loop Control

In normal cases, open-loop control mode is applied. In such mode, numerical control can only be adjusted manually.

Linearization of the speed and pressure shall be carried out separately by the methods covered in screen (46) and (47).

On the I/O board of the computer, the adjustable potentiometer PRG is for linearizing the maximum pressure output 99% and PR0G is for linearizing the zero pressure output 0%. Similarly, SPIG is for linearizing the maximum speed output 99% and SPI0G is for linearizing the zero speed output 0%.

6.4.8 Description of the Computer Internal Counters

No.	Function	Description
CT00	Cycle No.	No. of moulding setting
CT01	Reject No.	No. of rejected parts setting
CT02	Product Time	Total time required by production Unit: 0.1 hour
CT03	Purge	No. of purge setting
CT04	Eject No.	No. of ejection setting
CT05	Vibration Eject No.	Setting of No. of ejector vibration times, i.e. the back and forth vibration times of the ejector after ejection
CT06	Lubrication Cycle	Setting of No. of moulding cycles in the automatic lubrication interval
CT07	Grease Cycle	No. of grease cycle setting
CT08	Cycle Monitor	No. of cycle monitor setting
CT09	Force Backward	In use while the automatic mould clamping force adjustment
CT10	Force Forward	In use while the automatic mould clamping force adjustment
CT11	Aux 11	Reserved function
CT12	Unscrew In C	Unscrew forward revolution setting
CT13	Unscrew Out C	Unscrew backward revolution setting
CT14	Aux 14	Reserved function
CT15	Aux 15	Reserved function
CT16	Aux 16	Reserved function
CT17	Aux 17	Reserved function
CT18	Aux 18	Reserved function
CT19	Aux 19	Reserved function

6.4.9 Description of the Computer Internal Timer

No.	Function	Description
TM00	Cycle Time	Cycle time
TM01	Clamp Time	Mould clamping time
TM02	Carriage Forward	Carriage forward time
TM03	Filling	Material filling time
TM04	Hold Time	Pressure holding time
TM05	Plasticizing Delay	Under semi/fully automatic mode, the time delay interval between the end of injection and the start of next plasticizing motion
TM06	Cooling	Under auto mode, the time interval between end of injection and mould opening
TM07	Before Decompression	Pre-plasticizing decompression time
TM08	Plasticizing	Plasticizing time
TM09	After Decompression	After plasticizing decompression time
TM10	Carriage Backward	Carriage backward time
TM11	Mould Open	Mould opening time
TM12	Ejection Time	Ejection Time
TM13	Recycle	Under fully-automatic mode, the time interval between end of ejection and the start of next mould clamping
TM14	Injection Time	Total injection time, excluding the time of pressure holding
TM15	Hold 1 Time	Pressure holding stage 1 time
TM16	Hold 2 Time	Pressure holding stage 2 time
TM17	Hold 3 Time	Pressure holding stage 3 time
TM18	Hold 4 Time	Pressure holding stage 4 time
TM19	Hold 5 Time	Pressure holding stage 5 time
TM20	Purge Plasticizing	Plasticizing time during automatic purge
TM21	Ejector Pause	During automatic ejection, the time allowed for the ejector to stop at the forward position before its retraction
TM22	Core A In	Core A in time
TM23	Core A Out	Core A out time
TM24	Core B In	Core B in time
TM25	Core B Out	Core B out time
TM26	Core C In	Core C in time
TM27	Core C Out	Core C out time
TM28	Core D In	Reserved function
TM29	Core D Out	Reserved function

TM30	Lubrication Time	Lubrication oil supply time, over 10 seconds is suggested
TM31	Lubrication Alarm	Reserved function
TM32	Carriage Fast	Duration of fast carriage advance
TM33	Carriage Back	Under semi/fully automatic mode, the duration of carriage retraction. If no need to retract the carriage, set this time to 0
TM34	Melt Before Plasticizing	Reserved function
TM35	Cycle Timer	Allowable longest cycle time. Alarm if it exceeds.
TM36	Eject Out Delay	Time interval between mould opening end and next action
TM37	Low Pressure Detection	The allowed time interval between the start of low pressure clamping and the actuation of high pressure clamping
TM38	HP Charge Delay	Reserved function
TM39	High Press End Delay	Reserved function
TM40	Clamping End Delay	Time interval between clamping end and next action
TM41	Vibration Ejection	Ejector retraction position of vibration ejection
TM42	Carriage Bwd Delay	Delay of carriage retraction after melt decompression
TM43	Carriage End Delay	Reserved function
TM44	Purge Buffer	Reserved function
TM45	Door Open Slow	Reserved function
TM46	Door Open	Reserved function
TM47	Mould Adj Delay	Buffer time of change between advance and retraction of mould adjustment (the time is suggested to set over 0.3 seconds)
TM48	Clamping Interval	Buffer time of change between mould opening and clamping (the time is suggested to set over 0.1 seconds).
TM49	Fast Open Delay	Reserved function
TM50	Air 1 Timer	Duration of blowing 1
TM51	Air 2 Timer	Duration of blowing 2
TM52	Air 3 Delay	Time delay of blowing 3
TM53	Air 3 Timer	Duration of blowing 3
TM54	Force Forward	Automatic mould adjustment force forward time, which is suggested to set 2 seconds
TM55	Fore Backward	Automatic mould adjustment force backward time, which is suggested to set 0.3 seconds
TM56	Air 1 Delay	Reserved function
TM57	Air 2 Delay	Reserved function
TM58	Core F In	Reserved function

TM59	Core F Out	Reserved function
TM60	Motor Start	Motor start Y→△ time
TM61	Origin Reset	Encoder origin reset time, which is suggested to set 3~5 seconds
TM62	Mould Adj Monitor	Mould adjustment sensor monitor time. Alarm if it exceeds
TM63	Alarm On	Alarm (buzzer and signal lamp) duration, which is suggested to set 10 seconds
TM64	Alarm Off	Alarm (buzzer and signal lamp) pause time, which is suggested to set 10 seconds
TM65	Output Monitor	Opening and clamping, eject and retraction, core pulling and inserting, carriage slow speed, injection. Alarm if time exceeds, which is suggested to set over 5 seconds.
TM66	Aux	Reserved function
TM67	Grease Timer	Reserved function
TM68	Ejection Interval	Time interval between ejector forward and ejector backward (the time is suggested to set 0.1 seconds).
TM69	Cold Start	Timing after machine starting. Injection, plasticizing and melt decompression can only be performed after the time out and the barrel temperature reaching the set value. (The time is suggested to set over 50 seconds)
TM70	Nozzle Close	Time of nozzle closing (used by the function of hydraulic nozzle closing)
TM71	Acc Delay	When using accumulator assisted injection, the accumulator discharge delay time during injection
TM72	Low Pressure Delay	Auxiliary oil valve open delay during low pressure clamping (low pressure/fast valve or back pressure valve)
TM73	Action Delay	Buffer time of each action (Opening and clamping, ejector retraction, core pulling and inserting, injection. The time is suggested to set 0.1 seconds.)
TM74	Door Monitor	Max. time allowed by the action of safety door. Alarm if time exceeds, which is suggested to set over 3 seconds.
TM75	Special Low Pressure	Duration of special low pressure after mould clamping starts
TM76	Mould Open Back Press	Duration of synchronous mould opening and back pressure

TM77	Nozzle Open	Action time of opening the nozzle (used by the function of hydraulic nozzle closing)
TM78	Injection Cushion	Buffer time of injection
TM79	Plasticizing Cushion	Buffer time of plasticizing
TM80	Hold 6 Time	Reserved function
TM81	Hold 7 Time	Reserved function
TM82	Hold 8 Time	Reserved function
TM83	Hold 9 Time	Reserved function
TM84	Hold 10 Time	Reserved function
TM85	Core E In	Reserved function
TM86	Core E Out	Reserved function
TM87	Stem 1 Relay	Reserved function
TM88	Stem 1 Open	Reserved function
TM89	Stem 2 Relay	Reserved function
TM90	Stem 2 Open	Reserved function
TM91	Stem 3 Relay	Reserved function
TM92	Stem 3 Open	Reserved function
TM93	Stem 4 Relay	Reserved function
TM94	Stem 4 Open	Reserved function
TM95	Stem 5 Relay	Reserved function
TM96	Stem 5 Open	Reserved function
TM97	Aux	Reserved function
TM98	Charge Monitor	Reserved function
TM99	High Press Release	Reserved function

6.4.10 Description of the Computer Inputs and Outputs

No.	Function	Description
EI00	Input Port	Front Door
EI01	Input Port	Rear Door
EI02	Input Port	Safety Door Limit Switch
EI03	Input Port	Carriage Limit Switch
EI04	Input Port	Core B In
EI05	Input Port	Core B Out
EI06	Input Port	Unscrew C Count
EI07	Input Port	Nozzle Guard
EI08	Input Port	Core A In
EI09	Input Port	Core A Out
EI10	Input Port	Photo Eye
EI11	Input Port	Accumulation End
EI12	Input Port	Mould Area Free
EI13	Input Port	Eject Forward Enabled
EI14	Input Port	Mould Close Enabled
EI15	Input Port	Eject Plate
EI16	Input Port	Mould Adjustment Overload
EI17	Input Port	Pump Overload
EI18	Input Port	Adjustment 1 Forward Limit Switch
EI19	Input Port	Adjustment 1 Backward Limit Switch
EI20	Input Port	Mould Adjustment Count
EI21	Input Port	Lubrication Oil Level
EI22	Input Port	Lubrication Oil Pressure
EI23	Input Port	Core C In
EI24	Input Port	Core C Out
EI25	Input Port	Filter
EI26	Input Port	Aux/Door Open

EI27	Input Port	Door Opened
EI28	Input Port	Door Closing Slow
EI29	Input Port	Clamping Preset
EI30	Input Port	Ejector Preset
EI31	Input Port	Injection Preset
EI32	Input Port	Motor Runned
EI33	Input Port	Auxiliary Pump Run
EI34	Input Port	Core D In
EI35	Input Port	Core D Out
EI36	Input Port	Core E In Limit Switch
EI37	Input Port	Core E Out Limit Switch
EI38	Input Port	Door Crash
EI39	Input Port	Oil Level
EI40	Input Port	Aux/Door Close
EI41	Input Port	Rear Door 2
EI42	Input Port	Ejector Backward Enabled
EI43	Input Port	Robot Emergency Stop
EI44	Input Port	Robot Emergency Stop 2
EI45	Input Port	Robot Off
EI46	Input Port	Enable Core A In
EI47	Input Port	Enable Core A Out
EI48	Input Port	Enable Core B In
EI49	Input Port	Enable Core B Out
EI50	Input Port	Grease Pressure
EI51	Input Port	Open Limit
EI52	Input Port	Clamp Limit
EI53	Input Port	Foot Plate
EI54	Input Port	Core F In Limit Switch
EI55	Input Port	Core F Out Limit Switch

No.	Function	Description
EO00	Output Port	Adjustment 1 Forward
EO01	Output Port	Adjustment 1 Backward
EO02	Output Port	Mould Close
EO03	Output Port	Carriage Forward
EO04	Output Port	Injection
EO05	Output Port	Plasticizing
EO06	Output Port	Melt Decompression
EO07	Output Port	Carriage Backward
EO08	Output Port	Mould Open
EO09	Output Port	Ejector Forward
EO10	Output Port	Ejector Backward
EO11	Output Port	Boost
EO12	Output Port	Core A In
EO13	Output Port	Core A Out
EO14	Output Port	Core B In
EO15	Output Port	Core B Out
EO16	Output Port	Accumulator Charge
EO17	Output Port	Accumulation Inject
EO18	Output Port	Air 2
EO19	Output Port	Air 1
EO20	Output Port	Mould Open Back Pressure
EO21	Output Port	Boost/Low Pressure
EO22	Output Port	Low Pressure Clamp
EO23	Output Port	Aux/Air 3
EO24	Output Port	Door Open
EO25	Output Port	Door Close
EO26	Output Port	Fast Open
EO27	Output Port	Auto Mode
EO28	Output Port	Mould Open End
EO29	Output Port	Door Closed
EO30	Output Port	Core C In
EO31	Output Port	Core C Out
EO32	Output Port	Gas Injection

EO33	Output Port	Door Slowdown
EO34	Output Port	Brake Release
EO35	Output Port	Core D In
EO36	Output Port	Core D Out
EO37	Output Port	Core E In
EO38	Output Port	Core E Out
EO39	Output Port	Small Pump
EO40	Output Port	Carriage In
EO41	Output Port	Carriage Out
EO42	Output Port	Mould Open/Close
EO43	Output Port	Auxiliary Pump 1
EO44	Output Port	Auxiliary Pump 2
EO45	Output Port	Core F In
EO46	Output Port	Core F Out
EO47	Output Port	Cooling Water
EO48	Output Port	Rejected Part
EO49	Output Port	Mould Closed
EO50	Output Port	Ejector Forward End
EO51	Output Port	Ejector Backward End
EO52	Output Port	Core A Forward End
EO53	Output Port	Core A Backward End
EO54	Output Port	Core B Forward End
EO55	Output Port	Core B Backward End
EO56	Output Port	High Pressure Release
EO57	Output Port	High Pressure Clamp
EO58	Output Port	High Pressure Open
EO59	Output Port	Nut Close
EO60	Output Port	Nut Open
EO61	Output Port	High Pressure Charge
EO62	Output Port	Tie Bar Forward
EO63	Output Port	Adjustment 2 Forward
EO64	Output Port	Adjustment 2 Backward
EO65	Output Port	Adjustment 3 Forward
EO66	Output Port	Adjustment 3 Backward




E067	Output Port	Adjustment 4 Forward
E068	Output Port	Adjustment 4 Backward
E069	Output Port	Plasticizing/Decompression
E070	Output Port	Pressure Charge
E071	Output Port	Stopper Enabled
E072	Output Port	High Pressure/Stopper
E073	Output Port	Pump 2
E074	Output Port	Pump 3
E075	Output Port	Pump 4
E076	Output Port	Pump 5
E077	Output Port	Pump 6
E078	Output Port	Aux
E079	Output Port	Aux

6.5 Ai-11 Special Screen Operation

1	Automatic Purge Setting Screen (10)	Press "INJECTION" three times
2	Carriage Setting Screen (14)	Press "CARR/LUB."
3	Temperature Deviation Alarm Setting Screen (19)	Press "TEMP."
4	Heat Channel Setting Screen (20~22)	Press "TEMP." twice
5	Function Setting Screen (23)	Press "FUNCTION"
6	Mould Data Selection Screen (24)	Press "MD DATA"
7	Quality Statistics Screen (25)	Press "STATIST"
8	Timer Monitor Screen (26-28)	Press "MONITOR"
9	Counter Monitor Screen (29)	Press "MONITOR" twice
10	Input Monitor Screen (30)	Press "MONITOR" three times
11	Output Monitor Screen (31-33)	Press "MONITOR" four times
12	Relay Monitor Screen (34~56)	Press "MONITOR" five times
13	Program Monitor Screen (57)	Press "MONITOR" six times
14	Injection Speed Curve Screen (59)	Press "GRAPH" twice
15	Injection Pressure Curve Screen (60)	Press "GRAPH" three times
16	System Time and Language Setting Screen (65)	Press "CANCEL" + "MAIN"
17	Action Stroke Stage Number Selection Screen (66)	Press "CANCEL" + "MAIN" twice
18	Factory Setting Screen (78~79)	Press "CANCEL" and "MD DATA" 12 times
19	Network Screen (83)	Press "ICHEN"
20	Manual Lubrication Setting Screen (85)	Press "CARR/LUB."
21	Machine Adjustment Screen (87)	Press "SLOW"


VII. Appendix (Ai-11 Electrical Diagram)

7.1 Ai-11 Main Circuit Diagram




Ai-11 Main Circuit Diagram


7.2 Ai-11 Main Circuit Diagram (UPS)




Ai-11 Main Cabinet Wiring Diagram



7.4 Ai-11 I/O Board Layout Diagram




7.5 Ai-11 I/O Board Input Connection




Ai-11 I/O Board Input Connection

7.6 Ai-11 I/O Board Input Connection (Large Machine)




Ai-11 I/O Board Input Connection (Large Machine)

7.7 Ai-11 I/O Board Output Connection




Ai-11 I/O Board Output Connection

7.8 Ai-11 I/O Board Output Connection (CE)




7.9 Ai-11 I/O Board Output Connection (Large Machine)




Ai-11 I/O Board Output Connection (Large Machine)

7.10 Ai-11 Extend Board 1 Wiring Diagram




Ai-11 Extend Board 1 Wiring Diagram

7.11 Ai-11 Extend Board 1 Wiring Diagram (CE)




Ai-11 Extend Board 1 Wiring Diagram (CE)

7.12 Ai-11 Extend Board 1 Wiring Diagram (Large Machine)




Ai-11 Extend Board 1 Wiring Diagram (Large Machine)

7.13 Ai-11 Extend Board 1 Layout Diagram




Ai-11 Extend Board 1 Layout Diagram

7.14 Ai-11 Extend Board 2 Wiring Diagram




Ai-11 Extend Board 2 Wiring Diagram

7.15 Ai-11 Extend Board 2 Layout Diagram




Ai-11 Extend Board 2 Layout Diagram

Ai-11 Hydraulic Semi-closed Loop Wiring Diagram A




7.17 Ai-11 Hydraulic Semi-closed Loop Wiring Diagram B




Ai-11 Hydraulic Semi-closed Loop Wiring Diagram B


7.18 Ai-11 Hydraulic Semi-closed Loop Wiring Diagram C



7.19 Ai-11 Hydraulic Semi-closed Loop Wiring Diagram D




7.20 Ai-11 Hydraulic Semi-closed Loop Wiring Diagram E




Ai-11 Digital MOOG Injection Closed Loop Wiring Diagram




7.22 Ai-11 MOOG Injection Closed Loop Input Connection



7.23 Ai-11 MOOG Injection Closed Loop Output Connection



7.24 Ai-11 Robot Interface (CE67A) Wiring Diagram



Ai-11 Robot Interface(EUR67) Wiring Diagram

7.25 Ai-11 Safety Relay Wiring Diagram

